



# SCREEN COMPATIBILITY

---

A comprehensive list of all the screen makes and models that we have previously made a mount for. If you can't find your screen within this list - don't panic! Just drop an email to [sales@unicol.com](mailto:sales@unicol.com) or **enter the screen details when ordering online** and we'll check its compatibility and design and manufacture a new one for you if necessary.

SEARCH VIA MANUFACTURER

SEARCH VIA GROUP CODE

During our 55+ years of manufacturing, we've produced dedicated/universal mounts for thousands of screens and during this time we've noticed that some of them match one another. These group codes reflect the different mounts produced and show what other screens will work with each code.

Whilst we keep this as up-to-date as we can, we know that some screens may be missing - if this is the case, please email [sales@unicol.com](mailto:sales@unicol.com) or enter the product details when ordering online.

|      |      |      |      |      |      |      |      |      |      |      |      |      |
|------|------|------|------|------|------|------|------|------|------|------|------|------|
| 0000 | 0035 | 0080 | 0117 | 0155 | 0191 | 0226 | 0266 | 0304 | 0342 | 0374 | 0417 | 0450 |
| 0001 | 0037 | 0082 | 0118 | 0156 | 0193 | 0228 | 0267 | 0305 | 0343 | 0375 | 0418 | 0451 |
| 0002 | 0045 | 0083 | 0119 | 0157 | 0194 | 0229 | 0268 | 0307 | 0344 | 0377 | 0419 | 0452 |
| 0003 | 0046 | 0084 | 0120 | 0159 | 0195 | 0230 | 0270 | 0308 | 0345 | 0378 | 0420 | 0455 |
| 0004 | 0047 | 0085 | 0123 | 0160 | 0196 | 0231 | 0271 | 0309 | 0347 | 0379 | 0421 | 0457 |
| 0005 | 0050 | 0086 | 0125 | 0161 | 0197 | 0232 | 0272 | 0310 | 0348 | 0380 | 0422 | 0458 |
| 0006 | 0051 | 0087 | 0128 | 0162 | 0198 | 0233 | 0273 | 0311 | 0349 | 0382 | 0423 | 0459 |
| 0007 | 0052 | 0088 | 0129 | 0164 | 0199 | 0234 | 0274 | 0312 | 0350 | 0383 | 0424 | 0460 |
| 0008 | 0053 | 0089 | 0131 | 0166 | 0200 | 0235 | 0275 | 0313 | 0351 | 0386 | 0425 | 0461 |
| 0009 | 0055 | 0090 | 0132 | 0168 | 0201 | 0236 | 0276 | 0314 | 0352 | 0388 | 0426 | 0462 |
| 0011 | 0059 | 0091 | 0133 | 0169 | 0202 | 0237 | 0277 | 0315 | 0353 | 0389 | 0428 | 0463 |
| 0012 | 0060 | 0092 | 0134 | 0170 | 0203 | 0238 | 0278 | 0317 | 0354 | 0391 | 0429 | 0464 |
| 0013 | 0061 | 0093 | 0135 | 0171 | 0204 | 0239 | 0279 | 0318 | 0355 | 0395 | 0430 | 0465 |
| 0014 | 0062 | 0094 | 0136 | 0172 | 0205 | 0241 | 0280 | 0319 | 0356 | 0398 | 0431 | 0466 |
| 0015 | 0063 | 0095 | 0137 | 0173 | 0206 | 0242 | 0281 | 0321 | 0357 | 0399 | 0432 | 0467 |
| 0016 | 0064 | 0096 | 0138 | 0174 | 0207 | 0243 | 0282 | 0322 | 0358 | 0400 | 0433 | 0468 |
| 0017 | 0065 | 0097 | 0139 | 0175 | 0208 | 0244 | 0284 | 0323 | 0359 | 0401 | 0434 | 0469 |
| 0018 | 0066 | 0098 | 0140 | 0176 | 0209 | 0245 | 0285 | 0324 | 0360 | 0402 | 0435 | 0470 |
| 0019 | 0067 | 0100 | 0141 | 0177 | 0210 | 0246 | 0287 | 0325 | 0361 | 0403 | 0436 | 0471 |
| 0022 | 0068 | 0101 | 0142 | 0179 | 0211 | 0248 | 0288 | 0326 | 0362 | 0404 | 0437 | 0472 |
| 0023 | 0069 | 0102 | 0143 | 0180 | 0212 | 0249 | 0290 | 0327 | 0363 | 0405 | 0438 | 0474 |
| 0024 | 0070 | 0104 | 0144 | 0181 | 0213 | 0250 | 0291 | 0329 | 0364 | 0406 | 0439 | 0475 |
| 0025 | 0071 | 0105 | 0145 | 0182 | 0214 | 0251 | 0292 | 0330 | 0365 | 0408 | 0440 | 0476 |
| 0026 | 0072 | 0108 | 0146 | 0183 | 0215 | 0252 | 0293 | 0332 | 0366 | 0409 | 0441 | 0477 |
| 0027 | 0073 | 0109 | 0147 | 0184 | 0216 | 0253 | 0295 | 0333 | 0367 | 0410 | 0442 | 0478 |
| 0028 | 0074 | 0110 | 0149 | 0185 | 0217 | 0254 | 0296 | 0334 | 0368 | 0411 | 0443 | 0479 |
| 0029 | 0075 | 0111 | 0150 | 0186 | 0218 | 0255 | 0297 | 0335 | 0369 | 0412 | 0444 | 0480 |
| 0030 | 0076 | 0112 | 0151 | 0187 | 0220 | 0256 | 0298 | 0336 | 0370 | 0413 | 0446 | 0481 |
| 0031 | 0077 | 0113 | 0152 | 0188 | 0221 | 0262 | 0300 | 0337 | 0371 | 0414 | 0447 | 0482 |
| 0032 | 0078 | 0114 | 0153 | 0189 | 0222 | 0263 | 0302 | 0338 | 0372 | 0415 | 0448 | 0484 |
| 0034 | 0079 | 0116 | 0154 | 0190 | 0223 | 0264 | 0303 | 0341 | 0373 | 0416 | 0449 | 0485 |

0486

0487

0488

0619

0668

0681

9000

9001

9002

9003

9004

9005

Prefer to look for which universal/dedicated mount best suits your projector via the manufacturer?

Click on the button below to be taken to the manufacturer part of this PDF!

[\*\*SEARCH VIA MANUFACTURER\*\*](#)

|      |            |                   |             |
|------|------------|-------------------|-------------|
| 0000 | NEC        | X 754 HB          | 71 - 90"    |
| 0000 | SAMSUNG    | UE 75 JU 6400     | 71 - 90"    |
| 0000 | SAMSUNG    | ME 40             | C1          |
| 0000 | CELLO      | C 28227           | 15 - 32"    |
| 0000 | HISENSE    | LTDN 50 D 36 TUK  | 33 - 57"    |
| 0000 | IYAMA      | LH 4780           | 33 - 57"    |
| 0001 | PROMETHEAN | 78                | Interactive |
| 0001 | EIKI       | PLD 42 UE         | 33 - 57"    |
| 0001 | FUJITSU    | PDS 4203          | 33 - 57"    |
| 0001 | FUJITSU    | PDS 4207          | 33 - 57"    |
| 0001 | FUJITSU    | HTM 42            | 33 - 57"    |
| 0001 | FUJITSU    | PDS 4201          | 33 - 57"    |
| 0001 | FUJITSU    | PDS 4204          | 33 - 57"    |
| 0001 | FUJITSU    | PDS 4202          | 33 - 57"    |
| 0001 | JVC        | V 4225 PZW        | 33 - 57"    |
| 0001 | JVC        | V 425 PZW         | 33 - 57"    |
| 0001 | JVC        | GDV 425 PZW       | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4212          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4221          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4211          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4222          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4208          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4213          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4229          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4242          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4234          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4233          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 42 TRS        | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4241          | 33 - 57"    |
| 0002 | FUJITSU    | PDS 4214 ES       | 33 - 57"    |
| 0003 | DELPHI     | PRO 42            | 33 - 57"    |
| 0003 | DELPHI     | PRO MARK 2        | 33 - 57"    |
| 0003 | HANTAREX   | PDP 42 QV         | 33 - 57"    |
| 0003 | HANTAREX   | PDP 42 UX GA      | 33 - 57"    |
| 0003 | HANTAREX   | P 42 UX GA MARK 3 | 33 - 57"    |
| 0004 | FUJITSU    | PDF 2174          | 33 - 57"    |
| 0004 | FUJITSU    | PDF 2130          | 33 - 57"    |
| 0005 | UNIVERSAL  | MVP 2420          | 33 - 57"    |
| 0005 | UNIVERSAL  | MVP 420           | 33 - 57"    |
| 0005 | VUTRIX     | 42 MM             | 33 - 57"    |
| 0006 | PANASONIC  | TH 85 PF 12 E     | 71 - 90"    |
| 0006 | PANASONIC  | TH 85 VX 200 W    | 71 - 90"    |
| 0007 | NEC        | LCD 8205          | 71 - 90"    |
| 0007 | SAMSUNG    | 820 DXN           | 71 - 90"    |
| 0007 | SAMSUNG    | 820 DXN 2         | 71 - 90"    |
| 0007 | SAMSUNG    | 820 DX 3          | 71 - 90"    |

|      |           |                   |           |
|------|-----------|-------------------|-----------|
| 0007 | SAMSUNG   | 820 TSN 2         | 71 - 90"  |
| 0008 | PHILIPS   | BDL 9870 EU       | 91 - 108" |
| 0009 | SHARP     | 108               | 91 - 108" |
| 0011 | MARANTZ   | PD 4200 N 1 M     | 33 - 57"  |
| 0011 | PHILIPS   | 42 FD 9932        | 33 - 57"  |
| 0011 | PHILIPS   | 422 F 9922        | 33 - 57"  |
| 0011 | PHILIPS   | 420 P 10          | 33 - 57"  |
| 0011 | PHILIPS   | 42 FD 9952        | 33 - 57"  |
| 0012 | PANASONIC | TC 37 P 1 F       | 33 - 57"  |
| 0012 | PANASONIC | TH 37 PWD 4       | 33 - 57"  |
| 0012 | PANASONIC | TH 37 PWD 5       | 33 - 57"  |
| 0012 | PANASONIC | TH 37 PWD 8       | 33 - 57"  |
| 0012 | PANASONIC | TH 37 PX 80       | 33 - 57"  |
| 0012 | PANASONIC | TH 37 PX 70       | 33 - 57"  |
| 0012 | PANASONIC | TC 42 P 1 F       | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PWD 3 B     | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PWD 4 B     | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PWD 6       | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PW 7 BX     | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PHD 8 BK    | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PHD 9 BK    | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PR 10       | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PS 9        | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PS 10       | 33 - 57"  |
| 0012 | PANASONIC | TH 42 PD 12       | 33 - 57"  |
| 0012 | SANYO     | PDP 42 WV 1 SR    | 33 - 57"  |
| 0012 | TOSHIBA   | PD 42 BW 1 E      | 33 - 57"  |
| 0012 | TOSHIBA   | 42 WP 37          | 33 - 57"  |
| 0012 | FUJITSU   | PDS 5001 E        | 33 - 57"  |
| 0012 | FUJITSU   | P 50 XCA 11 EH    | 33 - 57"  |
| 0012 | FUJITSU   | P 50 X 11 A 10 ES | 33 - 57"  |
| 0012 | JVC       | GVD 500 PZU       | 33 - 57"  |
| 0012 | JVC       | GVD 500 PCE       | 33 - 57"  |
| 0012 | JVC       | GDV 502 PCE       | 33 - 57"  |
| 0012 | PANASONIC | TH 50 PHW 3       | 33 - 57"  |
| 0012 | PANASONIC | TH 50 PWD 5 B     | 33 - 57"  |
| 0012 | PANASONIC | TH 50 PHD 6 BX    | 33 - 57"  |
| 0012 | PANASONIC | TH 50 PHD 8 BK    | 33 - 57"  |
| 0012 | PANASONIC | TH 50 PH 9 BK     | 33 - 57"  |
| 0012 | PANASONIC | TH 50 PF 10 EK    | 33 - 57"  |
| 0012 | PANASONIC | TH 50 PH 10       | 33 - 57"  |
| 0012 | PANASONIC | TH 50 PF 9        | 33 - 57"  |
| 0012 | PANASONIC | TH 50 PH 12 EK    | 33 - 57"  |
| 0012 | TOSHIBA   | 50 XP 27          | 33 - 57"  |
| 0012 | TOSHIBA   | 50 WP 16 B        | 33 - 57"  |
| 0012 | TOSHIBA   | PD 42 W 16 E      | 33 - 57"  |
| 0013 | NEC       | PX 33 M 2 G       | 33 - 57"  |
| 0013 | NEC       | PX 3300           | 33 - 57"  |

|      |            |                 |          |
|------|------------|-----------------|----------|
| 0013 | NEC        | PX 33 M 3 G     | 33 - 57" |
| 0014 | DIGITAL    | DEVISE DPD 4210 | 33 - 57" |
| 0014 | ORION      | PM 4202         | 33 - 57" |
| 0014 | RELISYS    | PDP 4202        | 33 - 57" |
| 0014 | VISION     | PM 4204         | 33 - 57" |
| 0015 | MITSUBISHI | XP 4015 E       | 33 - 57" |
| 0016 | LG         | PD 40 X 2       | 33 - 57" |
| 0017 | JVC        | GDV 4200 PZW    | 33 - 57" |
| 0017 | JVC        | GDV 4210 PCE    | 33 - 57" |
| 0018 | HITACHI    | CMP 307 XE      | 33 - 57" |
| 0019 | HITACHI    | CMP 402 HDE     | 33 - 57" |
| 0019 | HITACHI    | CMP 4120 HDE    | 33 - 57" |
| 0022 | CONRAC     | 4142 WP         | 33 - 57" |
| 0023 | EIKI       | PV 4210 AT      | 33 - 57" |
| 0024 | CONRAC     | 4042 42 WP      | 33 - 57" |
| 0025 | CLARITY    | SN 4210 P       | 33 - 57" |
| 0026 | NEC        | 4200 W          | 33 - 57" |
| 0026 | NEC        | 4210 W          | 33 - 57" |
| 0026 | NEC        | PX 42 VP 1 G    | 33 - 57" |
| 0026 | NEC        | PX 42 M 2 G     | 33 - 57" |
| 0026 | NEC        | PX 42 VM 1      | 33 - 57" |
| 0026 | NEC        | 4205            | 33 - 57" |
| 0026 | NEC        | 42 PD 2         | 33 - 57" |
| 0026 | NEC        | PX 42 VM 2 G    | 33 - 57" |
| 0026 | NEC        | 42 MP 1         | 33 - 57" |
| 0026 | NEC        | PX 42 VP 4 G    | 33 - 57" |
| 0026 | NEC        | PX 42 VP 5 HG   | 33 - 57" |
| 0026 | NEC        | PX 42 XM 4 G    | 33 - 57" |
| 0026 | NEC        | PX 42 XM 2 G    | 33 - 57" |
| 0026 | NEC        | 42 XR 3         | 33 - 57" |
| 0026 | NEC        | PX 42 VM 5      | 33 - 57" |
| 0026 | NEC        | 42 MP 3         | 33 - 57" |
| 0026 | NEC        | 42 MP 2         | 33 - 57" |
| 0026 | NEC        | PX 42 XM 3 G    | 33 - 57" |
| 0026 | SANYO      | PDP 42 WE 1     | 33 - 57" |
| 0026 | SANYO      | PDP 42 WE 2     | 33 - 57" |
| 0026 | THOMSON    | 42 WS 90 E      | 33 - 57" |
| 0026 | NEC        | 5000 W          | 33 - 57" |
| 0026 | NEC        | 50 PD 1         | 33 - 57" |
| 0026 | NEC        | 50 PD 2         | 33 - 57" |
| 0026 | NEC        | PX 50 VP 1 G    | 33 - 57" |
| 0026 | NEC        | PX 50 XM 3 G    | 33 - 57" |

|      |            |               |             |
|------|------------|---------------|-------------|
| 0026 | NEC        | 50 MP 2       | 33 - 57"    |
| 0026 | THOMSON    | 50 WS 94 E    | 33 - 57"    |
| 0026 | JVC        | GMX 50 E      | 33 - 57"    |
| 0027 | PIONEER    | PDP 434 PE    | 33 - 57"    |
| 0027 | PIONEER    | PDP 433 PE    | 33 - 57"    |
| 0027 | PIONEER    | PDP 433 MXE   | 33 - 57"    |
| 0027 | PIONEER    | PDP 43 MXE 1  | 33 - 57"    |
| 0027 | PIONEER    | PDP 436 PE    | 33 - 57"    |
| 0027 | PIONEER    | PDP 42 MXE 10 | 33 - 57"    |
| 0027 | PIONEER    | PDP 427 XD    | 33 - 57"    |
| 0027 | PIONEER    | 4280 XD       | 33 - 57"    |
| 0027 | PIONEER    | PDP 42 MXE 20 | 33 - 57"    |
| 0027 | PIONEER    | PDP 4270 XD   | 33 - 57"    |
| 0027 | PIONEER    | PDP 428 XD    | 33 - 57"    |
| 0027 | PIONEER    | PDP 435       | 33 - 57"    |
| 0027 | SHARP      | PZ 43 HV 2 E  | 33 - 57"    |
| 0027 | PIONEER    | PDP 501 MX    | 33 - 57"    |
| 0027 | PIONEER    | PDP 502 MX    | 33 - 57"    |
| 0027 | PIONEER    | 50 MXE 1      | 33 - 57"    |
| 0027 | PIONEER    | PDP 506 PE    | 33 - 57"    |
| 0027 | PIONEER    | PDP 50 MXE 11 | 33 - 57"    |
| 0027 | PIONEER    | PDP 50 MXE 20 | 33 - 57"    |
| 0027 | PIONEER    | PDP 508 D     | 33 - 57"    |
| 0027 | PIONEER    | PDP 503 XD    | 33 - 57"    |
| 0027 | PIONEER    | PDP 504 XD    | 33 - 57"    |
| 0027 | PIONEER    | PDP 506 XDE   | 33 - 57"    |
| 0027 | PIONEER    | PDP 50 MXE 10 | 33 - 57"    |
| 0027 | PIONEER    | PDP 507 XDE   | 33 - 57"    |
| 0027 | PIONEER    | PDP 508 XDE   | 33 - 57"    |
| 0027 | SHARP      | PZ 50 HV 2 E  | 33 - 57"    |
| 0028 | PIONEER    | 40 PDPV 401 E | 33 - 57"    |
| 0028 | PIONEER    | PDP 401 E     | 33 - 57"    |
| 0028 | PIONEER    | 40 PDPV 402 E | 33 - 57"    |
| 0029 | SONY       | 42 PFM 500    | 33 - 57"    |
| 0030 | SONY       | FWD 40 LX 1   | 33 - 57"    |
| 0030 | SONY       | FWD 40 LX 2   | 33 - 57"    |
| 0030 | SONY       | 40 LX 2 FBC 2 | 33 - 57"    |
| 0030 | SONY       | PFM 42 B 1 E  | 33 - 57"    |
| 0030 | SONY       | PFM 42 V 1 E  | 33 - 57"    |
| 0030 | SONY       | PFM 42 V 1 N  | 33 - 57"    |
| 0030 | SONY       | FWD 42 PV 1   | 33 - 57"    |
| 0030 | SONY       | FWD 42 LX 1   | 33 - 57"    |
| 0030 | SONY       | PFM 42 X 1 N  | 33 - 57"    |
| 0030 | SONY       | FWD 42 PX 2   | 33 - 57"    |
| 0031 | EIZO       | P 5071        | 33 - 57"    |
| 0032 | SMARTBOARD | SB 580        | Interactive |

|      |              |               |          |
|------|--------------|---------------|----------|
| 0034 | DAEWOO       | DSP 4210 GM   | 33 - 57" |
| 0034 | DAEWOO       | DT 4280 NH    | 33 - 57" |
| 0035 | DELPHI       | DIRECT 42     | 33 - 57" |
| 0037 | FLATDISPLAYS | MPD 5020 A    | 33 - 57" |
| 0045 | LG           | MZ 42 PZ 10   | 33 - 57" |
| 0045 | LG           | MZ 42 PZ 44   | 33 - 57" |
| 0045 | LG           | MZ 42 PM 13   | 33 - 57" |
| 0045 | LG           | 42 PM 3 MVA   | 33 - 57" |
| 0045 | LG           | 42 PC 1 D     | 33 - 57" |
| 0045 | LG           | 42 PZ 17      | 33 - 57" |
| 0045 | OTRON        | EPM 420 A     | 33 - 57" |
| 0045 | TATUNG       | TPD 4201 S    | 33 - 57" |
| 0045 | THOMSON      | 42 WM 02 L    | 33 - 57" |
| 0045 | THOMSON      | 42 WM 03 L    | 33 - 57" |
| 0045 | THOMSON      | 42 PB 040 B 5 | 33 - 57" |
| 0045 | VISION       | GPTM 4200 HA  | 33 - 57" |
| 0045 | VISION       | DCM 42 WBP    | 33 - 57" |
| 0045 | VISION       | DCM 42 WT     | 33 - 57" |
| 0045 | VISION       | DCM 42 HBL    | 33 - 57" |
| 0045 | LG           | RZ 42 PX 11   | 33 - 57" |
| 0045 | LG           | RZ 42 PY 10 X | 33 - 57" |
| 0045 | LG           | 42 PX 5 D     | 33 - 57" |
| 0045 | LG           | 42 PX 3 RV    | 33 - 57" |
| 0045 | TATUNG       | TPT 4202 S    | 33 - 57" |
| 0046 | LG           | MZ 40 PA 10   | 33 - 57" |
| 0047 | PHILIPS      | 32 FD 9944    | 33 - 57" |
| 0047 | PHILIPS      | 32 FD 9964    | 33 - 57" |
| 0047 | PHILIPS      | 32 PF 9965    | 33 - 57" |
| 0050 | HITACHI      | CL 32 PD 2100 | 33 - 57" |
| 0050 | HITACHI      | CL 32 PD 3000 | 33 - 57" |
| 0051 | HITACHI      | C 37 PD 2100  | 33 - 57" |
| 0052 | HITACHI      | CMP 4121 HDE  | 33 - 57" |
| 0052 | HITACHI      | CL 42 PD 2100 | 33 - 57" |
| 0052 | HITACHI      | 42 PMA 400    | 33 - 57" |
| 0052 | HITACHI      | CMP 4202 W    | 33 - 57" |
| 0053 | SONY         | FWD 32 LX 1   | 33 - 57" |
| 0053 | SONY         | FWD 32 LX 2 F | 33 - 57" |
| 0053 | SONY         | PFM 32 C 1 E  | 33 - 57" |
| 0055 | UNIVERSAL    | MVP 3202      | 33 - 57" |
| 0059 | THOMSON      | 32 PW 95 E    | 33 - 57" |
| 0059 | THOMSON      | 32 WS 95 E    | 33 - 57" |
| 0059 | SANYO        | PDP 32 HIE    | 33 - 57" |



|      |                 |                 |          |
|------|-----------------|-----------------|----------|
| 0060 | SANYO           | PDP 42 H 1 EV   | 33 - 57" |
| 0061 | SONY            | KZ 42 TS 1 E    | 33 - 57" |
| 0061 | SONY            | KE 42 TS 2 E    | 33 - 57" |
| 0062 | SONY            | KZ 32 TS 1 E    | 33 - 57" |
| 0062 | SONY            | KE 32 TS 2 E    | 33 - 57" |
| 0063 | EIKI            | PLD 32 UE       | 33 - 57" |
| 0064 | SONY            | PFM 50 C 1 E    | 33 - 57" |
| 0064 | SONY            | FWD 50 PX 1 NS  | 33 - 57" |
| 0064 | SONY            | FWD 50 PX 2     | 33 - 57" |
| 0064 | SONY            | FWD 50 X 1      | 33 - 57" |
| 0064 | SONY            | FWD 50 PX 3     | 33 - 57" |
| 0065 | BENQ            | 46 W 1          | 33 - 57" |
| 0065 | CHUNGWA         | CLD PD 4610     | 33 - 57" |
| 0065 | CHUNGWA         | PD 4610         | 33 - 57" |
| 0065 | FLATDISPLAYS    | FD 46 PW 1      | 33 - 57" |
| 0065 | PHILIPS         | BDS 4611        | 33 - 57" |
| 0065 | PHILIPS         | BDS 4621        | 33 - 57" |
| 0065 | CHUNGWA         | PD 46 WV 1      | 33 - 57" |
| 0065 | CHUNGWA         | CPT PD 46 WV 1  | 33 - 57" |
| 0066 | NAKAMICHI       | PDP 42          | 33 - 57" |
| 0067 | FUJITSU SIEMENS | MYRICA P 422 H  | 33 - 57" |
| 0067 | FUJITSU SIEMENS | MYRICA P 422    | 33 - 57" |
| 0067 | FUJITSU SIEMENS | MYRICA V 401    | 33 - 57" |
| 0067 | MITAC           | PDP 42 H        | 33 - 57" |
| 0067 | RELISYS         | RP 4205         | 33 - 57" |
| 0067 | SAMSUNG         | PS 42 P 2 S     | 33 - 57" |
| 0067 | SAMSUNG         | PPM 42 S 3      | 33 - 57" |
| 0067 | TINY            | 42              | 33 - 57" |
| 0067 | WHARFEDALE      | W 42 S 40 PE    | 33 - 57" |
| 0067 | FUJITSU SIEMENS | P 502           | 33 - 57" |
| 0067 | SAMSUNG         | PPM 50 H 3      | 33 - 57" |
| 0067 | HYUNDAI         | HQP 421 SR      | 33 - 57" |
| 0067 | HYUNDAI         | PD 421          | 33 - 57" |
| 0067 | TINY            | HC PLASMA TV TY | 33 - 57" |
| 0068 | HANTAREX        | PD 42 SRL       | 33 - 57" |
| 0068 | HANTAREX        | PD 40 SRL       | 33 - 57" |
| 0069 | HITACHI         | CMP 5000 WXE    | 33 - 57" |
| 0070 | CONRAC          | 4042 42         | 33 - 57" |
| 0071 | PHILIPS         | 42 FD 9944      | 33 - 57" |
| 0071 | PHILIPS         | 42 PF 9964      | 33 - 57" |
| 0071 | PHILIPS         | 420 P 30        | 33 - 57" |
| 0071 | PHILIPS         | 420 P 20        | 33 - 57" |

|      |            |                 |          |
|------|------------|-----------------|----------|
| 0071 | PHILIPS    | 42 FD 9945      | 33 - 57" |
| 0071 | PHILIPS    | BDH 4211        | 33 - 57" |
| 0072 | LG         | MZ 50 PZ 43     | 33 - 57" |
| 0072 | LG         | 50 PXD 4        | 33 - 57" |
| 0072 | LG         | 50 PM 1 MA      | 33 - 57" |
| 0072 | LG         | RZ 50 PY 10     | 33 - 57" |
| 0072 | LG         | 50 PC 1 D       | 33 - 57" |
| 0073 | MITAC      | HP 5000         | 33 - 57" |
| 0073 | RELISYS    | RP 5000 S       | 33 - 57" |
| 0073 | SAMSUNG    | PS 50 P 2 HT    | 33 - 57" |
| 0074 | SHARP      | LC 37 HV 4 E    | 33 - 57" |
| 0074 | SHARP      | LCM 3700        | 33 - 57" |
| 0075 | FUJITSU    | P 42 HCA 11 EH  | 33 - 57" |
| 0075 | FUJITSU    | P 42 HHA 10 EF  | 33 - 57" |
| 0075 | FUJITSU    | P 42 VCA 11 EH  | 33 - 57" |
| 0075 | FUJITSU    | P 42 VCA 21 EH  | 33 - 57" |
| 0075 | FUJITSU    | P 42 VHA 20 ES  | 33 - 57" |
| 0075 | FUJITSU    | P 42 VCA 30 EH  | 33 - 57" |
| 0075 | FUJITSU    | P 42 HHA 3 ES   | 33 - 57" |
| 0075 | FUJITSU    | P 42 HHA 30 ES  | 33 - 57" |
| 0075 | FUJITSU    | P 42 VHA 51 ES  | 33 - 57" |
| 0075 | FUJITSU    | P 42 HCA 40     | 33 - 57" |
| 0075 | FUJITSU    | P 42 HHA 40     | 33 - 57" |
| 0075 | FUJITSU    | P 42 XHA 58     | 33 - 57" |
| 0075 | FUJITSU    | P 42 HCA 51     | 33 - 57" |
| 0075 | FUJITSU    | P 42 HCA 30 EH  | 33 - 57" |
| 0075 | FUJITSU    | P 42 VHA 40 ES  | 33 - 57" |
| 0076 | VUTRIX     | 30              | 33 - 57" |
| 0077 | SAMSUNG    | LW 29 A 13 W    | 33 - 57" |
| 0078 | JVC        | GMP 420 PCE     | 33 - 57" |
| 0078 | JVC        | GMP 421 PCE     | 33 - 57" |
| 0078 | JVC        | GMV 42 PCEB     | 33 - 57" |
| 0079 | SAMSUNG    | LW 40 A 13 W    | 33 - 57" |
| 0080 | RELISYS    | RLT 3000        | 15 - 32" |
| 0080 | LG         | RZ 30 LZ 13     | 33 - 57" |
| 0082 | MITSUBISHI | LDT 321 U       | 33 - 57" |
| 0082 | MITSUBISHI | MDT 321 S       | 33 - 57" |
| 0082 | MITSUBISHI | LDT 321 V       | 33 - 57" |
| 0082 | MITSUBISHI | LDT 323         | 33 - 57" |
| 0082 | IYAMA      | PROLITE L 320 W | 33 - 57" |
| 0082 | MITSUBISHI | LDT 371 V       | 33 - 57" |
| 0082 | MITSUBISHI | LDT 322         | 33 - 57" |
| 0082 | MITSUBISHI | L 464 G 7       | 33 - 57" |



|      |              |                 |          |
|------|--------------|-----------------|----------|
| 0100 | PANASONIC    | TH 37 PX 60     | 33 - 57" |
| 0100 | PANASONIC    | TH 42 PA 20     | 33 - 57" |
| 0100 | PANASONIC    | TH 42 PX 60 B   | 33 - 57" |
| 0100 | PANASONIC    | TH 42 PV 60     | 33 - 57" |
| 0100 | PANASONIC    | TH 42 PV 70     | 33 - 57" |
| 0100 | PANASONIC    | TH 42 PV 80     | 33 - 57" |
| 0100 | FUJITSU      | P 50 XTA 40 ES  | 33 - 57" |
| 0100 | FUJITSU      | P 50 XTS 51     | 33 - 57" |
| 0100 | FUJITSU      | P 50 XTA 51     | 33 - 57" |
| 0100 | PANASONIC    | TH 50 PX 60 B   | 33 - 57" |
| 0100 | PANASONIC    | TH 50 PZ 70     | 33 - 57" |
| 0100 | PANASONIC    | TH 50 PX 70     | 33 - 57" |
| 0100 | FUJITSU      | P 50 XCA 30 EH  | 33 - 57" |
| 0100 | FUJITSU      | 50 XHA 30       | 33 - 57" |
| 0100 | FUJITSU      | P 50 XHA 40     | 33 - 57" |
| 0100 | FUJITSU      | P 50 XHA 10     | 33 - 57" |
| 0100 | FUJITSU      | P 50 XCA 40     | 33 - 57" |
| 0100 | FUJITSU      | P 50 XCA 51     | 33 - 57" |
| 0101 | JVC          | LT 32 C 31 BJE  | 15 - 32" |
| 0101 | JVC          | 26 C 31 BJE     | 15 - 32" |
| 0101 | JVC          | LT 32 C 50 BJ   | 15 - 32" |
| 0101 | JVC          | LT 32 D 50      | 15 - 32" |
| 0102 | DIBOSS       | LT 32 HLP       | 15 - 32" |
| 0102 | MANHATTAN    | LT 30 FLP       | 15 - 32" |
| 0102 | PACKARD BELL | 300 SW          | 15 - 32" |
| 0104 | HYUNDAI      | DPD 4240        | 33 - 57" |
| 0104 | HYUNDAI      | HPT 4250        | 33 - 57" |
| 0104 | HYUNDAI      | HPT 4240        | 33 - 57" |
| 0105 | THOMSON      | 27 LCD B 03 B   | 15 - 32" |
| 0105 | THOMSON      | 30 LCD B 03     | 15 - 32" |
| 0105 | THOMSON      | 32 LB 120 S 4 U | 15 - 32" |
| 0108 | HITACHI      | 42 PD 5300      | 33 - 57" |
| 0108 | HITACHI      | CMP 4214 E      | 33 - 57" |
| 0108 | HITACHI      | 42 PMA 500      | 33 - 57" |
| 0108 | HITACHI      | 42 PD 5200      | 33 - 57" |
| 0108 | HITACHI      | 42 PD 5000      | 33 - 57" |
| 0108 | HITACHI      | 42 PD 5100      | 33 - 57" |
| 0108 | HITACHI      | 42 PD 4200      | 33 - 57" |
| 0108 | HITACHI      | 42 PD 7200      | 33 - 57" |
| 0109 | HANTAREX     | FPD TFT 40      | 33 - 57" |
| 0110 | SONY         | 50 MR 1         | 33 - 57" |
| 0111 | SANYO        | LMU TK 40 CK 2  | 33 - 57" |
| 0111 | CHRISTIE     | FP 40           | 33 - 57" |
| 0111 | CHRISTIE     | 38 FP 0001 01   | 33 - 57" |
| 0111 | CHRISTIE     | 38 FP 0001 02   | 33 - 57" |

|      |           |                 |          |
|------|-----------|-----------------|----------|
| 0112 | SAMSUNG   | 403 T           | 33 - 57" |
| 0113 | PHILIPS   | 42 PF 9945 / 12 | 33 - 57" |
| 0114 | HITACHI   | 32 PD 5200      | 15 - 32" |
| 0114 | HITACHI   | 32 PD 5100 E    | 15 - 32" |
| 0114 | HITACHI   | 32 PD 5300 E    | 15 - 32" |
| 0114 | HITACHI   | 32 PD 5000      | 15 - 32" |
| 0116 | TOSHIBA   | 32 WL 36 P      | 15 - 32" |
| 0117 | PHILIPS   | BDH 5011        | 33 - 57" |
| 0118 | HANTAREX  | PD 42 XPTVZ     | 33 - 57" |
| 0119 | BARCO     | SOLARIS LC 40   | 33 - 57" |
| 0119 | BARCO     | LCD 40          | 33 - 57" |
| 0120 | VISION    | LT 30 FEP       | 15 - 32" |
| 0123 | SAMSUNG   | 241 MP          | 15 - 32" |
| 0125 | NEC       | LCD 3000        | 15 - 32" |
| 0128 | SAMSUNG   | LW 40 A 23 W    | 33 - 57" |
| 0129 | PANASONIC | TH 50 PZ 81     | 33 - 57" |
| 0129 | PANASONIC | TH 37 PE 30     | 33 - 57" |
| 0129 | PANASONIC | TH 42 PE 30     | 33 - 57" |
| 0129 | PANASONIC | TH 50 PV 30     | 33 - 57" |
| 0129 | PANASONIC | TH 42 PV 500 B  | 33 - 57" |
| 0129 | PANASONIC | TH 50 PX 600    | 33 - 57" |
| 0129 | PANASONIC | TH 42 PX 600 B  | 33 - 57" |
| 0129 | PANASONIC | TH 50 PZ 700    | 33 - 57" |
| 0129 | PANASONIC | 50 PX 7         | 33 - 57" |
| 0129 | PANASONIC | TH 42 PZ 85     | 33 - 57" |
| 0129 | PANASONIC | TH 37 PV 500    | 33 - 57" |
| 0129 | PANASONIC | TH 37 PV 600    | 33 - 57" |
| 0129 | PANASONIC | TH 37 PX 600    | 33 - 57" |
| 0129 | PANASONIC | TH 37 PA 50     | 33 - 57" |
| 0129 | PANASONIC | TH 50 PV 600    | 33 - 57" |
| 0131 | PANASONIC | TX 26 LXD 1     | 15 - 32" |
| 0131 | PANASONIC | TX 32 LXD 1     | 15 - 32" |
| 0131 | PANASONIC | TX 32 LXD 50    | 15 - 32" |
| 0131 | PANASONIC | TX 26 LXD 50    | 15 - 32" |
| 0132 | HYUNDAI   | HPT 5040        | 33 - 57" |
| 0133 | HITACHI   | 55 PMA 550      | 33 - 57" |
| 0134 | JVC       | VM 42 WX 84     | 33 - 57" |
| 0134 | JVC       | PD 35 B 50 BU   | 33 - 57" |

|      |          |                |          |
|------|----------|----------------|----------|
| 0134 | JVC      | PD 42 DX 6 BJ  | 33 - 57" |
| 0134 | JVC      | PD 42 B 50 BU  | 33 - 57" |
| 0134 | JVC      | VM 42 V 31 BUE | 33 - 57" |
| 0135 | JVC      | VM 42 D 30 ES  | 33 - 57" |
| 0136 | TECHWOOD | TWP 4210       | 33 - 57" |
| 0137 | CLARITY  | SN 4035 WX     | 33 - 57" |
| 0138 | VISION   | 30 V 2         | 15 - 32" |
| 0139 | HISENSE  | PDP 4212 EU    | 33 - 57" |
| 0139 | RELISYS  | RP 4210 S      | 33 - 57" |
| 0139 | RELISYS  | RP 5010 S      | 33 - 57" |
| 0140 | THOMSON  | 50 WP 03 P     | 33 - 57" |
| 0141 | LG       | L 3000 H       | 15 - 32" |
| 0142 | RELISYS  | RP 4206        | 33 - 57" |
| 0143 | SAMSUNG  | PS 42 D 4 S    | 33 - 57" |
| 0143 | SAMSUNG  | PS 42 V 4 S    | 33 - 57" |
| 0143 | SAMSUNG  | PS 50 P 4 H 1  | 33 - 57" |
| 0144 | VISION   | OP 50 TI       | 33 - 57" |
| 0145 | SONY     | KDL L 32 MRX 1 | 15 - 32" |
| 0145 | SONY     | KLV L 32 MRX 1 | 15 - 32" |
| 0145 | SONY     | LDM 3210       | 15 - 32" |
| 0146 | A+K      | EPM 5000       | 33 - 57" |
| 0147 | SONY     | LMD 320 W      | 15 - 32" |
| 0147 | SONY     | LMD 322 W      | 15 - 32" |
| 0147 | SONY     | LMD 3250 MV    | 15 - 32" |
| 0149 | HITACHI  | 28 LD 5200 E   | 15 - 32" |
| 0150 | PHILIPS  | 50 FD 9935     | 33 - 57" |
| 0151 | TOSHIBA  | 42 WP 36 P     | 33 - 57" |
| 0152 | LG       | RZ 37 LZ 30    | 33 - 57" |
| 0153 | SONY     | KLV L 32 M 1   | 15 - 32" |
| 0154 | SONY     | KDEP 42 XS 1   | 33 - 57" |
| 0154 | SONY     | KDEP 37 XS 1   | 33 - 57" |
| 0154 | SONY     | KEP 42 M 1     | 33 - 57" |
| 0155 | GOODMANS | GTV 50 P       | 33 - 57" |

|      |           |                 |          |
|------|-----------|-----------------|----------|
| 0155 | SAMSUNG   | PS 50 P 3 H     | 33 - 57" |
| 0156 | ARCHER    | T 42 V 2 T      | 33 - 57" |
| 0156 | NEOVIA    | SL 42 VK 10     | 33 - 57" |
| 0156 | RELISYS   | RP 4207         | 33 - 57" |
| 0157 | JVC       | LT 32 DX 7      | 33 - 57" |
| 0157 | PANASONIC | TXL 37 G 20 B   | 33 - 57" |
| 0157 | RELISYS   | RLT 32 AB 20 RU | 33 - 57" |
| 0157 | RELISYS   | RLT 32 AB 50 RU | 33 - 57" |
| 0157 | SHARP     | LC 32 GA 3 E    | 33 - 57" |
| 0157 | SHARP     | LC 32 GA 5 E    | 33 - 57" |
| 0157 | SHARP     | LC 32 P 55 E    | 33 - 57" |
| 0157 | SHARP     | LC 37 GA 8 E    | 33 - 57" |
| 0157 | SHARP     | LC 32 GA 8 E    | 33 - 57" |
| 0157 | SHARP     | LC 32 AD 5 E    | 33 - 57" |
| 0157 | SHARP     | LC 32 WD 1 E    | 33 - 57" |
| 0157 | SHARP     | LC 32 GA 9 E    | 33 - 57" |
| 0157 | SHARP     | LC 32 P 50 E    | 33 - 57" |
| 0157 | SHARP     | LC 37 GA 6      | 33 - 57" |
| 0157 | SHARP     | LC 37 GD 1 E    | 33 - 57" |
| 0157 | SHARP     | LC 32 GD 9 E    | 33 - 57" |
| 0157 | SHARP     | LC 32 SA 1      | 33 - 57" |
| 0157 | SHARP     | LC 32 SD 1 E    | 33 - 57" |
| 0157 | SHARP     | LC 37 GE 1      | 33 - 57" |
| 0157 | SONY      | KDL 32 V 4000   | 33 - 57" |
| 0157 | TOSHIBA   | 32 WLT 58       | 33 - 57" |
| 0157 | TOSHIBA   | 32 WLT 68       | 33 - 57" |
| 0157 | TOSHIBA   | 32 WLT 66       | 33 - 57" |
| 0157 | TOSHIBA   | 32 C 3030       | 33 - 57" |
| 0157 | TOSHIBA   | 32 C 3031       | 33 - 57" |
| 0157 | TOSHIBA   | 37 WLT 66       | 33 - 57" |
| 0157 | TOSHIBA   | 37 WL 66 P      | 33 - 57" |
| 0157 | TOSHIBA   | 32 C 3035       | 33 - 57" |
| 0157 | TOSHIBA   | 39 L 4353       | 33 - 57" |
| 0157 | TOSHIBA   | 39 L 2333       | 33 - 57" |
| 0157 | SHARP     | LC 46 XL 1 E    | 33 - 57" |
| 0157 | SHARP     | LC 46 XD 1 E    | 33 - 57" |
| 0157 | SHARP     | LC 46 LD 266 K  | 33 - 57" |
| 0157 | SHARP     | LC 42 LE 761 K  | 33 - 57" |
| 0157 | SHARP     | LC 42 LD 266 K  | 33 - 57" |
| 0157 | TOSHIBA   | 42 WLT 58       | 33 - 57" |
| 0157 | TOSHIBA   | 42 A 3030       | 33 - 57" |
| 0157 | TOSHIBA   | 42 C 3035       | 33 - 57" |
| 0157 | TOSHIBA   | 42 WLT 66       | 33 - 57" |
| 0157 | TOSHIBA   | 42 WLT 68       | 33 - 57" |
| 0157 | SHARP     | LC 42 SD 1 E    | 33 - 57" |
| 0157 | SHARP     | LC 42 XD 1 E    | 33 - 57" |
| 0157 | SHARP     | LC 37 GD 8      | 33 - 57" |
| 0157 | SHARP     | LC 37 GD 7      | 33 - 57" |
| 0157 | SHARP     | LC 37 P 50 E    | 33 - 57" |
| 0157 | SHARP     | LC 37 P 55 E    | 33 - 57" |
| 0157 | SHARP     | LC 42 AD 5 E    | 33 - 57" |

|      |           |                  |          |
|------|-----------|------------------|----------|
| 0157 | TOSHIBA   | 37 WLT 68        | 33 - 57" |
| 0159 | PHILIPS   | 42 HF 9442       | 33 - 57" |
| 0159 | PHILIPS   | 42 PF 3320       | 33 - 57" |
| 0159 | PHILIPS   | BDS 4231 R       | 33 - 57" |
| 0159 | PHILIPS   | 42 PF 9946       | 33 - 57" |
| 0159 | PHILIPS   | 107 FP 4         | 33 - 57" |
| 0160 | PHILIPS   | 37 PF 9946       | 33 - 57" |
| 0161 | PHILIPS   | 32 PF 9956       | 33 - 57" |
| 0161 | PHILIPS   | 32 PF 9976       | 33 - 57" |
| 0162 | CONRAC    | 6040 PD GEB 7    | 33 - 57" |
| 0162 | CONRAC    | 6040 PD 002 010  | 33 - 57" |
| 0164 | PHILIPS   | 30 PF 9946 12    | 33 - 57" |
| 0164 | PHILIPS   | 30 HF 9442       | 33 - 57" |
| 0166 | SAHARA    | P 42 CDN         | 33 - 57" |
| 0168 | SAMSUNG   | LW 32 A 33 W     | 33 - 57" |
| 0169 | PHILIPS   | 32 PF 9986       | 33 - 57" |
| 0170 | SAHARA    | LT 30 AAN        | 33 - 57" |
| 0170 | VIEWSONIC | N 3000 W         | 33 - 57" |
| 0171 | TATUNG    | TLT 3001 S       | 33 - 57" |
| 0172 | JVC       | LT 30 E 45 SJ    | 33 - 57" |
| 0173 | TOSHIBA   | 42 WP 46 P       | 33 - 57" |
| 0174 | LG        | L 4200 A         | 33 - 57" |
| 0174 | LG        | FLATRON M 4201 C | 33 - 57" |
| 0174 | LG        | L 4200 C         | 33 - 57" |
| 0175 | FUJITSU   | P 55 XHA 30 ES   | 33 - 57" |
| 0175 | FUJITSU   | P 55 XTS 51 RS   | 33 - 57" |
| 0175 | FUJITSU   | P 55 XHA 55      | 33 - 57" |
| 0176 | IYYAMA    | PROLITE L 400 W  | 33 - 57" |
| 0177 | GOODMANS  | LD 3201          | 33 - 57" |
| 0177 | SAMSUNG   | 320 P            | 33 - 57" |
| 0179 | HYUNDAI   | HPTN 4200 S      | 33 - 57" |
| 0179 | HYUNDAI   | HPTD 4202 S      | 33 - 57" |
| 0179 | PHILIPS   | BDS 4241 V / 00  | 33 - 57" |
| 0179 | PHILIPS   | BDH 4241         | 33 - 57" |
| 0179 | RELISYS   | RP 42 AB 50      | 33 - 57" |
| 0179 | RELISYS   | RP 42 AB 20      | 33 - 57" |



|      |           |                  |          |
|------|-----------|------------------|----------|
| 0179 | RELISYS   | RP 50 AB 50      | 33 - 57" |
| 0180 | RELISYS   | RP 42 DV 30      | 33 - 57" |
| 0180 | HITACHI   | 42 PMA 225 EZ    | 33 - 57" |
| 0180 | HITACHI   | 42 PD 3200       | 33 - 57" |
| 0180 | HITACHI   | 42 PD 6600       | 33 - 57" |
| 0180 | HITACHI   | 42 PD 6 A 10     | 33 - 57" |
| 0180 | RELISYS   | RP 42 AV 20      | 33 - 57" |
| 0181 | SANYO     | CE 30 LC 3 B     | 33 - 57" |
| 0181 | SANYO     | CE 30 LD 3 B     | 33 - 57" |
| 0182 | VISION    | PTS 4241         | 33 - 57" |
| 0182 | VISION    | PM 4241          | 33 - 57" |
| 0183 | PHILIPS   | 42 PF 9966       | 33 - 57" |
| 0183 | PHILIPS   | 42 PF 9956       | 33 - 57" |
| 0184 | RELISYS   | RLT 3200         | 33 - 57" |
| 0185 | PANASONIC | TH 37 PE 50      | 33 - 57" |
| 0185 | PANASONIC | TH 37 PG 9 B     | 33 - 57" |
| 0185 | PANASONIC | TH 42 PA 50      | 33 - 57" |
| 0185 | PANASONIC | TH 42 PG 9 B     | 33 - 57" |
| 0185 | PANASONIC | TH 42 PX 80      | 33 - 57" |
| 0185 | PANASONIC | TH 50 PX 706     | 33 - 57" |
| 0185 | PANASONIC | TH 50 PX 70 BA   | 33 - 57" |
| 0186 | SANYO     | CE 27 LC 3 B     | 33 - 57" |
| 0187 | GDS       | G 320            | 33 - 57" |
| 0187 | GDS       | G 370            | 33 - 57" |
| 0188 | CONRAC    | 6030 PD GEB 7    | 33 - 57" |
| 0189 | STARMEDIA | LCDTV 32         | 33 - 57" |
| 0189 | VIEWSONIC | N 3200 W         | 33 - 57" |
| 0190 | PANASONIC | TH 32 LHD 7 EK   | 33 - 57" |
| 0190 | PANASONIC | TH 32 LHD 7 ES   | 33 - 57" |
| 0191 | TATUNG    | P 50 BSAT        | 33 - 57" |
| 0193 | HYUNDAI   | HPTD 4201 S      | 33 - 57" |
| 0194 | INFOCUS   | TD 40            | 33 - 57" |
| 0194 | RELISYS   | RLT 4000         | 33 - 57" |
| 0194 | RELISYS   | RLT 40 AH 20     | 33 - 57" |
| 0194 | RELISYS   | RYT 42 AH 20     | 33 - 57" |
| 0195 | RELISYS   | RLT 2720 RU      | 33 - 57" |
| 0196 | CISCO     | CCD 100 PRO 40 N | 33 - 57" |

|      |         |                 |          |
|------|---------|-----------------|----------|
| 0197 | THOMSON | 42 PB 020       | 33 - 57" |
| 0198 | HITACHI | 32 LD 7200      | 33 - 57" |
| 0199 | DMTECH  | DML 4132 WD     | 33 - 57" |
| 0199 | DMTECH  | LM 32 DT        | 33 - 57" |
| 0200 | SAMSUNG | SM 320 MXN      | 33 - 57" |
| 0200 | SAMSUNG | 320 TSN         | 33 - 57" |
| 0200 | SAMSUNG | 320 MX 3        | 33 - 57" |
| 0200 | SAMSUNG | 320 MXN 3       | 33 - 57" |
| 0200 | SAMSUNG | 320 BX          | 33 - 57" |
| 0200 | SAMSUNG | 320 TSN 3       | 33 - 57" |
| 0200 | SAMSUNG | UA 32 EH 4005   | 33 - 57" |
| 0200 | SAMSUNG | UA 32 EH 4003   | 33 - 57" |
| 0200 | SAMSUNG | UA 32 H 4500    | 33 - 57" |
| 0200 | SAMSUNG | LE 32 R 74 BD   | 33 - 57" |
| 0200 | SAMSUNG | LE 32 R 41 BX   | 33 - 57" |
| 0200 | SAMSUNG | LE 32 M 61      | 33 - 57" |
| 0200 | SAMSUNG | LE 32 S 81      | 33 - 57" |
| 0200 | SAMSUNG | LE 32 S 86      | 33 - 57" |
| 0200 | SAMSUNG | 320 MX 2        | 33 - 57" |
| 0200 | SAMSUNG | LE 32 T 51 B    | 33 - 57" |
| 0200 | SAMSUNG | LE 32 R 51      | 33 - 57" |
| 0200 | SAMSUNG | UA 40 EH 5005   | 33 - 57" |
| 0200 | SAMSUNG | UA 40 EH 5000   | 33 - 57" |
| 0200 | SAMSUNG | LE 40 R 51 B    | 33 - 57" |
| 0200 | SAMSUNG | LE 40 R 72      | 33 - 57" |
| 0200 | BEKO    | TV 42 FHGER     | 33 - 57" |
| 0200 | SAMSUNG | LE 40 M 61 B    | 33 - 57" |
| 0200 | SAMSUNG | 40 R 74 BDX     | 33 - 57" |
| 0200 | SAMSUNG | LE 40 N 73 BD   | 33 - 57" |
| 0200 | SAMSUNG | LE 40 R 73      | 33 - 57" |
| 0200 | SAMSUNG | LE 37 R 87 BD   | 33 - 57" |
| 0200 | SAMSUNG | LE 37 R 87      | 33 - 57" |
| 0200 | SAMSUNG | LE 37 S 71      | 33 - 57" |
| 0200 | SAMSUNG | LE 37 A 559     | 33 - 57" |
| 0200 | MIRAI   | T 3715 C        | 33 - 57" |
| 0201 | SHARP   | LC 45 GD 1 E    | 33 - 57" |
| 0202 | PHILIPS | 42 PF 9986 12   | 33 - 57" |
| 0202 | PHILIPS | 50 PF 9966 12   | 33 - 57" |
| 0203 | CLARITY | BOBCAT XSN 4045 | 33 - 57" |
| 0204 | SAGEM   | AXIUM HDL 27    | 33 - 57" |
| 0205 | SAMSUNG | PS 42 D 5 S     | 33 - 57" |
| 0205 | SAMSUNG | LE 46 M 87 BD   | 33 - 57" |
| 0205 | SAMSUNG | 400 DXN         | 33 - 57" |
| 0205 | SAMSUNG | 460 DX 3        | 33 - 57" |
| 0205 | SAMSUNG | 550 DX          | 33 - 57" |

|      |         |                   |          |
|------|---------|-------------------|----------|
| 0205 | SAMSUNG | 400 UX 3          | 33 - 57" |
| 0205 | SAMSUNG | 400 UXN 3         | 33 - 57" |
| 0205 | SAMSUNG | 460 UX 3          | 33 - 57" |
| 0205 | SAMSUNG | 460 UXN 3         | 33 - 57" |
| 0205 | SAMSUNG | 460 UT 2          | 33 - 57" |
| 0205 | SAMSUNG | 460 UTN 2         | 33 - 57" |
| 0205 | SAMSUNG | 460 UTB           | 33 - 57" |
| 0205 | SAMSUNG | 460 UTNB          | 33 - 57" |
| 0205 | SAMSUNG | 400 MX 3          | 33 - 57" |
| 0205 | SAMSUNG | 460 MX 3          | 33 - 57" |
| 0205 | SAMSUNG | 460 BX            | 33 - 57" |
| 0205 | SAMSUNG | 400 TS 3          | 33 - 57" |
| 0205 | SAMSUNG | 460 TS 3          | 33 - 57" |
| 0205 | SAMSUNG | UD 46 A           | 33 - 57" |
| 0205 | SAMSUNG | UD 46 C           | 33 - 57" |
| 0205 | SAMSUNG | UD 55 C           | 33 - 57" |
| 0205 | SAMSUNG | UD 46 C-B         | 33 - 57" |
| 0205 | SAMSUNG | SL 46 B           | 33 - 57" |
| 0206 | DIBOSS  | LT 26 HLF         | 33 - 57" |
| 0207 | MEDION  | MD 41527          | 33 - 57" |
| 0208 | FIMI    | 42 LCDTS          | 33 - 57" |
| 0208 | PHILIPS | BDL 4211          | 33 - 57" |
| 0209 | LG      | M 5500 C          | 33 - 57" |
| 0210 | PHILIPS | 37 PF 5520 D      | 33 - 57" |
| 0210 | PHILIPS | 42 PF 5520 D      | 33 - 57" |
| 0210 | PHILIPS | 50 PF 7320        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 5521 D      | 33 - 57" |
| 0210 | PHILIPS | 37 PF 5521 D / 10 | 33 - 57" |
| 0210 | PHILIPS | 42 PF 7320        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 5320        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 9731        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 9831        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 5421        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 7520 D      | 33 - 57" |
| 0211 | VISION  | P 42 SX           | 33 - 57" |
| 0212 | REVOX   | E 542             | 33 - 57" |
| 0213 | HITACHI | 32 LD 6200        | 33 - 57" |
| 0214 | SONY    | KDL 32 P 3020 U   | 33 - 57" |
| 0214 | SONY    | KDLS 32 A 12 U    | 33 - 57" |
| 0214 | SONY    | KDL 32 S 5500     | 33 - 57" |
| 0215 | SAMSUNG | PS 50 A 457       | 33 - 57" |
| 0216 | DELL    | W 3202 MC         | 33 - 57" |

|      |            |                 |             |
|------|------------|-----------------|-------------|
| 0216 | DELL       | W 3706 MC       | 33 - 57"    |
| 0217 | BARCO      | LC 42           | 33 - 57"    |
| 0218 | LG         | 42 LS 3400      | 33 - 57"    |
| 0218 | LG         | 42 LS 341       | 33 - 57"    |
| 0218 | LG         | RZ 32 LZ 55 H   | 33 - 57"    |
| 0218 | LG         | 37 LK 455       | 33 - 57"    |
| 0218 | LG         | 42 LM 3400      | 33 - 57"    |
| 0218 | MIRAI      | DTL 632 E 500   | 33 - 57"    |
| 0218 | SHARP      | 26 D 44         | 33 - 57"    |
| 0218 | SONY       | KDL 26 U 3000   | 33 - 57"    |
| 0218 | SONY       | LMD 2450 MD     | 33 - 57"    |
| 0218 | SONY       | FWD 32 EX 650 P | 33 - 57"    |
| 0218 | SONY       | FWD 32 B 1      | 33 - 57"    |
| 0220 | VIEWSONIC  | N 3260 W        | 33 - 57"    |
| 0220 | VIEWSONIC  | N 3766 W        | 33 - 57"    |
| 0220 | VIEWSONIC  | N 3760 W        | 33 - 57"    |
| 0220 | VIEWSONIC  | N 4060 W        | 33 - 57"    |
| 0221 | SAVILLE AV | KDEW 50 A 12 U  | 33 - 57"    |
| 0222 | THOMSON    | 32 LB 04 S 5 U  | 33 - 57"    |
| 0223 | SONY       | KDLW 40 A 12 U  | 33 - 57"    |
| 0226 | NEC        | T 1000          | 33 - 57"    |
| 0228 | SMARTBOARD | SB 660          | Interactive |
| 0228 | SMARTBOARD | SB 680          | Interactive |
| 0229 | JVC        | GMH 40 L 1 G    | 33 - 57"    |
| 0229 | JVC        | GMH 40 L 2 G    | 33 - 57"    |
| 0230 | SONY       | KDL 40 V 2000   | 33 - 57"    |
| 0230 | SONY       | KDL 46 X 2000   | 33 - 57"    |
| 0230 | SONY       | KDLS 40 A 12 U  | 33 - 57"    |
| 0230 | SONY       | KDL 40 S 2010   | 33 - 57"    |
| 0231 | LOEWE      | INDIVIDUAL 32 S | 33 - 57"    |
| 0232 | NEC        | PX 50 XM 5 G    | 33 - 57"    |
| 0232 | NEC        | PX 50 XR 5 G    | 33 - 57"    |
| 0232 | NEC        | 50 XM 6         | 33 - 57"    |
| 0233 | PANASONIC  | TX 32 LXD 60    | 33 - 57"    |
| 0233 | PANASONIC  | BTLH 2600 WE    | 33 - 57"    |
| 0234 | CONRAC     | 6032 PD         | 33 - 57"    |
| 0234 | CONRAC     | 6032 PD 005 025 | 33 - 57"    |
| 0235 | VISION     | GLTM 550 B      | 33 - 57"    |

|      |                 |                   |          |
|------|-----------------|-------------------|----------|
| 0236 | HUMAX           | 32 PF 9731        | 33 - 57" |
| 0236 | HUMAX           | LGB 40 TPVR       | 33 - 57" |
| 0237 | CISCO           | 32"               | 33 - 57" |
| 0237 | LG              | M 3200 C          | 33 - 57" |
| 0237 | LG              | M 3202 C          | 33 - 57" |
| 0237 | LG              | L 3200 C          | 33 - 57" |
| 0237 | LG              | M 3201 C          | 33 - 57" |
| 0238 | SAMSUNG         | SMT 4022 P        | 33 - 57" |
| 0239 | CONRAC          | 6946 PD 002 001   | 33 - 57" |
| 0241 | ATEC            | AV 420 W          | 33 - 57" |
| 0242 | VISION          | VMD 4200 P        | 33 - 57" |
| 0243 | PHILIPS         | BDL 4221          | 33 - 57" |
| 0244 | DAEWOO          | DLP 37 D 1        | 33 - 57" |
| 0245 | ACER            | AT 3202           | 33 - 57" |
| 0246 | RELISYS         | RLT 32 AG 20      | 33 - 57" |
| 0248 | TOSHIBA         | 37 WLT 58         | 33 - 57" |
| 0249 | MARANTZ         | LC 3201 ENIB      | 33 - 57" |
| 0250 | TEW             | T 42 - 122        | 33 - 57" |
| 0251 | HITACHI         | 55 PD 9700 U      | 33 - 57" |
| 0252 | FUJITSU SIEMENS | V 301             | 33 - 57" |
| 0253 | FUJITSU SIEMENS | PDP TV PQ 421     | 33 - 57" |
| 0254 | SONY            | KDL 32 S 2010     | 33 - 57" |
| 0254 | SONY            | 32 V 2500         | 33 - 57" |
| 0255 | BANG & OLUFSEN  | BEOVISION 732 880 | 33 - 57" |
| 0256 | TOSHIBA         | 47 WLT 66         | 33 - 57" |
| 0262 | NEC             | E 321             | 33 - 57" |
| 0262 | SANYO           | CE 32 LM 5        | 33 - 57" |
| 0262 | SHARP           | 32 D 44           | 33 - 57" |
| 0262 | TOSHIBA         | 32 XV 55          | 33 - 57" |
| 0262 | TOSHIBA         | 32 AV 615 DB      | 33 - 57" |
| 0262 | TOSHIBA         | 32 AV 635         | 33 - 57" |
| 0262 | TOSHIBA         | 32 A 3000 P       | 33 - 57" |
| 0262 | TOSHIBA         | 32 AV 504         | 33 - 57" |
| 0262 | TOSHIBA         | 32 DV 713 B       | 33 - 57" |

|      |            |                   |             |
|------|------------|-------------------|-------------|
| 0262 | SANYO      | CE 42 WPX 1       | 33 - 57"    |
| 0262 | SANYO      | CE 42 LM 4 R E    | 33 - 57"    |
| 0262 | SANYO      | CE 42 LM 4 WPRE   | 33 - 57"    |
| 0262 | SANYO      | 42 LM 5           | 33 - 57"    |
| 0262 | SANYO      | 42 SR 4           | 33 - 57"    |
| 0263 | NEC        | LCD 5710          | 33 - 57"    |
| 0264 | SMARTBOARD | SB 540            | Interactive |
| 0264 | SONY       | KDL 32 U 2000     | 33 - 57"    |
| 0266 | SONY       | KDL 52 X 2000     | 33 - 57"    |
| 0267 | SONY       | KDL 40 U 2000     | 33 - 57"    |
| 0268 | LG         | 50 PY 2 R         | 33 - 57"    |
| 0270 | VISION     | LT 5520 APN       | 33 - 57"    |
| 0271 | HITACHI    | 32 LD 8700        | 33 - 57"    |
| 0271 | HITACHI    | 37 LD 8700        | 33 - 57"    |
| 0272 | HITACHI    | 42 PD 9700        | 33 - 57"    |
| 0273 | PENTA      | D 1001401         | 33 - 57"    |
| 0273 | PENTA      | 47 HD 2           | 33 - 57"    |
| 0274 | PANASONIC  | TH 103 PF 9 EC    | 91 - 108"   |
| 0274 | PANASONIC  | TH 103 PF 12      | 91 - 108"   |
| 0275 | SCEPTRE    | X 37 SV - NAGA    | 33 - 57"    |
| 0276 | SHARP      | LC 52 XD 1 E      | 33 - 57"    |
| 0276 | SHARP      | LC 52 XL 1 E      | 33 - 57"    |
| 0277 | DMTECH     | LQ 37 XTY         | 33 - 57"    |
| 0277 | DMTECH     | DML 4137 XTY      | 33 - 57"    |
| 0277 | DMTECH     | LM 37 DT          | 33 - 57"    |
| 0278 | LG         | 32 LX 2 R         | 33 - 57"    |
| 0278 | LG         | 32 LC 56          | 33 - 57"    |
| 0279 | JVC        | LT 46 DZ 7 BJ     | 33 - 57"    |
| 0279 | JVC        | LT 46 DS 9        | 33 - 57"    |
| 0280 | DAEWOO     | DLP 42 C 1        | 33 - 57"    |
| 0281 | LG         | 42 LT 75          | 33 - 57"    |
| 0282 | SHARP      | LCD 32 DH 57 E    | 33 - 57"    |
| 0282 | SAMSUNG    | LE 32 R 87 BD     | 33 - 57"    |
| 0282 | SAMSUNG    | LE 32 A 436 T 1 D | 33 - 57"    |
| 0282 | SAMSUNG    | LE 32 A 457       | 33 - 57"    |

|      |         |                 |          |
|------|---------|-----------------|----------|
| 0282 | SAMSUNG | LE 32 R 86      | 33 - 57" |
| 0282 | SAMSUNG | LE 32 R 88      | 33 - 57" |
| 0282 | SAMSUNG | LE 32 A 45      | 33 - 57" |
| 0282 | SAMSUNG | LE 32 B 550     | 33 - 57" |
| 0282 | SAMSUNG | LE 37 A 436     | 33 - 57" |
| 0282 | SAMSUNG | LE 32 B 450     | 33 - 57" |
| 0282 | LG      | 42 LG 3000      | 33 - 57" |
| 0282 | LG      | 47 LG 5000      | 33 - 57" |
| 0282 | LG      | 42 LG 5000      | 33 - 57" |
| 0282 | SAMSUNG | LE 40 R 87 BD   | 33 - 57" |
| 0282 | SAMSUNG | LE 40 N 87      | 33 - 57" |
| 0282 | SAMSUNG | LE 40 S 86 BDX  | 33 - 57" |
| 0282 | SAMSUNG | 40 A 656        | 33 - 57" |
| 0282 | SAMSUNG | LE 40 A 786     | 33 - 57" |
| 0282 | SAMSUNG | LE 40 A 558     | 33 - 57" |
| 0282 | SAMSUNG | LE 40 A 336 J 1 | 33 - 57" |
| 0282 | SAMSUNG | LE 37 S 86 BDX  | 33 - 57" |
| 0284 | PENTA   | PD 37 W         | 33 - 57" |
| 0285 | THOMSON | LB 138 B 5      | 33 - 57" |
| 0287 | SONY    | KDL 46 S 2530 U | 33 - 57" |
| 0287 | SONY    | KDL 46 S 2000   | 33 - 57" |
| 0287 | SONY    | KDL 46 S 2510   | 33 - 57" |
| 0287 | SONY    | KDL 46 V 2500   | 33 - 57" |
| 0288 | NEC     | LCD 3210        | 33 - 57" |
| 0288 | NEC     | LCD 3215        | 33 - 57" |
| 0288 | NEC     | V 321           | 33 - 57" |
| 0288 | NEC     | LCD 3220        | 33 - 57" |
| 0288 | NEC     | LCD 4010        | 33 - 57" |
| 0288 | NEC     | M 40 AV         | 33 - 57" |
| 0288 | PHILIPS | MDT 421 S       | 33 - 57" |
| 0288 | PHILIPS | BDL 4251 V      | 33 - 57" |
| 0288 | PHILIPS | BDL 3245 E      | 33 - 57" |
| 0288 | PHILIPS | LDT 461 V       | 33 - 57" |
| 0288 | PHILIPS | MDT 461 S       | 33 - 57" |
| 0288 | PHILIPS | LDT 422 V 2     | 33 - 57" |
| 0288 | NEC     | LCD 4610        | 33 - 57" |
| 0288 | NEC     | LCD 4620        | 33 - 57" |
| 0288 | NEC     | M 46 AV         | 33 - 57" |
| 0288 | NEC     | V 461           | 33 - 57" |
| 0288 | NEC     | V 421           | 33 - 57" |
| 0288 | NEC     | E 505           | 33 - 57" |
| 0288 | PHILIPS | BDL 4225        | 33 - 57" |
| 0288 | PHILIPS | BDL 4230 E      | 33 - 57" |
| 0288 | PHILIPS | BDL 4651 VH     | 33 - 57" |
| 0288 | PHILIPS | BDL 4645 E      | 33 - 57" |
| 0288 | PHILIPS | BDL 4245 E      | 33 - 57" |
| 0288 | SHARP   | PN 465 E        | 33 - 57" |
| 0288 | SHARP   | PNE 471         | 33 - 57" |
| 0288 | SHARP   | LC 50 LE 751 K  | 33 - 57" |

|      |                |                 |          |
|------|----------------|-----------------|----------|
| 0288 | SHARP          | LC 50 LE 651 K  | 33 - 57" |
| 0288 | TOSHIBA        | 42 XV 635       | 33 - 57" |
| 0288 | JVC            | GDF 46 L 1      | 33 - 57" |
| 0288 | JVC            | GD 463 D 10 E   | 33 - 57" |
| 0288 | NEC            | LCD 4000        | 33 - 57" |
| 0290 | SAMSUNG        | LE 52 M 87 BD   | 33 - 57" |
| 0290 | SAMSUNG        | LE 52 F 96      | 33 - 57" |
| 0291 | HITACHI        | P 50 T 01 U     | 33 - 57" |
| 0292 | CISCO          | PRO 52          | 33 - 57" |
| 0292 | SAMSUNG        | 570 DX          | 33 - 57" |
| 0292 | SAMSUNG        | SM 570          | 33 - 57" |
| 0292 | SAMSUNG        | 520 DX          | 33 - 57" |
| 0293 | BANG & OLUFSEN | BV 740          | 33 - 57" |
| 0295 | INFINITE       | M PDP 4220      | 33 - 57" |
| 0295 | ORION          | 4220            | 33 - 57" |
| 0296 | DEMCO          | SMP 420 APZ     | 33 - 57" |
| 0297 | LG             | 50 PC 55        | 33 - 57" |
| 0298 | LG             | 42 LM 620 T     | 33 - 57" |
| 0298 | SHARP          | LC 52 X 20 E    | 33 - 57" |
| 0298 | SHARP          | 52 D 65         | 33 - 57" |
| 0298 | SHARP          | LC 52 XL 2 E    | 33 - 57" |
| 0298 | SONY           | GXDL 52 H 1     | 33 - 57" |
| 0300 | SONY           | 40 S 3000       | 33 - 57" |
| 0300 | SONY           | KDL 40 D 3500 U | 33 - 57" |
| 0300 | SONY           | KDL 40 D 3000   | 33 - 57" |
| 0300 | SONY           | FWD 40 W 600 P  | 33 - 57" |
| 0300 | SONY           | FWDS 42 H 5     | 33 - 57" |
| 0300 | SONY           | KDL 40 X 3000 U | 33 - 57" |
| 0300 | SONY           | FWD 48 W 600 P  | 33 - 57" |
| 0302 | NEC            | 42 XP 10        | 33 - 57" |
| 0302 | NEC            | 50 XP 10        | 33 - 57" |
| 0302 | NEC            | 50 XC 10        | 33 - 57" |
| 0303 | SANYO          | CE 42 LD 81 B   | 33 - 57" |
| 0304 | MIRAI          | DTL 632 E 600   | 33 - 57" |
| 0305 | SHARP          | LC 42 LE 40 E   | 33 - 57" |
| 0305 | SONY           | FWDS 42 H 1     | 33 - 57" |
| 0305 | SONY           | 42 H 5          | 33 - 57" |
| 0305 | SONY           | FWD 42 B 2      | 33 - 57" |
| 0305 | SONY           | FWDS 42 H 2     | 33 - 57" |
| 0305 | SHARP          | LC 46 X 20 E    | 33 - 57" |



|      |         |                 |          |
|------|---------|-----------------|----------|
| 0305 | SHARP   | LC 42 XL 2 E    | 33 - 57" |
| 0305 | SHARP   | LC 42 B 20 E    | 33 - 57" |
| 0305 | SHARP   | LC 46 XL 2 E    | 33 - 57" |
| 0305 | SHARP   | LC 46 D 65      | 33 - 57" |
| 0305 | SHARP   | LC 46 LE 600 E  | 33 - 57" |
| 0305 | SHARP   | LC 46 LE 700 E  | 33 - 57" |
| 0305 | SHARP   | LC 42 DH 77 E   | 33 - 57" |
| 0305 | SHARP   | LC 46 LE 821 E  | 33 - 57" |
| 0305 | SHARP   | LC 46 LE 811    | 33 - 57" |
| 0305 | SHARP   | LC 46 LE 631 E  | 33 - 57" |
| 0305 | SHARP   | LC 42 X 20 E    | 33 - 57" |
| 0305 | SHARP   | LC 40 SH 340 K  | 33 - 57" |
| 0305 | SHARP   | LC 40 LE 631 E  | 33 - 57" |
| 0305 | SONY    | FWDS 47 H       | 33 - 57" |
| 0305 | SONY    | FWD 46 B 2      | 33 - 57" |
| 0305 | SONY    | FWD-S 46 H 2    | 33 - 57" |
| 0305 | SONY    | LMD 4250 K      | 33 - 57" |
| 0305 | SONY    | FWDS 55 H 2     | 33 - 57" |
| 0305 | SONY    | FWD 55 B 2      | 33 - 57" |
| 0307 | SHARP   | LC 37 X 20 E    | 33 - 57" |
| 0307 | SHARP   | LC 40 LE 600    | 33 - 57" |
| 0307 | SHARP   | LC 40 LE 831 E  | 33 - 57" |
| 0307 | SHARP   | LC 40 LE 700 E  | 33 - 57" |
| 0307 | SONY    | KDL 40 LX 903 U | 33 - 57" |
| 0307 | PIONEER | KRL 32 V        | 33 - 57" |
| 0307 | PIONEER | KRL 37 V        | 33 - 57" |
| 0307 | SHARP   | LC 32 X 20      | 33 - 57" |
| 0308 | SONY    | KDL 55 EX 713 U | 33 - 57" |
| 0308 | SONY    | KDL 52 W 3000   | 33 - 57" |
| 0308 | SONY    | KDL 52 X 3500   | 33 - 57" |
| 0309 | SANYO   | CE 26 LD 33 B   | 33 - 57" |
| 0309 | GRUNDIG | GV 32 DVD       | 33 - 57" |
| 0309 | HITACHI | L 37 V 01 U     | 33 - 57" |
| 0309 | SANYO   | 32 LD 81        | 33 - 57" |
| 0309 | SANYO   | CE 32 LD 33 B   | 33 - 57" |
| 0309 | SANYO   | CE 37 FD 90     | 33 - 57" |
| 0309 | SANYO   | CE 37 FD 33     | 33 - 57" |
| 0309 | SHARP   | LC 42 CT 2 E    | 33 - 57" |
| 0310 | JVC     | GDF 52 L 1      | 33 - 57" |
| 0310 | SHARP   | PN 525 E        | 33 - 57" |
| 0310 | SHARP   | PNE 521         | 33 - 57" |
| 0311 | ELONEX  | LNX GAZ 50 A    | 33 - 57" |
| 0312 | PACER   | SMP 320 LPZ     | 33 - 57" |
| 0313 | AXIUM   | HDL 32          | 15 - 32" |
| 0314 | PHILIPS | BDL 3731 V      | 33 - 57" |

|      |            |               |          |
|------|------------|---------------|----------|
| 0315 | SANYO      | CE 42 LE 1    | 33 - 57" |
| 0315 | SANYO      | CE 42 SRE 1   | 33 - 57" |
| 0315 | SAVILLE AV | HD 4200       | 33 - 57" |
| 0317 | NEC        | P 551         | 33 - 57" |
| 0317 | DYNASCAN   | DS 55 LT 4    | 33 - 57" |
| 0317 | NEC        | V 551         | 33 - 57" |
| 0317 | NEC        | X 551 UN      | 33 - 57" |
| 0317 | NEC        | P 552         | 33 - 57" |
| 0317 | NEC        | X 554 UN      | 33 - 57" |
| 0317 | NEC        | X 554 UNS     | 33 - 57" |
| 0317 | JVC        | GMF 520 S     | 33 - 57" |
| 0317 | NEC        | LCD 5220      | 33 - 57" |
| 0317 | NEC        | P 521         | 33 - 57" |
| 0318 | PHILIPS    | 32 PFL 5403   | 33 - 57" |
| 0319 | TOSHIBA    | 52 Z 3030     | 33 - 57" |
| 0319 | TOSHIBA    | 52 XV 555     | 33 - 57" |
| 0319 | TOSHIBA    | 55 ZV 635     | 33 - 57" |
| 0319 | TOSHIBA    | 57 Z 3030     | 33 - 57" |
| 0319 | TOSHIBA    | 55 WL 53 B    | 33 - 57" |
| 0321 | SAMSUNG    | PS 42 A 457   | 33 - 57" |
| 0321 | SAMSUNG    | PS 42 B 451   | 33 - 57" |
| 0322 | LG         | 42 LA 660 V   | 33 - 57" |
| 0322 | LG         | 42 LA 860 W   | 33 - 57" |
| 0322 | LG         | 42 LA 740 V   | 33 - 57" |
| 0322 | LG         | 42 LA 690 V   | 33 - 57" |
| 0322 | LG         | 42 LA 641 V   | 33 - 57" |
| 0322 | LG         | 42 LA 640 V   | 33 - 57" |
| 0322 | LG         | 42 LB 730 V   | 33 - 57" |
| 0322 | LG         | 42 LB 630 V   | 33 - 57" |
| 0322 | LG         | 42 LB 580 V   | 33 - 57" |
| 0322 | LG         | 42 LB 561 V   | 33 - 57" |
| 0322 | LG         | 42 LB 5500    | 33 - 57" |
| 0322 | LG         | 42 LB 731 V   | 33 - 57" |
| 0322 | LG         | 42 LB 700 V   | 33 - 57" |
| 0322 | LG         | 42 LB 585 V   | 33 - 57" |
| 0322 | LG         | 42 LB 570 V   | 33 - 57" |
| 0322 | LG         | PD 42 PG 3000 | 33 - 57" |
| 0322 | LG         | 47 LA 620 V   | 33 - 57" |
| 0322 | LG         | 50 PH 660 V   | 33 - 57" |
| 0322 | LG         | 50 PN 650 T   | 33 - 57" |
| 0322 | LG         | 42 PN 450 B   | 33 - 57" |
| 0322 | LG         | 47 LA 740 V   | 33 - 57" |
| 0322 | LG         | 47 LA 660 V   | 33 - 57" |
| 0322 | LG         | 47 LA 860 W   | 33 - 57" |
| 0322 | LG         | 50 PH 670 V   | 33 - 57" |
| 0322 | LG         | 50 PN 450 B   | 33 - 57" |
| 0322 | LG         | 47 LN 575 V   | 33 - 57" |
| 0322 | LG         | 50 LA 660 V   | 33 - 57" |

|      |           |             |          |
|------|-----------|-------------|----------|
| 0322 | LG        | 47 LN 578 V | 33 - 57" |
| 0322 | LG        | 47 LN 570 V | 33 - 57" |
| 0322 | LG        | 50 LA 620 V | 33 - 57" |
| 0322 | LG        | 47 LA 790 W | 33 - 57" |
| 0322 | LG        | 50 LN 540 V | 33 - 57" |
| 0322 | LG        | 47 LA 641 V | 33 - 57" |
| 0322 | LG        | 47 LA 640 V | 33 - 57" |
| 0322 | LG        | 50 LN 578 V | 33 - 57" |
| 0322 | LG        | 47 LN 5400  | 33 - 57" |
| 0322 | LG        | 47 LA 613 V | 33 - 57" |
| 0322 | LG        | 47 LN 613 V | 33 - 57" |
| 0322 | LG        | 50 PZ 950 T | 33 - 57" |
| 0322 | LG        | 50 PA 650 T | 33 - 57" |
| 0322 | LG        | 47 LM 670 T | 33 - 57" |
| 0322 | LG        | 47 LM 620 T | 33 - 57" |
| 0322 | LG        | 50 PA 4500  | 33 - 57" |
| 0322 | LG        | 47 LM 660 T | 33 - 57" |
| 0322 | LG        | 47 LS 5700  | 33 - 57" |
| 0322 | LG        | 47 LW 650 T | 33 - 57" |
| 0322 | LG        | 47 LV 550 T | 33 - 57" |
| 0322 | LG        | 42 LS 5600  | 33 - 57" |
| 0322 | LG        | 47 LS 5600  | 33 - 57" |
| 0322 | LG        | 47 LW 550 T | 33 - 57" |
| 0322 | LG        | 47 WL 10 MS | 33 - 57" |
| 0322 | LG        | 50 PB 5600  | 33 - 57" |
| 0322 | LG        | 47 LB 731 V | 33 - 57" |
| 0322 | LG        | 47 LA 690 V | 33 - 57" |
| 0322 | LG        | 55 LA 620 V | 33 - 57" |
| 0322 | LG        | 55 LA 690 V | 33 - 57" |
| 0322 | LG        | 55 LA 660 V | 33 - 57" |
| 0322 | LG        | 55 LA 860 W | 33 - 57" |
| 0322 | LG        | 55 LA 740 V | 33 - 57" |
| 0322 | LG        | 55 LA 790 W | 33 - 57" |
| 0322 | LG        | 55 LN 575 V | 33 - 57" |
| 0322 | LG        | 55 LA 640 V | 33 - 57" |
| 0322 | LG        | 55 LA 641 V | 33 - 57" |
| 0322 | PANASONIC | TH 55 LFE 8 | 33 - 57" |
| 0322 | LG        | 50 PG 6000  | 33 - 57" |
| 0323 | SAMSUNG   | LE 52 A 559 | 33 - 57" |
| 0323 | SAMSUNG   | LE 52 A 656 | 33 - 57" |
| 0323 | SAMSUNG   | OM 55 D     | 33 - 57" |
| 0324 | LG        | 50 PG 3000  | 33 - 57" |
| 0325 | LG        | M 5520 C    | 33 - 57" |
| 0325 | LG        | M 4716 CC   | 33 - 57" |
| 0325 | LG        | 47 VS 10    | 33 - 57" |
| 0325 | LG        | 55 VS 20    | 33 - 57" |
| 0325 | LG        | 47 VX 30 AF | 33 - 57" |
| 0325 | LG        | 47 WV 30    | 33 - 57" |
| 0325 | LG        | 47 VL 10    | 33 - 57" |
| 0325 | LG        | 47 VS 20    | 33 - 57" |

|      |           |                 |          |
|------|-----------|-----------------|----------|
| 0326 | LG        | M 5201          | 33 - 57" |
| 0326 | LG        | 52 LG 5000      | 33 - 57" |
| 0327 | SONY      | KDL 52 NX 803   | 33 - 57" |
| 0327 | SONY      | 52 W 4000       | 33 - 57" |
| 0327 | SONY      | KDL 52 V 4000 U | 33 - 57" |
| 0327 | SONY      | 52 V 5500       | 33 - 57" |
| 0327 | SONY      | KDL 52 W 5500   | 33 - 57" |
| 0327 | SONY      | KDL 52 V 5100   | 33 - 57" |
| 0327 | SONY      | KDL 52 W 5810   | 33 - 57" |
| 0327 | SONY      | KDL 52 V 5810   | 33 - 57" |
| 0327 | SONY      | KDL 52 Z 4500   | 33 - 57" |
| 0327 | SONY      | KDL 52 EX 703 U | 33 - 57" |
| 0327 | SONY      | FWD 55 HX 750 P | 33 - 57" |
| 0327 | SONY      | KDL 55 EX 720 P | 33 - 57" |
| 0329 | SANYO     | CE 42 FD 33 B   | 33 - 57" |
| 0329 | SANYO     | CE 42 LD 33 B   | 33 - 57" |
| 0329 | SANYO     | CE 42 FD 90     | 33 - 57" |
| 0330 | PHILIPS   | 42 PFL 5603 D   | 33 - 57" |
| 0330 | PHILIPS   | 42 PFL 8404     | 33 - 57" |
| 0330 | PHILIPS   | 47 PFL 7404     | 33 - 57" |
| 0330 | PHILIPS   | 47 PFL 4007     | 33 - 57" |
| 0332 | LG        | 32 LT 360 C     | 33 - 57" |
| 0332 | LG        | 32 LN 549 C     | 33 - 57" |
| 0332 | SONY      | KDL 40 R 473 A  | 33 - 57" |
| 0333 | SONY      | KDL 46 V 3000   | 33 - 57" |
| 0334 | TOSHIBA   | 42 C 505        | 33 - 57" |
| 0334 | TOSHIBA   | 42 RV 555       | 33 - 57" |
| 0334 | TOSHIBA   | 42 AV 635       | 33 - 57" |
| 0334 | TOSHIBA   | 46 XV 635 DB    | 33 - 57" |
| 0334 | TOSHIBA   | 42 CV 505 DB    | 33 - 57" |
| 0334 | TOSHIBA   | 42 XV 505 DB    | 33 - 57" |
| 0334 | TOSHIBA   | 40 RV 733       | 33 - 57" |
| 0334 | TOSHIBA   | 50 L 7355       | 33 - 57" |
| 0334 | TOSHIBA   | 50 L 4353       | 33 - 57" |
| 0334 | TOSHIBA   | 50 L 2333       | 33 - 57" |
| 0334 | TOSHIBA   | 40 L 1333       | 33 - 57" |
| 0334 | TOSHIBA   | 40 L 1353       | 33 - 57" |
| 0334 | TOSHIBA   | 40 L 1354       | 33 - 57" |
| 0334 | TOSHIBA   | 40 BV 702       | 33 - 57" |
| 0334 | TOSHIBA   | 42 HL 833 B     | 33 - 57" |
| 0335 | SANYO     | 52 LH 1 R       | 33 - 57" |
| 0336 | SANYO     | CE 32 LD 90 B   | 33 - 57" |
| 0336 | SANYO     | CE 32 FD 90     | 33 - 57" |
| 0336 | PRESTIGIO | P 320 DVD XD    | 33 - 57" |

|      |           |                 |          |
|------|-----------|-----------------|----------|
| 0337 | CISCO     | LCD-110L-PRO-42 | 33 - 57" |
| 0337 | LG        | M 4225          | 33 - 57" |
| 0337 | LG        | M 4214          | 33 - 57" |
| 0337 | LG        | 42 VS 10        | 33 - 57" |
| 0337 | PHILIPS   | 42 PFL 7662 D   | 33 - 57" |
| 0338 | BARCO     | LC 5621         | 33 - 57" |
| 0341 | LG        | 32 LS 570 T     | 33 - 57" |
| 0341 | LG        | 32 LB 580 V     | 33 - 57" |
| 0341 | LG        | 32 LB 561 V     | 33 - 57" |
| 0341 | LG        | 32 LB 5500      | 33 - 57" |
| 0341 | LG        | 32 LB 550 U     | 33 - 57" |
| 0341 | LG        | 32 LB 550 B     | 33 - 57" |
| 0341 | LG        | 32 LB 585 V     | 33 - 57" |
| 0341 | LG        | 32 LW 340 C     | 33 - 57" |
| 0341 | PANASONIC | TXL 26 X 10 B   | 33 - 57" |
| 0341 | PANASONIC | TXL 32 ET 5 B   | 33 - 57" |
| 0341 | PANASONIC | TXL 32 X 5 B    | 33 - 57" |
| 0341 | PANASONIC | TXL 32 DT 30 B  | 33 - 57" |
| 0341 | PANASONIC | TXL 32 E 3 B    | 33 - 57" |
| 0341 | SAMSUNG   | MD 32 B         | 33 - 57" |
| 0341 | SAMSUNG   | ED 32 D         | 33 - 57" |
| 0341 | SHARP     | LC 32 LE 60     | 33 - 57" |
| 0341 | LG        | 37 LH 2000      | 33 - 57" |
| 0341 | LG        | 37 LH 4000      | 33 - 57" |
| 0341 | LG        | 37 LH 3000      | 33 - 57" |
| 0341 | LG        | 37 LD 450       | 33 - 57" |
| 0341 | LG        | 37 LH 301       | 33 - 57" |
| 0341 | LG        | 37 SL 8000      | 33 - 57" |
| 0341 | LG        | 42 LN 578 V     | 33 - 57" |
| 0341 | LG        | 42 LN 540 V     | 33 - 57" |
| 0341 | LG        | 42 LN 575 V     | 33 - 57" |
| 0341 | LG        | 42 LN 570 V     | 33 - 57" |
| 0341 | LG        | 37 LM 620 T     | 33 - 57" |
| 0341 | LG        | M 3204 C        | 33 - 57" |
| 0341 | LG        | 37 LS 570 T     | 33 - 57" |
| 0341 | LG        | 37 LT 360 C     | 33 - 57" |
| 0341 | LG        | 32 LB 650 V     | 33 - 57" |
| 0341 | LG        | 42 LN 543 V     | 33 - 57" |
| 0341 | LG        | 43 SE 3 KE      | 33 - 57" |
| 0341 | PANASONIC | TX 32 S 10      | 33 - 57" |
| 0341 | PANASONIC | TXL 32 G 10     | 33 - 57" |
| 0341 | PANASONIC | TXL 37 S 10     | 33 - 57" |
| 0341 | PANASONIC | TXL 37 E 30     | 33 - 57" |
| 0341 | PANASONIC | TXL 32 X 15 B   | 33 - 57" |
| 0341 | PANASONIC | TXL 37 E 5 B    | 33 - 57" |
| 0341 | PANASONIC | TXL 32 U 3 B    | 33 - 57" |
| 0341 | PANASONIC | TXL 37 ET 5 B   | 33 - 57" |
| 0341 | PANASONIC | TXL 37 DT 30 B  | 33 - 57" |
| 0341 | PANASONIC | TXL 32 C 5 B    | 33 - 57" |
| 0341 | PANASONIC | TXL 32 C 3 B    | 33 - 57" |
| 0341 | PANASONIC | TXL 37 E 3 B    | 33 - 57" |

|      |           |                   |          |
|------|-----------|-------------------|----------|
| 0341 | PANASONIC | TXL 32 E 30 B     | 33 - 57" |
| 0341 | PANASONIC | TH 32 LRH 30 U    | 33 - 57" |
| 0341 | PANASONIC | TH 32 LRU 5       | 33 - 57" |
| 0341 | PANASONIC | TH 37 LRU 5       | 33 - 57" |
| 0341 | PHILIPS   | 37 PFL 9604       | 33 - 57" |
| 0341 | SAMSUNG   | LE 32 A 558 P3F   | 33 - 57" |
| 0341 | SAMSUNG   | CE 32 C 530       | 33 - 57" |
| 0341 | SAMSUNG   | LE 32 A 656       | 33 - 57" |
| 0341 | SAMSUNG   | LE 32 A 556       | 33 - 57" |
| 0341 | SAMSUNG   | LE 37 B 550       | 33 - 57" |
| 0341 | SAMSUNG   | LE 37 B 530       | 33 - 57" |
| 0341 | SAMSUNG   | LE 40 B 550 A 5 W | 33 - 57" |
| 0341 | SAMSUNG   | LE 40 B 553       | 33 - 57" |
| 0341 | SAMSUNG   | UE 37 D 50000     | 33 - 57" |
| 0341 | SAMSUNG   | MD 40 B           | 33 - 57" |
| 0341 | SAMSUNG   | ED 40             | 33 - 57" |
| 0341 | SAMSUNG   | MD 40 C           | 33 - 57" |
| 0341 | SAMSUNG   | 40 ES 6300        | 33 - 57" |
| 0341 | SAMSUNG   | 32 D 550          | 33 - 57" |
| 0341 | SAMSUNG   | LE 40 D 503       | 33 - 57" |
| 0341 | SAMSUNG   | 40 EH 5000        | 33 - 57" |
| 0341 | SAMSUNG   | ED 40 D           | 33 - 57" |
| 0341 | SHARP     | LC 37 D 65 E      | 33 - 57" |
| 0341 | SONY      | KDL 32 W 5500     | 33 - 57" |
| 0341 | SONY      | KDL 32 EX 401     | 33 - 57" |
| 0341 | SONY      | KDL 32 W 5710     | 33 - 57" |
| 0341 | SONY      | KDL 32 EX 503     | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 133 DB       | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 7355         | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 6353         | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 1353 DB      | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 1354 DB      | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 1333 DB      | 33 - 57" |
| 0341 | TOSHIBA   | 40 HL 933 B       | 33 - 57" |
| 0341 | LG        | 42 LH 2000        | 33 - 57" |
| 0341 | LG        | 42 LH 3000        | 33 - 57" |
| 0341 | LG        | 42 SL 9000        | 33 - 57" |
| 0341 | LG        | 47 LH 4000        | 33 - 57" |
| 0341 | LG        | 42 LH 5000        | 33 - 57" |
| 0341 | LG        | 47 LH 3000        | 33 - 57" |
| 0341 | LG        | 42 SL 9500        | 33 - 57" |
| 0341 | LG        | 42 LH 201         | 33 - 57" |
| 0341 | LG        | 47 LD 920         | 33 - 57" |
| 0341 | LG        | 47 LD 450         | 33 - 57" |
| 0341 | LG        | 42 LD 450         | 33 - 57" |
| 0341 | LG        | 42 LD 420         | 33 - 57" |
| 0341 | LG        | 47 LD 420 C       | 33 - 57" |
| 0341 | LG        | 42 LK 450         | 33 - 57" |
| 0341 | LG        | 42 LK 455         | 33 - 57" |
| 0341 | LG        | 42 LH 301         | 33 - 57" |
| 0341 | LG        | 42 LK 530         | 33 - 57" |
| 0341 | LG        | 42 CS 460         | 33 - 57" |
| 0341 | LG        | 42 LN 5400        | 33 - 57" |

|      |              |                  |          |
|------|--------------|------------------|----------|
| 0341 | LG           | 42 LA 613 V      | 33 - 57" |
| 0341 | LG           | 42 LN 613 V      | 33 - 57" |
| 0341 | LG           | 42 LE 5310       | 33 - 57" |
| 0341 | PANASONIC    | TXL 42 S 10 B    | 33 - 57" |
| 0341 | PANASONIC    | TXL 42 E 30 B    | 33 - 57" |
| 0341 | PANASONIC    | TXL 42 D 25 B    | 33 - 57" |
| 0341 | PANASONIC    | TH 42 LRU 5      | 33 - 57" |
| 0341 | PANASONIC    | TH 42 LFE 7 U    | 33 - 57" |
| 0341 | SAMSUNG      | LE 40 A 457      | 33 - 57" |
| 0341 | SAMSUNG      | LE 40 B 650      | 33 - 57" |
| 0341 | SAMSUNG      | ED 40 C          | 33 - 57" |
| 0341 | SONY         | FW 49 BZ 35 F    | 33 - 57" |
| 0341 | LG           | 37 LG 3000       | 33 - 57" |
| 0341 | LG           | 37 LF 2510       | 33 - 57" |
| 0341 | LG           | 42 LF 2500       | 33 - 57" |
| 0341 | LG           | 37 LF 7700       | 33 - 57" |
| 0341 | LG           | 42 LF 7700       | 33 - 57" |
| 0341 | LG           | 42 D 490         | 33 - 57" |
| 0341 | LG           | 37 LS 5600       | 33 - 57" |
| 0341 | LG           | 42 LA 620 V      | 33 - 57" |
| 0341 | LG           | 42 LN 540        | 33 - 57" |
| 0341 | LG           | 43 LX 341 C      | 33 - 57" |
| 0341 | LG           | 32 LX 330 C      | 33 - 57" |
| 0341 | LG           | 43 LH 604 V      | 33 - 57" |
| 0341 | LG           | 40 UF 770 V      | 33 - 57" |
| 0341 | LG           | 32 LV 340 C      | 33 - 57" |
| 0341 | LG           | 37 LH 201 C      | 33 - 57" |
| 0341 | SAHARA       | SV 40            | 33 - 57" |
| 0342 | CLEVER TOUCH | 52 MDT 1000      | 33 - 57" |
| 0343 | CLEVER TOUCH | 42 MDT 1000      | 33 - 57" |
| 0343 | COLLEVO      | 42 MDT 1         | 33 - 57" |
| 0344 | SAMSUNG      | KDL 40 EX 703    | 33 - 57" |
| 0344 | SONY         | 40 W 5710        | 33 - 57" |
| 0344 | SONY         | KDL 40 V 5500    | 33 - 57" |
| 0344 | SONY         | KDL 40 V 5810    | 33 - 57" |
| 0344 | SONY         | KDL 40 W 5740    | 33 - 57" |
| 0344 | SONY         | KDL 40 W 5810    | 33 - 57" |
| 0344 | SONY         | KDL 37 W 5810    | 33 - 57" |
| 0344 | SONY         | KDL 37 EX 524    | 33 - 57" |
| 0344 | SONY         | KDL 37 S 5500    | 33 - 57" |
| 0344 | SONY         | FWD 40 EX 650 P  | 33 - 57" |
| 0344 | SONY         | FWD 42 W 800 P/T | 33 - 57" |
| 0344 | SONY         | FWD 42 W 800 P   | 33 - 57" |
| 0344 | SONY         | KDL 40 HX 723    | 33 - 57" |
| 0344 | SONY         | KDL 40 CX 520 P  | 33 - 57" |
| 0344 | SONY         | KDL 46 EX 521 P  | 33 - 57" |
| 0344 | SONY         | KDL 46 CX 520 P  | 33 - 57" |
| 0344 | PHILIPS      | 47 PFL 9664 H/12 | 33 - 57" |
| 0344 | SONY         | KDL 46 V 4000 U  | 33 - 57" |
| 0344 | SONY         | KDL 40 EX 503 U  | 33 - 57" |

|      |         |                    |          |
|------|---------|--------------------|----------|
| 0344 | SONY    | KDL 40 L 4000      | 33 - 57" |
| 0344 | SONY    | KDL 46 W 5810      | 33 - 57" |
| 0344 | SONY    | KDL 40 S 5500      | 33 - 57" |
| 0344 | SONY    | KDL 46 Z 4500      | 33 - 57" |
| 0344 | SONY    | KDL 40 EX 401 U    | 33 - 57" |
| 0344 | SONY    | KDL 46 EX 403      | 33 - 57" |
| 0344 | SONY    | KDL 40 EX 523      | 33 - 57" |
| 0344 | SONY    | KDL 46 W 55        | 33 - 57" |
| 0344 | SONY    | FWD 46 EX 650 P    | 33 - 57" |
| 0344 | SONY    | FWD 47 W 800 P / T | 33 - 57" |
| 0344 | SONY    | FWD 47 W 800 P     | 33 - 57" |
| 0344 | SONY    | KDL 40 EX 501 P    | 33 - 57" |
| 0344 | SONY    | KDL 46 EX 723      | 33 - 57" |
| 0344 | SONY    | KDL 40 EX 500 P    | 33 - 57" |
| 0344 | SONY    | FWD 55 W 800 P / T | 33 - 57" |
| 0344 | SONY    | FWD 55 W 800 P     | 33 - 57" |
| 0344 | SONY    | FWD 55 X 8600 P    | 33 - 57" |
| 0344 | SONY    | FW 55 X 8570 C     | 33 - 57" |
| 0344 | SONY    | FW 65 BZ 35 F      | 33 - 57" |
| 0345 | HITACHI | L 42 VC 04 U       | 33 - 57" |
| 0347 | TVS     | KA 42              | 33 - 57" |
| 0348 | SONY    | KLH 40 X 1         | 33 - 57" |
| 0349 | AQUIVO  | AQWP 42 R          | 33 - 57" |
| 0350 | DGM     | LTV 3203 HT        | 33 - 57" |
| 0351 | SAMSUNG | LE 46 A 856        | 33 - 57" |
| 0352 | LG      | 42 WS 50           | 33 - 57" |
| 0352 | LG      | 42 WS 10           | 33 - 57" |
| 0352 | LG      | 42 PM 470 T        | 33 - 57" |
| 0352 | LG      | 42 PQ 6000         | 33 - 57" |
| 0352 | LG      | 50 PK 530          | 33 - 57" |
| 0352 | LG      | 50 PJ 650          | 33 - 57" |
| 0352 | LG      | PD 50 PJ 650       | 33 - 57" |
| 0352 | LG      | 50 PT 353 K        | 33 - 57" |
| 0352 | LG      | 42 PT 353 K        | 33 - 57" |
| 0352 | LG      | 50 PQ 6000         | 33 - 57" |
| 0352 | LG      | 55 LM 620          | 33 - 57" |
| 0352 | LG      | 55 LM 610          | 33 - 57" |
| 0352 | LG      | 42 PQ 3000         | 33 - 57" |
| 0352 | LG      | 50 PQ 3000         | 33 - 57" |
| 0352 | LG      | 50 PS 3000         | 33 - 57" |
| 0352 | LG      | 50 PQ 2000         | 33 - 57" |
| 0352 | LG      | 42 PJ 350          | 33 - 57" |
| 0352 | LG      | 50 PJ 350          | 33 - 57" |
| 0352 | LG      | 47 LV 355 U        | 33 - 57" |
| 0352 | LG      | 42 LV 450          | 33 - 57" |
| 0352 | LG      | 55 LA 970 W        | 33 - 57" |



|      |            |                |          |
|------|------------|----------------|----------|
| 0353 | mitsubishi | LDT 521 V      | 33 - 57" |
| 0354 | AQUIVO     | AQWP 32 R      | 33 - 57" |
| 0355 | PANASONIC  | TX 37 LZ 80    | 33 - 57" |
| 0355 | LG         | 42 LE 5900     | 33 - 57" |
| 0355 | LG         | 47 LK 530      | 33 - 57" |
| 0356 | PHILIPS    | 52 PFL 7404 H  | 33 - 57" |
| 0356 | PHILIPS    | BDT 5530 EM    | 33 - 57" |
| 0356 | PHILIPS    | 46 HFL 5573    | 33 - 57" |
| 0356 | PHILIPS    | 50 PFL 3807    | 33 - 57" |
| 0356 | SAMSUNG    | LE 52 A 856    | 33 - 57" |
| 0356 | SMARTBOARD | 6055           | 33 - 57" |
| 0356 | SONY       | 55 PFL 6606 T  | 33 - 57" |
| 0357 | PANASONIC  | TXP 37 X 10 B  | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 G 10    | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 S 10    | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 X 10 B  | 33 - 57" |
| 0357 | PANASONIC  | TH 42 PH 20 E  | 33 - 57" |
| 0357 | PANASONIC  | TH 42 PF 30    | 33 - 57" |
| 0357 | PANASONIC  | TXP 46 G 10 B  | 33 - 57" |
| 0357 | PANASONIC  | TH 42 PF 20 E  | 33 - 57" |
| 0357 | PANASONIC  | TXP 50 GT 60 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 GT 60 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 50 ST 50 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 ST 60 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 50 X 60 B  | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 X 60 B  | 33 - 57" |
| 0357 | PANASONIC  | TXP 50 GT 50 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 46 ST 30 B | 33 - 57" |
| 0357 | PANASONIC  | TH 42 PF 50 E  | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 GT 30 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 S 30    | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 U 30    | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 GT 50 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 ST 30 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 C 3     | 33 - 57" |
| 0357 | PANASONIC  | TXP 50 X 50 B  | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 X 50 B  | 33 - 57" |
| 0357 | PANASONIC  | TXP 46 GT 30 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 46 G 20 B  | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 UT 30 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 VT 30 E | 33 - 57" |
| 0357 | PANASONIC  | TXP 42 UT 50 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 50 UT 50 B | 33 - 57" |
| 0357 | PANASONIC  | TXP 50 VT 50 B | 33 - 57" |
| 0357 | PANASONIC  | TH 42 BT 300 U | 33 - 57" |
| 0357 | PANASONIC  | TH 42 PF 30 U  | 33 - 57" |
| 0357 | PANASONIC  | TH 42 PH 30 U  | 33 - 57" |
| 0357 | PANASONIC  | TXP 50 G 10 B  | 33 - 57" |
| 0357 | PANASONIC  | TXP 50 X 10    | 33 - 57" |

|      |           |                 |          |
|------|-----------|-----------------|----------|
| 0357 | PANASONIC | TXP 50 X 20 B   | 33 - 57" |
| 0357 | PANASONIC | TH 50 PF 20 E   | 33 - 57" |
| 0357 | PANASONIC | TX 50 PG 10     | 33 - 57" |
| 0357 | PANASONIC | TXP 50 V 10     | 33 - 57" |
| 0357 | PANASONIC | TXP 50 S 10     | 33 - 57" |
| 0357 | PANASONIC | TXP 50 G 20 B   | 33 - 57" |
| 0357 | PANASONIC | TH 50 PH 30 E   | 33 - 57" |
| 0357 | PANASONIC | TXP 50 VT 65 B  | 33 - 57" |
| 0357 | PANASONIC | TH 50 BT 300    | 33 - 57" |
| 0357 | PANASONIC | TXP 50 C 3      | 33 - 57" |
| 0357 | PANASONIC | TH 50 PF 50 E   | 33 - 57" |
| 0357 | PANASONIC | TXP 50 G 30 B   | 33 - 57" |
| 0357 | PANASONIC | TXP 50 U 30     | 33 - 57" |
| 0357 | PANASONIC | TXP 50 VT 30 E  | 33 - 57" |
| 0357 | PANASONIC | TXP 50 UT 30 B  | 33 - 57" |
| 0357 | PANASONIC | TH 50 BT 300 U  | 33 - 57" |
| 0357 | PANASONIC | TH 50 PF 30 U   | 33 - 57" |
| 0357 | PANASONIC | TH 50 PF 50 U   | 33 - 57" |
| 0357 | PANASONIC | TH 50 PH 30 U   | 33 - 57" |
| 0358 | SAMSUNG   | LE 55 B 650     | 33 - 57" |
| 0358 | SAMSUNG   | LE 55 B 655     | 33 - 57" |
| 0358 | SAMSUNG   | LE 55 C 650     | 33 - 57" |
| 0359 | SAMSUNG   | LE 46 B 530 P 7 | 33 - 57" |
| 0359 | SAMSUNG   | LE 46 B 550     | 33 - 57" |
| 0359 | SAMSUNG   | 46 B 650        | 33 - 57" |
| 0359 | SAMSUNG   | 42 C 450        | 33 - 57" |
| 0359 | SAMSUNG   | LE 46 C 530     | 33 - 57" |
| 0359 | SAMSUNG   | PS 43 E 430     | 33 - 57" |
| 0359 | SAMSUNG   | PS 43 E 450     | 33 - 57" |
| 0359 | SAMSUNG   | 50 EH 5300      | 33 - 57" |
| 0359 | SAMSUNG   | PS 51 D 550     | 33 - 57" |
| 0359 | SAMSUNG   | PS 43 D 450     | 33 - 57" |
| 0359 | SAMSUNG   | PS 51 D 450     | 33 - 57" |
| 0359 | SAMSUNG   | UE 46 ES 5500   | 33 - 57" |
| 0359 | SAMSUNG   | 46 EH 5000      | 33 - 57" |
| 0359 | SAMSUNG   | 46 D 6530       | 33 - 57" |
| 0359 | SAMSUNG   | 46 D 580        | 33 - 57" |
| 0359 | SAMSUNG   | PS 43 E 490     | 33 - 57" |
| 0359 | SAMSUNG   | 46 ES 8000      | 33 - 57" |
| 0359 | SAMSUNG   | UE 46 D 8090    | 33 - 57" |
| 0359 | SAMSUNG   | UE 50 ES 6300   | 33 - 57" |
| 0359 | SAMSUNG   | PS 42 B 430     | 33 - 57" |
| 0359 | SAMSUNG   | PS 50 B 430     | 33 - 57" |
| 0359 | SAMSUNG   | PS 50 B 551     | 33 - 57" |
| 0359 | SAMSUNG   | PS 50 B 451     | 33 - 57" |
| 0359 | SAMSUNG   | PS 50 C 450     | 33 - 57" |
| 0359 | SAMSUNG   | PS 50 C 550     | 33 - 57" |
| 0359 | SAMSUNG   | LE 50 B 550     | 33 - 57" |
| 0359 | SAMSUNG   | 55 ES 6300      | 33 - 57" |
| 0360 | SANYO     | CE 26 LD 90     | 33 - 57" |

|      |           |                |          |
|------|-----------|----------------|----------|
| 0361 | SAMSUNG   | UE 55 B 7020   | 33 - 57" |
| 0361 | SAMSUNG   | UE 55 C 7000   | 33 - 57" |
| 0361 | SAMSUNG   | UE 55 C 8000   | 33 - 57" |
| 0361 | SAMSUNG   | LE 46 C 653    | 33 - 57" |
| 0361 | SAMSUNG   | UE 55 D 6100   | 33 - 57" |
| 0361 | SAMSUNG   | 55 ES 6800     | 33 - 57" |
| 0361 | SAMSUNG   | UE 46 F 7000   | 33 - 57" |
| 0361 | SAMSUNG   | UE 55 F 7000   | 33 - 57" |
| 0362 | CLARION   | CD 460 - WX01  | 33 - 57" |
| 0363 | PANASONIC | TXP 55 VT 65 B | 33 - 57" |
| 0363 | PANASONIC | TXP 55 ST 60 B | 33 - 57" |
| 0363 | PANASONIC | TXP 55 VT 50 B | 33 - 57" |
| 0363 | PANASONIC | TH 58 PF 20 ER | 33 - 57" |
| 0363 | PANASONIC | TXP 55 VT 30 B | 33 - 57" |
| 0364 | SAMSUNG   | UE 40 C 5100   | 33 - 57" |
| 0364 | SAMSUNG   | UE 46 B 7020   | 33 - 57" |
| 0364 | SAMSUNG   | UE 40 B 7020   | 33 - 57" |
| 0364 | SAMSUNG   | 46 B 6000      | 33 - 57" |
| 0364 | SAMSUNG   | UE 40 B 8000   | 33 - 57" |
| 0364 | SAMSUNG   | UE 40 B 7000   | 33 - 57" |
| 0364 | SAMSUNG   | UE 40 B 6000   | 33 - 57" |
| 0364 | SAMSUNG   | LE 46 C 6530   | 33 - 57" |
| 0364 | SAMSUNG   | DE 46 A        | 33 - 57" |
| 0364 | SAMSUNG   | MD 46 B        | 33 - 57" |
| 0364 | SAMSUNG   | UE 46 D 5000   | 33 - 57" |
| 0364 | SAMSUNG   | ME 46 B        | 33 - 57" |
| 0364 | SAMSUNG   | UE 46 F 5000   | 33 - 57" |
| 0364 | SAMSUNG   | ED 46 C        | 33 - 57" |
| 0364 | SAMSUNG   | DE 46 C        | 33 - 57" |
| 0364 | SAMSUNG   | PE 46 C        | 33 - 57" |
| 0364 | SAMSUNG   | LE 46 C        | 33 - 57" |
| 0364 | SAMSUNG   | ME 46 A        | 33 - 57" |
| 0364 | SAMSUNG   | ME 46 C        | 33 - 57" |
| 0364 | SAMSUNG   | MD 46 C        | 33 - 57" |
| 0364 | SAMSUNG   | UE 46 A        | 33 - 57" |
| 0364 | SAMSUNG   | UE 46 C        | 33 - 57" |
| 0364 | SAMSUNG   | PS 51 F 4900   | 33 - 57" |
| 0364 | SAMSUNG   | 46 ES 6710     | 33 - 57" |
| 0364 | SAMSUNG   | 40 D 6100      | 33 - 57" |
| 0364 | SAMSUNG   | UE 46 F 5500   | 33 - 57" |
| 0364 | SAMSUNG   | UE 46 D 8000   | 33 - 57" |
| 0364 | SAMSUNG   | DB 48 D        | 33 - 57" |
| 0364 | SAMSUNG   | DH 48 D        | 33 - 57" |
| 0364 | SAMSUNG   | DM 48 D        | 33 - 57" |
| 0364 | SAMSUNG   | ED 46 D        | 33 - 57" |
| 0364 | SAMSUNG   | UA 50 HU 7000  | 33 - 57" |
| 0364 | SAMSUNG   | UA 48 H 5100 A | 33 - 57" |
| 0364 | SAMSUNG   | UA 48 H 5500 A | 33 - 57" |
| 0364 | SAMSUNG   | UA 48 H 6400 A | 33 - 57" |
| 0364 | SAMSUNG   | UA 46 H 7000 A | 33 - 57" |

|      |         |                 |          |
|------|---------|-----------------|----------|
| 0364 | SAMSUNG | PA 51 H 5000 A  | 33 - 57" |
| 0364 | SAMSUNG | UA 48 H 6300 A  | 33 - 57" |
| 0364 | SAMSUNG | PA 51 H 4500 A  | 33 - 57" |
| 0364 | SAMSUNG | PA 43 H 4500 A  | 33 - 57" |
| 0364 | SAMSUNG | PA 43 H 4000 A  | 33 - 57" |
| 0364 | SAMSUNG | PS 51 F 5500 A  | 33 - 57" |
| 0364 | SAMSUNG | UE 48 H 6400    | 33 - 57" |
| 0364 | SAMSUNG | UE 50 H 6400    | 33 - 57" |
| 0364 | SAMSUNG | DM 48 E         | 33 - 57" |
| 0364 | SAMSUNG | HG 48 ED 670 CK | 33 - 57" |
| 0364 | SAMSUNG | DE 55 A         | 33 - 57" |
| 0364 | SAMSUNG | ME 55 A         | 33 - 57" |
| 0364 | SAMSUNG | MD 55 B         | 33 - 57" |
| 0364 | SAMSUNG | ME 55 B         | 33 - 57" |
| 0364 | SAMSUNG | DE 55 C         | 33 - 57" |
| 0364 | SAMSUNG | LE 55 C         | 33 - 57" |
| 0364 | SAMSUNG | PE 55 C         | 33 - 57" |
| 0364 | SAMSUNG | ME 55 C         | 33 - 57" |
| 0364 | SAMSUNG | MD 55 C         | 33 - 57" |
| 0364 | SAMSUNG | UE 55 A         | 33 - 57" |
| 0364 | SAMSUNG | UE 55 C         | 33 - 57" |
| 0364 | SAMSUNG | ED 55 C         | 33 - 57" |
| 0364 | SAMSUNG | DH 55 D         | 33 - 57" |
| 0364 | SAMSUNG | DB 55 B         | 33 - 57" |
| 0364 | SAMSUNG | ED 55 D         | 33 - 57" |
| 0364 | SAMSUNG | UE 55 D 8000    | 33 - 57" |
| 0364 | SAMSUNG | UE 55 H 6400    | 33 - 57" |
| 0364 | SAMSUNG | DB 55 E         | 33 - 57" |
| 0364 | SAMSUNG | 550 EX          | 33 - 57" |

|      |     |           |          |
|------|-----|-----------|----------|
| 0365 | NEC | P 401     | 33 - 57" |
| 0365 | NEC | M 401     | 33 - 57" |
| 0365 | NEC | P 402     | 33 - 57" |
| 0365 | NEC | X 401 S   | 33 - 57" |
| 0365 | NEC | V 423     | 33 - 57" |
| 0365 | NEC | P 403     | 33 - 57" |
| 0365 | NEC | P 403 DST | 33 - 57" |
| 0365 | NEC | P 461     | 33 - 57" |
| 0365 | NEC | M 461 AV  | 33 - 57" |
| 0365 | NEC | X 461 UN  | 33 - 57" |
| 0365 | NEC | P 462     | 33 - 57" |
| 0365 | NEC | X 461 H   | 33 - 57" |
| 0365 | NEC | X 551 S   | 33 - 57" |
| 0365 | NEC | X 462 S   | 33 - 57" |
| 0365 | NEC | X 462 HB  | 33 - 57" |
| 0365 | NEC | X 462 UN  | 33 - 57" |
| 0365 | NEC | X 463 UN  | 33 - 57" |
| 0365 | NEC | P 463     | 33 - 57" |
| 0365 | NEC | P 463 DST | 33 - 57" |
| 0365 | NEC | X 464 UN  | 33 - 57" |
| 0365 | NEC | X 464 UNV | 33 - 57" |
| 0365 | NEC | X 474 HB  | 33 - 57" |
| 0365 | NEC | P 404     | 33 - 57" |

|      |            |                  |          |
|------|------------|------------------|----------|
| 0365 | NEC        | V 484            | 33 - 57" |
| 0365 | NEC        | V 552            | 33 - 57" |
| 0365 | NEC        | X 552 S          | 33 - 57" |
| 0365 | NEC        | P 553            | 33 - 57" |
| 0365 | NEC        | P 554            | 33 - 57" |
| 0366 | BUSH       | FHD 52785        | 33 - 57" |
| 0367 | SAMPO      | PME 50 XP 12 P   | 33 - 57" |
| 0368 | NEC        | X 431 BT         | 33 - 57" |
| 0369 | SHARP      | PNU 423          | 33 - 57" |
| 0369 | JVC        | LT 42 DV 1 BJ    | 33 - 57" |
| 0369 | JVC        | LT 42 WX 70      | 33 - 57" |
| 0369 | SHARP      | PNU 473          | 33 - 57" |
| 0369 | SHARP      | PNU 553          | 33 - 57" |
| 0370 | LG         | 47 LK 355        | 33 - 57" |
| 0370 | LG         | 47 LN 549 C      | 33 - 57" |
| 0370 | LG         | 50 LN 575        | 33 - 57" |
| 0370 | LG         | 42 PA 4500       | 33 - 57" |
| 0370 | LG         | 47 LN 540 V      | 33 - 57" |
| 0370 | LG         | 42 LS 570 T      | 33 - 57" |
| 0370 | LG         | 49 UB 850 V      | 33 - 57" |
| 0370 | LG         | 47 LB 730 V      | 33 - 57" |
| 0370 | LG         | 50 LB 650 V      | 33 - 57" |
| 0370 | LG         | 47 LB 650 V      | 33 - 57" |
| 0370 | LG         | 42 LB 650 V      | 33 - 57" |
| 0370 | LG         | 47 LB 630 V      | 33 - 57" |
| 0370 | LG         | 50 LB 580 V      | 33 - 57" |
| 0370 | LG         | 47 LB 580 V      | 33 - 57" |
| 0370 | LG         | 50 LB 561 V      | 33 - 57" |
| 0370 | LG         | 47 LB 561 V      | 33 - 57" |
| 0370 | LG         | 50 PB 690 V      | 33 - 57" |
| 0370 | LG         | 47 LB 700 V      | 33 - 57" |
| 0370 | LG         | 47 LB 585 V      | 33 - 57" |
| 0370 | TELEFUNKEN | D 50 F 275 N 3 C | 33 - 57" |
| 0370 | LG         | 55 LE 5300       | 33 - 57" |
| 0370 | LG         | 55 LW 450 U      | 33 - 57" |
| 0370 | LG         | 55 LW 451        | 33 - 57" |
| 0370 | LG         | 55 LM 660 T      | 33 - 57" |
| 0370 | LG         | 55 LW 650 T      | 33 - 57" |
| 0370 | LG         | 55 LW 550 T      | 33 - 57" |
| 0370 | LG         | 55 UB 950 V      | 33 - 57" |
| 0370 | LG         | 55 UB 850 V      | 33 - 57" |
| 0370 | LG         | 55 LB 730 V      | 33 - 57" |
| 0370 | LG         | 55 LB 650 V      | 33 - 57" |
| 0370 | LG         | 55 LB 630 V      | 33 - 57" |
| 0370 | LG         | 55 LB 580 V      | 33 - 57" |
| 0370 | LG         | 55 LB 561 V      | 33 - 57" |
| 0370 | LG         | 55 LB 700 V      | 33 - 57" |
| 0370 | LG         | 55 LA 965 W      | 33 - 57" |

|      |              |                |          |
|------|--------------|----------------|----------|
| 0370 | LG           | 55 LB 731 V    | 33 - 57" |
| 0370 | LG           | 60 UF 695 V    | 33 - 57" |
| 0370 | SHARP        | 52 LE 700      | 33 - 57" |
| 0370 | SHARP        | LC 52 LE 831 E | 33 - 57" |
| 0370 | SHARP        | LC 50 LD 266 K | 33 - 57" |
| 0370 | SHARP        | LC 50 LE 761 K | 33 - 57" |
| 0370 | SHARP        | LC 52 LE 700 E | 33 - 57" |
| 0370 | SHARP        | PNQ 701 K      | 33 - 57" |
| 0371 | AQUALITE     | AQLS 52        | 33 - 57" |
| 0372 | PACER        | W 42 L 100     | 33 - 57" |
| 0373 | SONY         | KDL 55 EX 503  | 33 - 57" |
| 0374 | JVC          | GMF 470        | 33 - 57" |
| 0374 | LG           | 55 WS 10       | 33 - 57" |
| 0374 | JVC          | GMF 420 S      | 33 - 57" |
| 0375 | PHILIPS      | 46 PFL 7605    | 33 - 57" |
| 0377 | GENEE WORLD  | GT 55          | 33 - 57" |
| 0378 | CLEVER TOUCH | GT 52 MCP      | 33 - 57" |
| 0379 | CELLO        | L 40227 DVB    | 33 - 57" |
| 0379 | TOSHIBA      | 32 BV 700      | 33 - 57" |
| 0380 | NEC          | V 462          | 33 - 57" |
| 0380 | NEC          | V 422          | 33 - 57" |
| 0380 | NEC          | V 463          | 33 - 57" |
| 0380 | NEC          | V 554          | 33 - 57" |
| 0382 | AQUALITE     | AQLS 32        | 33 - 57" |
| 0383 | LG           | 47 LT 360      | 33 - 57" |
| 0386 | GOODMANS     | LD 3261 HDFVT  | 33 - 57" |
| 0386 | GOODMANS     | LD 3265 D      | 33 - 57" |
| 0386 | WHARFEDALE   | LCD 32 HDM 1   | 33 - 57" |
| 0386 | DMTECH       | LT 42 DT       | 33 - 57" |
| 0388 | MIRAI        | DTL 642 E 500  | 33 - 57" |
| 0388 | MIRAI        | DTL 742 E 600  | 33 - 57" |
| 0388 | PANASONIC    | TXL 32 V 10 B  | 33 - 57" |
| 0388 | PANASONIC    | TXL 37 V 10 B  | 33 - 57" |
| 0389 | SAMSUNG      | SM 400 EX      | 33 - 57" |
| 0389 | SAMSUNG      | 400 EXN        | 33 - 57" |
| 0391 | PHILIPS      | 52 PFL 5605 H  | 33 - 57" |
| 0395 | CTOUCH       | 46             | 33 - 57" |

|      |            |                 |          |
|------|------------|-----------------|----------|
| 0395 | SMARTBOARD | IWB 8055 I      | 33 - 57" |
| 0398 | PHILIPS    | BDL 5231        | 33 - 57" |
| 0398 | PHILIPS    | BDL 5545 E      | 33 - 57" |
| 0398 | CISCO      | 55"             | 33 - 57" |
| 0398 | mitsubishi | MDT 521 S       | 33 - 57" |
| 0398 | mitsubishi | MDT 552 S       | 33 - 57" |
| 0398 | mitsubishi | MDT 551 S       | 33 - 57" |
| 0398 | mitsubishi | LDT 551 V       | 33 - 57" |
| 0399 | SHARP      | PNE 802         | 71 - 90" |
| 0399 | SHARP      | PNL 802 B       | 71 - 90" |
| 0400 | SAMSUNG    | VESA 200X200 M8 | 33 - 57" |
| 0400 | SAMSUNG    | ME 32 B         | 33 - 57" |
| 0400 | SAMSUNG    | DE 40 A         | 33 - 57" |
| 0400 | SAMSUNG    | DE 40 C         | 33 - 57" |
| 0400 | SAMSUNG    | PE 40 C         | 33 - 57" |
| 0400 | SAMSUNG    | LE 32 C         | 33 - 57" |
| 0400 | SAMSUNG    | ME 40 A         | 33 - 57" |
| 0400 | SAMSUNG    | ME 40 B         | 33 - 57" |
| 0400 | SAMSUNG    | ME 32 C         | 33 - 57" |
| 0400 | SAMSUNG    | ME 40 C         | 33 - 57" |
| 0400 | SAMSUNG    | 32 ES 6710      | 33 - 57" |
| 0400 | SAMSUNG    | UE 40 D 8000    | 33 - 57" |
| 0400 | SAMSUNG    | 32 D 4000       | 33 - 57" |
| 0400 | SAMSUNG    | 37 D 6530       | 33 - 57" |
| 0400 | SAMSUNG    | UE 32 F 5070    | 33 - 57" |
| 0400 | SAMSUNG    | UE 32 ES 6300   | 33 - 57" |
| 0400 | SAMSUNG    | 32 EH 5000      | 33 - 57" |
| 0400 | SAMSUNG    | 37 ES 6710      | 33 - 57" |
| 0400 | SAMSUNG    | UE 42 F 5000    | 33 - 57" |
| 0400 | SAMSUNG    | DB 32 D         | 33 - 57" |
| 0400 | SAMSUNG    | DH 40 D         | 33 - 57" |
| 0400 | SAMSUNG    | DM 32 D         | 33 - 57" |
| 0400 | SAMSUNG    | DM 40 D         | 33 - 57" |
| 0400 | SAMSUNG    | UA 40 H 4200    | 33 - 57" |
| 0400 | SAMSUNG    | UA 40 HU 7000   | 33 - 57" |
| 0400 | SAMSUNG    | UA 32 H 5400 A  | 33 - 57" |
| 0400 | SAMSUNG    | UA 40 H 6400 A  | 33 - 57" |
| 0400 | SAMSUNG    | UA 40 H 6300 A  | 33 - 57" |
| 0400 | SAMSUNG    | UA 40 H 5500 A  | 33 - 57" |
| 0400 | SAMSUNG    | UA 32 H 5100 A  | 33 - 57" |
| 0400 | SAMSUNG    | UA 32 H 4100 A  | 33 - 57" |
| 0400 | SAMSUNG    | UA 40 H 5100 A  | 33 - 57" |
| 0400 | SAMSUNG    | UE 40 F 7000    | 33 - 57" |
| 0400 | SAMSUNG    | UE 32 H 6400    | 33 - 57" |
| 0400 | SAMSUNG    | UE 40 H 6400    | 33 - 57" |
| 0400 | SAMSUNG    | DM 32 E         | 33 - 57" |
| 0401 | SHARP      | LC 80 LE 646    | 71 - 90" |
| 0401 | SHARP      | LC 90 LE 757 K  | 71 - 90" |
| 0401 | TOSHIBA    | 84 L 9363       | 71 - 90" |

|      |              |               |           |
|------|--------------|---------------|-----------|
| 0402 | SONY         | KDL 40 EX 521 | 33 - 57"  |
| 0403 | U-TOUCH      | CSLCD 70      | 71 - 90"  |
| 0404 | SAMSUNG      | ED 32 C       | 33 - 57"  |
| 0404 | LG           | 37 LN 549 C   | 33 - 57"  |
| 0404 | LG           | 43 UW 761 H   | 33 - 57"  |
| 0404 | SAMSUNG      | SMT 4031      | 33 - 57"  |
| 0404 | LG           | 42 LT 360     | 33 - 57"  |
| 0404 | LG           | 42 WL 10 MS   | 33 - 57"  |
| 0404 | LG           | 42 WL 30      | 33 - 57"  |
| 0404 | PANASONIC    | TH 48 LFE 8   | 33 - 57"  |
| 0404 | LG           | 43 LW 340 C   | 33 - 57"  |
| 0404 | LG           | 43 LV 340 C   | 33 - 57"  |
| 0404 | PANASONIC    | TH 43 LFE 8   | 33 - 57"  |
| 0404 | TOSHIBA      | 48 U 7653 DB  | 33 - 57"  |
| 0405 | LG           | 72 LM 905 V   | 71 - 90"  |
| 0405 | LG           | 84 LM 960 V   | 71 - 90"  |
| 0405 | LG           | 84 WS 70      | 71 - 90"  |
| 0405 | LG           | 84 UB 980 V   | 71 - 90"  |
| 0405 | LG           | 79 UB 980 V   | 71 - 90"  |
| 0405 | LG           | 84 WT 70      | 71 - 90"  |
| 0406 | KOGAN        | KULED 551 HD  | 33 - 57"  |
| 0408 | NEC          | V 801         | 71 - 90"  |
| 0408 | NEC          | P 801         | 71 - 90"  |
| 0408 | NEC          | X 841 UHD     | 71 - 90"  |
| 0408 | NEC          | E 805         | 71 - 90"  |
| 0408 | NEC          | E 905         | 71 - 90"  |
| 0408 | NEC          | V 754 Q       | 71 - 90"  |
| 0408 | SAMSUNG      | ME 75         | 71 - 90"  |
| 0408 | SAMSUNG      | ME 75 C       | 71 - 90"  |
| 0408 | SAMSUNG      | ED 75 C       | 71 - 90"  |
| 0408 | SAMSUNG      | 75 ES 9000    | 71 - 90"  |
| 0408 | SAMSUNG      | ED 75 D       | 71 - 90"  |
| 0408 | SAMSUNG      | DM 75 D       | 71 - 90"  |
| 0408 | SAMSUNG      | UE 75 F 6470  | 71 - 90"  |
| 0408 | SAMSUNG      | UE 75 H 6400  | 71 - 90"  |
| 0408 | NEC          | X 981 UHD     | 91 - 108" |
| 0409 | SAHARA       | SV 46         | 33 - 57"  |
| 0409 | SAHARA       | SV 55         | 33 - 57"  |
| 0409 | SAHARA       | SV 47         | 33 - 57"  |
| 0409 | SAHARA       | SV 40 B       | 33 - 57"  |
| 0410 | PANASONIC    | TH 80 LF 50   | 71 - 90"  |
| 0411 | LG           | 32 WL 30      | 33 - 57"  |
| 0412 | CLEVER TOUCH | GT 42 MSQ     | 33 - 57"  |



|      |              |                 |           |
|------|--------------|-----------------|-----------|
| 0413 | SHARP        | PNR 903         | 71 - 90"  |
| 0414 | SAMSUNG      | ME 95           | 91 - 108" |
| 0414 | SAMSUNG      | ME 95 C         | 91 - 108" |
| 0415 | PHILIPS      | BDL 4330 QL     | 33 - 57"  |
| 0415 | PHILIPS      | 49 BDL 4050 D   | 33 - 57"  |
| 0415 | HANNSPREE    | SE 40           | 33 - 57"  |
| 0415 | LG           | 47 WS 10        | 33 - 57"  |
| 0415 | LG           | 55 WL 30        | 33 - 57"  |
| 0415 | LG           | 55 LS 33 A      | 33 - 57"  |
| 0415 | LG           | 55 WX 30        | 33 - 57"  |
| 0415 | PHILIPS      | BDL 4671 VL/00  | 33 - 57"  |
| 0415 | PHILIPS      | BDL 4765 EL     | 33 - 57"  |
| 0416 | CTOUCH       | LEDDURA XT 84   | 71 - 90"  |
| 0416 | SAMSUNG      | QM 85 D         | 71 - 90"  |
| 0416 | SAMSUNG      | LH 85 QMD       | 71 - 90"  |
| 0416 | SAMSUNG      | DM 82 E - BR    | 71 - 90"  |
| 0416 | SMARTBOARD   | SB 8084 I G4    | 71 - 90"  |
| 0417 | SONY         | KDL 32 W 653    | 33 - 57"  |
| 0417 | SONY         | KDL 42 W 654 A  | 33 - 57"  |
| 0417 | SONY         | KDL 50 W 685    | 33 - 57"  |
| 0418 | SAMSUNG      | QM 85 F         | 71 - 90"  |
| 0418 | SHARP        | LC 80 LE 657 KN | 71 - 90"  |
| 0418 | SHARP        | LC 80 UQ 10 KN  | 71 - 90"  |
| 0419 | PANASONIC    | TH 50 LFE 6     | 33 - 57"  |
| 0420 | SAMSUNG      | UE 50 F 5070    | 33 - 57"  |
| 0420 | SAMSUNG      | UE 50 F 5700 AW | 33 - 57"  |
| 0421 | CLEVER TOUCH | 84" 1547008     | 71 - 90"  |
| 0422 | PANASONIC    | TX 50 AS 500 B  | 33 - 57"  |
| 0422 | PANASONIC    | TX 50 A 400 B   | 33 - 57"  |
| 0423 | LG           | 42 LB 550       | 33 - 57"  |
| 0423 | LG           | 42 LY 330 C     | 33 - 57"  |
| 0423 | LG           | 42 LF 580 V     | 33 - 57"  |
| 0424 | LG           | 47 LY 330 C     | 33 - 57"  |
| 0424 | LG           | 47 WS 50        | 33 - 57"  |
| 0424 | LG           | 50 LF 5610      | 33 - 57"  |
| 0424 | PANASONIC    | TH 49 LF 80 W   | 33 - 57"  |
| 0424 | PHILIPS      | BDL 4830 QL     | 33 - 57"  |
| 0424 | TOSHIBA      | TDZ 551         | 33 - 57"  |
| 0425 | PENTA        | PD 32 W         | 33 - 57"  |
| 0426 | SAMSUNG      | UE 40 H 6700    | 33 - 57"  |

|      |              |                 |          |
|------|--------------|-----------------|----------|
| 0426 | SAMSUNG      | UE 40 H 5500    | 33 - 57" |
| 0428 | SAMSUNG      | UE 32 F 4500    | 33 - 57" |
| 0429 | SAMSUNG      | DB 40 D         | 33 - 57" |
| 0429 | SAMSUNG      | DB 40 E         | 33 - 57" |
| 0430 | CELLO        | C 50238 - V2    | 33 - 57" |
| 0431 | NEOVO        | RX 32           | 33 - 57" |
| 0431 | DYNASCAN     | DS 421 LT 4     | 33 - 57" |
| 0431 | PHILIPS      | 55 BDL 3050 Q   | 33 - 57" |
| 0431 | IYAMA        | TH 4664 MIS     | 33 - 57" |
| 0431 | IYAMA        | TH 4264 MIS     | 33 - 57" |
| 0432 | SONY         | KDL 42 7 SERIES | 33 - 57" |
| 0432 | SONY         | KDL 50 W 829 B  | 33 - 57" |
| 0433 | LG           | 55 LY 330 C     | 33 - 57" |
| 0433 | LG           | 55 LF 580 V     | 33 - 57" |
| 0434 | NEC          | E 464           | 33 - 57" |
| 0434 | NEC          | E 554           | 33 - 57" |
| 0434 | NEC          | E 585           | 33 - 57" |
| 0434 | PHILIPS      | BDL 5520 QL     | 33 - 57" |
| 0435 | CELLO        | C 50238 V3      | 33 - 57" |
| 0436 | SAMSUNG      | DM 55 D         | 33 - 57" |
| 0436 | SAMSUNG      | QM 49 R         | 33 - 57" |
| 0436 | SMARTBOARD   | 8055I G5        | 33 - 57" |
| 0437 | PANASONIC    | TH 84 LQ 70     | 71 - 90" |
| 0438 | SAMSUNG      | OM 75 D         | 71 - 90" |
| 0439 | LG           | 47 LV 35 A      | 33 - 57" |
| 0439 | LG           | 55 LV 35 A      | 33 - 57" |
| 0440 | CLEVER TOUCH | PLUS 84"        | 71 - 90" |
| 0441 | DYNASCAN     | DS 841 LR 4     | 71 - 90" |
| 0442 | SONY         | KDL 32 W 706 B  | 33 - 57" |
| 0443 | LG           | 55 EC 930 V     | 33 - 57" |
| 0444 | SAMSUNG      | RM 48 D         | 33 - 57" |
| 0444 | SAMSUNG      | LH 48D          | 33 - 57" |
| 0446 | LG           | 49 LW 340 C     | 33 - 57" |
| 0446 | LG           | 49 LV 340 C     | 33 - 57" |
| 0446 | LG           | 49 LJ 515 V     | 33 - 57" |

|      |               |                     |           |
|------|---------------|---------------------|-----------|
| 0446 | M & B         | DB 502101 FSM       | 33 - 57"  |
| 0446 | LG            | 55 UH 661 V         | 33 - 57"  |
| 0446 | LG            | 55 UJ 630 V         | 33 - 57"  |
| 0446 | LG            | 55 UH 5 C           | 33 - 57"  |
| 0446 | LG            | 55 LX 341 C         | 33 - 57"  |
| 0446 | LG            | 55 LW 340 C         | 33 - 57"  |
| 0446 | SAMSUNG       | QM 105              | 91 - 108" |
| 0447 | SAMSUNG       | DC 49 J             | 33 - 57"  |
| 0447 | SAMSUNG       | PM 49 H             | 33 - 57"  |
| 0447 | SAMSUNG       | UE 55 J 5100        | 33 - 57"  |
| 0447 | SAMSUNG       | DC 55               | 33 - 57"  |
| 0448 | SONY          | FWL 75 W 855 C      | 71 - 90"  |
| 0448 | SONY          | FW 75 XD 8501       | 71 - 90"  |
| 0448 | SONY          | FW 85 XD 8501       | 71 - 90"  |
| 0448 | SONY          | FW 75 BZ 35 F       | 71 - 90"  |
| 0449 | LG            | 98 LS 95 A          | 91 - 108" |
| 0450 | JVC           | LT 50 C 550         | 33 - 57"  |
| 0451 | GDS           | LITE 80             | 71 - 90"  |
| 0452 | SAMSUNG       | UE 40 J 5100        | 33 - 57"  |
| 0452 | SAMSUNG       | HG 48 EE 470 SK     | 33 - 57"  |
| 0452 | SAMSUNG       | HG 49 EE 470 HK     | 33 - 57"  |
| 0455 | CLEVER VISION | CV 50 AS            | 33 - 57"  |
| 0457 | PRYSM         | CASCADE 85"         | 71 - 90"  |
| 0458 | PANASONIC     | TH 98 LQ 70 W       | 91 - 108" |
| 0459 | ELO           | 5501                | 33 - 57"  |
| 0460 | MICROSOFT     | SURFACE HUB 55      | 33 - 57"  |
| 0460 | PRYSM         | CASCADE 98"         | 91 - 108" |
| 0461 | MICROSOFT     | SURFACE HUB 84 INCH | 71 - 90"  |
| 0462 | DYNASCAN      | DS 72 LT 4          | 71 - 90"  |
| 0463 | PHILIPS       | BDL 8470 EU         | 71 - 90"  |
| 0464 | SAMSUNG       | OH 55 D             | 33 - 57"  |
| 0465 | LG            | 55 EF 950 V         | 33 - 57"  |
| 0466 | BENQ          | ST 550 K            | 33 - 57"  |
| 0467 | BENQ          | TL 550              | 33 - 57"  |

|      |              |                             |          |
|------|--------------|-----------------------------|----------|
| 0468 | SONY         | FWL 55 W 805 C              | 33 - 57" |
| 0469 | BUSH         | DLED 50265                  | 33 - 57" |
| 0469 | SAMSUNG      | SH 37 F                     | 33 - 57" |
| 0470 | DELL         | P 4317 Q                    | 33 - 57" |
| 0471 | LG           | 86 BH 5 C - 150X150 CENTRES | 71 - 90" |
| 0472 | PANASONIC    | TH 42 AF 1 W                | 33 - 57" |
| 0472 | CISCO        | SPARKBOARD 55"              | 33 - 57" |
| 0474 | CISCO        | SPARKBOARD 70"              | 33 - 57" |
| 0475 | SAMSUNG      | OH 46 F                     | 33 - 57" |
| 0476 | CELLO        | 65 ANSMT 4K                 | 33 - 57" |
| 0477 | SONY         | KD 55 XE 7002               | 33 - 57" |
| 0477 | SONY         | FW 55 BZ 35 F               | 33 - 57" |
| 0478 | SAMSUNG      | OH 55 F                     | 33 - 57" |
| 0479 | PANASONIC    | TH 75 EQ 1 W                | 71 - 90" |
| 0480 | CLEVER TOUCH | 15486 PRO E CAP             | 71 - 90" |
| 0481 | SONY         | FW 43 XE 8001               | 33 - 57" |
| 0481 | SONY         | FW 43 BZ 35 F               | 33 - 57" |
| 0482 | SONY         | FW 85 BZ 35 F               | 71 - 90" |
| 0484 | ALLSEE       | OW 43 D                     | 33 - 57" |
| 0485 | SAMSUNG      | UE 49 NU 7100               | 33 - 57" |
| 0485 | SAMSUNG      | UE 43 RU 7400               | 33 - 57" |
| 0485 | SAMSUNG      | QM 43 N                     | 33 - 57" |
| 0486 | MICROSOFT    | HUB 2                       | 33 - 57" |
| 0487 | IYYAMA       | PROLITE TE 8668             | 71 - 90" |
| 0488 | SAMSUNG      | PM 43 H                     | 33 - 57" |
| 0619 | LG           | 32 LY 330 C                 | 33 - 57" |
| 0668 | BENQ         | ST 650                      | 33 - 57" |
| 0681 | SAMSUNG      | UE 55 NU 7021               | 33 - 57" |
| 9000 | LG           | 32 LD 350                   | 15 - 32" |
| 9000 | TOSHIBA      | 32 WL 46                    | 15 - 32" |

|      |           |                |          |
|------|-----------|----------------|----------|
| 9001 | LG        | 26 LT 360 C    | 15 - 32" |
| 9001 | NEC       | EA 244 WMI     | 15 - 32" |
| 9001 | NEC       | E 324          | 15 - 32" |
| 9001 | NEC       | E 324 R        | 15 - 32" |
| 9001 | PANASONIC | TXL 24 C 3 B   | 15 - 32" |
| 9001 | PHILIPS   | 32 PFL 3208 T  | 15 - 32" |
| 9001 | PHILIPS   | 32 PFL 3258 T  | 15 - 32" |
| 9001 | PHILIPS   | 32 PFL 9705 H  | 15 - 32" |
| 9001 | SHARP     | LC 32 LD 166 K | 15 - 32" |
| 9002 | ACER      | AT 3201 W      | 15 - 32" |
| 9002 | HUMAX     | LGB 32 TPVR    | 15 - 32" |
| 9002 | LG        | 32 LC 2        | 15 - 32" |
| 9002 | LG        | 32 LB 1 R      | 15 - 32" |
| 9002 | LG        | 32 LB 1 D      | 15 - 32" |
| 9002 | LG        | 32 LG 5000     | 15 - 32" |
| 9002 | LG        | 32 LG 3000     | 15 - 32" |
| 9002 | LG        | 32 LG 4000     | 15 - 32" |
| 9002 | LG        | 32 LH 3000     | 15 - 32" |
| 9002 | LG        | 32 LH 2000     | 15 - 32" |
| 9002 | LG        | 26 LG 4000     | 15 - 32" |
| 9002 | LG        | 32 LH 201 C    | 15 - 32" |
| 9002 | LG        | 32 LD 450      | 15 - 32" |
| 9002 | LG        | 32 LH 301      | 15 - 32" |
| 9002 | LG        | 26 LD 350      | 15 - 32" |
| 9002 | LG        | 32 LD 320      | 15 - 32" |
| 9002 | LG        | 32 LH 202      | 15 - 32" |
| 9002 | LG        | 32 LK 455      | 15 - 32" |
| 9002 | LG        | 26 LK 355      | 15 - 32" |
| 9002 | LG        | 32 LK 450      | 15 - 32" |
| 9002 | LG        | 26 LK 335 C    | 15 - 32" |
| 9002 | LG        | 32 LN 5400     | 15 - 32" |
| 9002 | LG        | 32 LA 620 V    | 15 - 32" |
| 9002 | LG        | 32 LN 575 V    | 15 - 32" |
| 9002 | LG        | 32 LN 540 V    | 15 - 32" |
| 9002 | LG        | 32 LN 578 V    | 15 - 32" |
| 9002 | LG        | 32 LN 540 U    | 15 - 32" |
| 9002 | LG        | 32 LN 570 U    | 15 - 32" |
| 9002 | LG        | 32 LN 540 B    | 15 - 32" |
| 9002 | NEC       | E 323          | 15 - 32" |
| 9002 | PANASONIC | TX 32 LMD 70   | 15 - 32" |
| 9002 | PANASONIC | TX 32 LXD 7    | 15 - 32" |
| 9002 | PANASONIC | TX 32 LXD 70   | 15 - 32" |
| 9002 | PANASONIC | TX 32 LXD 700  | 15 - 32" |
| 9002 | PANASONIC | TXL 32 XM 6 B  | 15 - 32" |
| 9002 | PANASONIC | TXL 32 B 6 B   | 15 - 32" |
| 9002 | PANASONIC | TH 32 LRU 6 U  | 15 - 32" |
| 9002 | PHILIPS   | 32 PF 5520 D   | 15 - 32" |
| 9002 | PHILIPS   | 32 PF 7520 D   | 15 - 32" |
| 9002 | PHILIPS   | 32 HF 7473     | 15 - 32" |
| 9002 | PHILIPS   | 32 PF 4320     | 15 - 32" |
| 9002 | PHILIPS   | 32 PF 5320     | 15 - 32" |
| 9002 | PHILIPS   | 32 HF 7875     | 15 - 32" |

|      |           |                  |          |
|------|-----------|------------------|----------|
| 9002 | PHILIPS   | 32 PFL 4208 T    | 15 - 32" |
| 9002 | PHILIPS   | 32 PFL 4258 T    | 15 - 32" |
| 9002 | PHILIPS   | 32 HFL 3007 D    | 15 - 32" |
| 9002 | PHILIPS   | 32 PF 9631 D     | 15 - 32" |
| 9002 | PHILIPS   | 32 PF 9531       | 15 - 32" |
| 9002 | SAMSUNG   | LE 32 A 41 BS    | 15 - 32" |
| 9002 | SANYO     | CE 32 LM 3 WPB   | 15 - 32" |
| 9002 | SHARP     | LC 32 LE 351 KBK | 15 - 32" |
| 9002 | SHARP     | LC 32 LE 351 KWH | 15 - 32" |
| 9002 | SHARP     | LC 32 LD 145 K   | 15 - 32" |
| 9002 | SHARP     | LC 32 LD 135 K   | 15 - 32" |
| 9002 | SONY      | KLV 30 HR 3      | 15 - 32" |
| 9002 | TOSHIBA   | 32 D 1333        | 15 - 32" |
| 9002 | TOSHIBA   | 32 L 4353        | 15 - 32" |
| 9002 | TOSHIBA   | 32 L 6353        | 15 - 32" |
| 9002 | TOSHIBA   | 32 W 4333        | 15 - 32" |
| 9002 | TOSHIBA   | 32 W 1333 DB     | 15 - 32" |
| 9002 | TOSHIBA   | 32 W 1333        | 15 - 32" |
| 9002 | TOSHIBA   | 32 L 1353 DB     | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 512        | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 712        | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 504        | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 702        | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 502        | 15 - 32" |
| 9003 | HITACHI   | L 32 HP 01 U     | 15 - 32" |
| 9003 | LG        | 32 VS 10         | 15 - 32" |
| 9003 | LG        | 32 SE 3 KB       | 15 - 32" |
| 9003 | NEC       | V 322            | 15 - 32" |
| 9003 | NEC       | V 323            | 15 - 32" |
| 9003 | PANASONIC | TXL 32 E 6 B     | 15 - 32" |
| 9003 | PHILIPS   | 32 PFL 5008 T    | 15 - 32" |
| 9003 | SAMSUNG   | SM 320 MX 3      | 15 - 32" |
| 9003 | SAMSUNG   | MD 32 C          | 15 - 32" |
| 9003 | SAMSUNG   | LE 32 D 400 E    | 15 - 32" |
| 9003 | TOSHIBA   | 32 BV 801        | 15 - 32" |
| 9003 | VIEWSONIC | CD 3200          | 15 - 32" |
| 9003 | TOSHIBA   | 40 BV 705        | 33 - 57" |
| 9003 | LG        | M 3203           | 33 - 57" |
| 9003 | LG        | 42 LN 549 C      | 33 - 57" |
| 9003 | NEC       | E 423            | 33 - 57" |
| 9003 | NEC       | E 424            | 33 - 57" |
| 9003 | PANASONIC | TXL 42 DT 65 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 42 FT 60 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 42 ET 60 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 42 E 6 B     | 33 - 57" |
| 9003 | PANASONIC | TXL 39 E 6 B     | 33 - 57" |
| 9003 | PANASONIC | TXL 39 EM 6 B    | 33 - 57" |
| 9003 | PANASONIC | TXL 42 B 6 B     | 33 - 57" |
| 9003 | PANASONIC | TXL 39 B 6 B     | 33 - 57" |
| 9003 | PANASONIC | TXL 42 ET 5 B    | 33 - 57" |
| 9003 | PANASONIC | TH 42 LF 5 E     | 33 - 57" |
| 9003 | PANASONIC | TXL 42 ET 50 B   | 33 - 57" |

|      |           |                  |          |
|------|-----------|------------------|----------|
| 9003 | PANASONIC | TH 42 LF 20 E    | 33 - 57" |
| 9003 | PANASONIC | TH 42 LF 25 U    | 33 - 57" |
| 9003 | PANASONIC | TH 42 LF 30 U    | 33 - 57" |
| 9003 | PANASONIC | TH 42 LRU 60 U   | 33 - 57" |
| 9003 | PHILIPS   | 37 PFL 5604      | 33 - 57" |
| 9003 | PHILIPS   | 32 PFL 5605      | 33 - 57" |
| 9003 | PHILIPS   | 40 PFL 3208 T    | 33 - 57" |
| 9003 | PHILIPS   | 39 PFL 3208 T    | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 3208 T    | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 5008 T    | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 6188 S    | 33 - 57" |
| 9003 | PHILIPS   | 39 PFL 4208 T    | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 4208 T    | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 7008 S    | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 6008 S    | 33 - 57" |
| 9003 | PHILIPS   | 40 PFL 9705 H    | 33 - 57" |
| 9003 | PHILIPS   | 32 PFL 9604 H    | 33 - 57" |
| 9003 | PHILIPS   | 37 PFL 9604 H    | 33 - 57" |
| 9003 | PHILIPS   | 32 PFL 9613 D    | 33 - 57" |
| 9003 | PHILIPS   | 37 PFL 9603 D    | 33 - 57" |
| 9003 | PHILIPS   | 32 PFL 9603 D    | 33 - 57" |
| 9003 | PHILIPS   | 32 PFL 9632 D    | 33 - 57" |
| 9003 | SAMSUNG   | 37 D 550         | 33 - 57" |
| 9003 | SAMSUNG   | 400 BX           | 33 - 57" |
| 9003 | SHARP     | LC 37 GA 3       | 33 - 57" |
| 9003 | SHARP     | LC 40 LE 811     | 33 - 57" |
| 9003 | SHARP     | LC 39 LE 751 K   | 33 - 57" |
| 9003 | SHARP     | LC 39 LE 651 K   | 33 - 57" |
| 9003 | SHARP     | LC 39 LE 351 KBK | 33 - 57" |
| 9003 | SHARP     | LC 39 LE 351 KWH | 33 - 57" |
| 9003 | SHARP     | LC 39 LD 145 K   | 33 - 57" |
| 9003 | SHARP     | LC 39 LE 351 K   | 33 - 57" |
| 9003 | LG        | 42 PJ 650        | 33 - 57" |
| 9003 | LG        | 47 LD 950        | 33 - 57" |
| 9003 | LG        | 50 PJ 550        | 33 - 57" |
| 9003 | PANASONIC | TH LRG 20 B      | 33 - 57" |
| 9003 | PANASONIC | TXP 42 S 20 B    | 33 - 57" |
| 9003 | PANASONIC | TXL 47 WT 65 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 50 DT 65 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 47 DT 65 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 47 FT 60 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 50 ET 60 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 47 ET 60 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 50 E 6 B     | 33 - 57" |
| 9003 | PANASONIC | TXL 50 EM 6 B    | 33 - 57" |
| 9003 | PANASONIC | TXL 50 B 6 B     | 33 - 57" |
| 9003 | PANASONIC | TXL 47 E 5 B     | 33 - 57" |
| 9003 | PANASONIC | TH 47 LFP 30 W   | 33 - 57" |
| 9003 | PANASONIC | TXL 42 U 5 B     | 33 - 57" |
| 9003 | PANASONIC | TXL 47 ET 5 B    | 33 - 57" |
| 9003 | PANASONIC | TXL 50 EM 5 B    | 33 - 57" |
| 9003 | PANASONIC | TH 47 LF 20 E    | 33 - 57" |
| 9003 | PANASONIC | TH 47 LF 30      | 33 - 57" |

|      |           |                |          |
|------|-----------|----------------|----------|
| 9003 | PANASONIC | TXL 42 E 5 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 42 E 3 B   | 33 - 57" |
| 9003 | PANASONIC | TXL 47 ET 50 B | 33 - 57" |
| 9003 | PANASONIC | TH 47 LF 25 ER | 33 - 57" |
| 9003 | PANASONIC | TH 47 LF 25 U  | 33 - 57" |
| 9003 | PANASONIC | TH 47 LF 30 U  | 33 - 57" |
| 9003 | PANASONIC | TH 47 LFT 30 W | 33 - 57" |
| 9003 | PANASONIC | TX 50 AX 802 B | 33 - 57" |
| 9003 | PHILIPS   | 46 PFL 3208 T  | 33 - 57" |
| 9003 | PHILIPS   | 50 PFL 4208 T  | 33 - 57" |
| 9003 | PHILIPS   | 47 PFL 5008 T  | 33 - 57" |
| 9003 | PHILIPS   | 50 PFL 5008 T  | 33 - 57" |
| 9003 | PHILIPS   | 46 PFL 4208 T  | 33 - 57" |
| 9003 | PHILIPS   | 47 PFL 6188 S  | 33 - 57" |
| 9003 | PHILIPS   | 47 PFL 7008 S  | 33 - 57" |
| 9003 | PHILIPS   | 47 PFL 7108 S  | 33 - 57" |
| 9003 | PHILIPS   | 46 PFL 8008 S  | 33 - 57" |
| 9003 | PHILIPS   | 47 PFL 6008 S  | 33 - 57" |
| 9003 | PHILIPS   | BDL 4610 Q     | 33 - 57" |
| 9003 | PHILIPS   | 46 PFL 9707 S  | 33 - 57" |
| 9003 | PHILIPS   | 46 PFL 9707 T  | 33 - 57" |
| 9003 | PHILIPS   | 46 PFL 9706 T  | 33 - 57" |
| 9003 | PHILIPS   | 46 PFL 9705 H  | 33 - 57" |
| 9003 | PHILIPS   | 47 PFL 9664 H  | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 9664 H  | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 9803 H  | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 9603 D  | 33 - 57" |
| 9003 | PHILIPS   | 47 PFL 9603 D  | 33 - 57" |
| 9003 | PHILIPS   | 42 PFL 9703 D  | 33 - 57" |
| 9003 | PHILIPS   | 37 PFL 9632 D  | 33 - 57" |
| 9003 | SAMSUNG   | UN 46 C 7000   | 33 - 57" |
| 9003 | SAMSUNG   | LE 46 C 650    | 33 - 57" |
| 9003 | SAMSUNG   | 46 C 580       | 33 - 57" |
| 9003 | SAMSUNG   | LE 46 C 580    | 33 - 57" |
| 9003 | SAMSUNG   | LE 40 C 652    | 33 - 57" |
| 9003 | SAMSUNG   | 40 C 7000      | 33 - 57" |
| 9003 | SAMSUNG   | UE 46 C 5100   | 33 - 57" |
| 9003 | SAMSUNG   | LE 46 C 750    | 33 - 57" |
| 9003 | SAMSUNG   | LE 40 D 550    | 33 - 57" |
| 9003 | SHARP     | PNE 421        | 33 - 57" |
| 9003 | LG        | 55 LE 8900     | 33 - 57" |
| 9003 | LG        | 50 PK 590      | 33 - 57" |
| 9003 | NEC       | E 553          | 33 - 57" |
| 9003 | PANASONIC | TXL 55 WT 65 B | 33 - 57" |
| 9003 | PANASONIC | TXL 55 DT 65 B | 33 - 57" |
| 9003 | PANASONIC | TXL 55 ET 60 B | 33 - 57" |
| 9003 | PANASONIC | TXL 55 ET 5 B  | 33 - 57" |
| 9003 | PANASONIC | TH 55 LfV 5 U  | 33 - 57" |
| 9003 | PHILIPS   | 55 PDL 8908 S  | 33 - 57" |
| 9003 | PHILIPS   | 55 PFL 7008 S  | 33 - 57" |
| 9003 | PHILIPS   | 55 PFL 7108 S  | 33 - 57" |
| 9003 | PHILIPS   | 55 PFL 8008 S  | 33 - 57" |
| 9003 | PHILIPS   | 55 PFL 6008 S  | 33 - 57" |



|      |         |                  |          |
|------|---------|------------------|----------|
| 9003 | PHILIPS | 55 PFL 6188 S    | 33 - 57" |
| 9003 | PHILIPS | 52 PFL 9606 T    | 33 - 57" |
| 9003 | SAMSUNG | PS 50 B 530      | 33 - 57" |
| 9003 | SAMSUNG | TXP 50 G 20      | 33 - 57" |
| 9003 | SONY    | KDL 55 EX 500    | 33 - 57" |
| 9004 | A+K     | EPM 6000         | 33 - 57" |
| 9004 | CONRAC  | 6030 CD          | 33 - 57" |
| 9004 | LG      | FLATRON M 3700 C | 33 - 57" |
| 9004 | LG      | M 3701 C         | 33 - 57" |
| 9004 | LG      | 37 LC 2 D        | 33 - 57" |
| 9004 | LG      | 37 LC 55         | 33 - 57" |
| 9004 | LG      | 37 LT 75         | 33 - 57" |
| 9004 | LG      | M 3702 C         | 33 - 57" |
| 9004 | LG      | M 3703           | 33 - 57" |
| 9004 | LG      | 42 VS 20         | 33 - 57" |
| 9004 | PHILIPS | 37 PFL 5522 D/05 | 33 - 57" |
| 9004 | PHILIPS | 40 PFL 9704 H    | 33 - 57" |
| 9004 | SHARP   | 37 XD 1 E        | 33 - 57" |
| 9004 | BARCO   | LC 47            | 33 - 57" |
| 9004 | LG      | 42 LC 2 D        | 33 - 57" |
| 9004 | LG      | 42 LF 66         | 33 - 57" |
| 9004 | LG      | 42 LF 65         | 33 - 57" |
| 9004 | LG      | 42 PC 55         | 33 - 57" |
| 9004 | LG      | 42 LC 55         | 33 - 57" |
| 9004 | LG      | 42 PT 85         | 33 - 57" |
| 9004 | LG      | 42 LF 75         | 33 - 57" |
| 9004 | LG      | 42 PC 5 D        | 33 - 57" |
| 9004 | LG      | 42 LB 1 DB       | 33 - 57" |
| 9004 | LG      | M 4212 CBA       | 33 - 57" |
| 9004 | LG      | M 4210 G         | 33 - 57" |
| 9004 | LG      | M 4213 C         | 33 - 57" |
| 9004 | LG      | M 4224 CBA       | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 5522      | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 5532 D    | 33 - 57" |
| 9004 | PHILIPS | 46 PFL 9704 H    | 33 - 57" |
| 9004 | PHILIPS | 47 PFL 9632 D    | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 9900 D    | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 9732 D    | 33 - 57" |
| 9004 | PHILIPS | 47 PFL 9732 D    | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 9632 D    | 33 - 57" |
| 9004 | SAMSUNG | 400 PNS          | 33 - 57" |
| 9004 | SAMSUNG | 400 P            | 33 - 57" |
| 9004 | SAMSUNG | SM 400 PXN       | 33 - 57" |
| 9004 | SAMSUNG | 460 P            | 33 - 57" |
| 9004 | SAMSUNG | PPM 42 M 5 SS    | 33 - 57" |
| 9004 | SAMSUNG | LE 46 F 71 B     | 33 - 57" |
| 9004 | SAMSUNG | PPM 42 M 7 HS    | 33 - 57" |
| 9004 | SAMSUNG | SM 460 DXN       | 33 - 57" |
| 9004 | SAMSUNG | LE 46 A 656 A 1  | 33 - 57" |
| 9004 | SAMSUNG | LE 46 A 559 P 4  | 33 - 57" |
| 9004 | SAMSUNG | SM 400 MXN       | 33 - 57" |
| 9004 | SAMSUNG | 400 CXN          | 33 - 57" |

|      |         |                     |          |
|------|---------|---------------------|----------|
| 9004 | SAMSUNG | PS 42 M 5           | 33 - 57" |
| 9004 | SAMSUNG | PS 42 M 6           | 33 - 57" |
| 9004 | SAMSUNG | PS 42 M 7           | 33 - 57" |
| 9004 | SAMSUNG | PS 42 P 5           | 33 - 57" |
| 9004 | SAMSUNG | PS 42 S 5           | 33 - 57" |
| 9004 | SAMSUNG | PPM 42 M 6          | 33 - 57" |
| 9004 | SAMSUNG | PS 42 C 91 HX       | 33 - 57" |
| 9004 | SAMSUNG | PS 42 C 96 HDX      | 33 - 57" |
| 9004 | SAMSUNG | SPDN 42 KLP         | 33 - 57" |
| 9004 | SAMSUNG | PS 42 Q 97 HD       | 33 - 57" |
| 9004 | SAMSUNG | LH 40 MG FLBS / 2 A | 33 - 57" |
| 9004 | SAMSUNG | SM 400 MX 2         | 33 - 57" |
| 9004 | SAMSUNG | SM 400 CXN 2        | 33 - 57" |
| 9004 | SAMSUNG | PS 42 V 6 S         | 33 - 57" |
| 9004 | SAMSUNG | LE 46 S 86 BDX      | 33 - 57" |
| 9004 | SAMSUNG | LE 46 N 73 BD       | 33 - 57" |
| 9004 | SAMSUNG | LE 46 F 86          | 33 - 57" |
| 9004 | SAMSUNG | LE 46 A 559         | 33 - 57" |
| 9004 | SAMSUNG | PS 42 Q 7 HD        | 33 - 57" |
| 9004 | SAMSUNG | 400 UXN             | 33 - 57" |
| 9004 | SAMSUNG | PS 42 E 7           | 33 - 57" |
| 9004 | SAMSUNG | SM 460 UXN          | 33 - 57" |
| 9004 | SAMSUNG | SM 460 MX 2         | 33 - 57" |
| 9004 | SAMSUNG | P 42 H 2            | 33 - 57" |
| 9004 | SAMSUNG | LE 46 M 53 BD       | 33 - 57" |
| 9004 | SAMSUNG | LH 40 MG QLBC       | 33 - 57" |
| 9004 | SAMSUNG | SM 400 MX 3         | 33 - 57" |
| 9004 | SAMSUNG | 400 DX 3            | 33 - 57" |
| 9004 | TOSHIBA | 42 WP 56 P          | 33 - 57" |
| 9004 | LG      | 50 PC 5 D           | 33 - 57" |
| 9004 | PHILIPS | 50 FD 9631 D        | 33 - 57" |
| 9004 | PHILIPS | 52 PFL 9703 D       | 33 - 57" |
| 9004 | PHILIPS | 52 PFL 9632 D       | 33 - 57" |
| 9004 | SAMSUNG | P 50 H              | 33 - 57" |
| 9004 | SAMSUNG | PPM 50 H 5 HS       | 33 - 57" |
| 9004 | SAMSUNG | PPM 50 M 5 HS       | 33 - 57" |
| 9004 | SAMSUNG | PS 50 Q 7 HD        | 33 - 57" |
| 9004 | SAMSUNG | PS 50 Q 97 HDX      | 33 - 57" |
| 9004 | SAMSUNG | PS 50 P 5 H         | 33 - 57" |
| 9004 | SAMSUNG | PPM 50 M 7          | 33 - 57" |
| 9004 | SAMSUNG | P 50 FP             | 33 - 57" |
| 9004 | SAMSUNG | P 50 HP             | 33 - 57" |
| 9004 | SAMSUNG | PS 50 C 96          | 33 - 57" |
| 9004 | SAMSUNG | UD 55 A             | 33 - 57" |
| 9005 | LG      | M 4715 C            | 33 - 57" |
| 9005 | LG      | M 4712              | 33 - 57" |
| 9005 | LG      | M 4714              | 33 - 57" |
| 9005 | LG      | M 4710 C            | 33 - 57" |
| 9005 | LG      | 4716 CCBA           | 33 - 57" |
| 9005 | PHILIPS | 42 PF 9731 D        | 33 - 57" |
| 9005 | PHILIPS | 42 PF 9831 D        | 33 - 57" |

During our 55+ years of manufacturing, we've produced dedicated/universal mounts for thousands of screens and are always continuing to develop our mounts to suit more and more manufacturers. Whilst we keep this as up-to-date as we can, we know that some screens may be missing - if this is the case, please email sales@unicol.com or enter the product details when ordering online.

|                |                 |           |              |             |
|----------------|-----------------|-----------|--------------|-------------|
| A+K            | CONRAC          | GOODMANS  | MITSUBISHI   | SAVILLE AV  |
| ACER           | CTOUCH          | GRUNDIG   | NAKAMICHI    | SCEPTRE     |
| ALLSEE         | DAEWOO          | HANNSPREE | NEC          | SHARP       |
| AQUALITE       | DELL            | HANTAREX  | NEOVIA       | SMARTBOARD  |
| AQUIVO         | DELPHI          | HISENSE   | NEOVO        | SONY        |
| ARCHER         | DEMCO           | HITACHI   | ORION        | STARMEDIA   |
| ARTICO         | DGM             | HUMAX     | OTRON        | TATUNG      |
| ATEC           | DIBOSS          | HYUNDAI   | PACER        | TECHWOOD    |
| AXIUM          | DIGITAL         | IYAMA     | PACKARD BELL | TELEFUNKEN  |
| BANG & OLUFSEN | DMTECH          | INFINITE  | PANASONIC    | TEW         |
| BARCO          | DYNASCAN        | INFOCUS   | PENTA        | THOMSON     |
| BEKO           | EIKI            | JVC       | PHILIPS      | TINY        |
| BENQ           | EIZO            | KOGAN     | PIONEER      | TOSHIBA     |
| BUSH           | ELO             | LG        | PRESTIGIO    | TVS         |
| CELLO          | ELONEX          | LOEWE     | PROMETHEAN   | UNIVERSAL   |
| CHRISTIE       | FIMI            | M & B     | PRYSM        | U-TOUCH     |
| CHUNGWA        | FLATDISPLAYS    | MANHATTAN | RELISYS      | VIEWSONIC   |
| CISCO          | FRONTNICHE      | MARANTZ   | REVOX        | VISION      |
| CLARION        | FUJIMARO        | MAXENT    | SAGEM        | VUTRIX      |
| CLARITY        | FUJITSU         | MEDION    | SAHARA       | WHARFEDAILE |
| CLEVER TOUCH   | FUJITSU SIEMENS | MICROSOFT | SAMPO        |             |
| CLEVER VISION  | GDS             | MIRAI     | SAMSUNG      |             |
| COLLEVO        | GENEE WORLD     | MITAC     | SANYO        |             |

Prefer to look for which universal/dedicated mount best suits your screen via it's UNICOL Group Code?

Click on the button below to be taken to the Group Code part of this PDF!

[SEARCH VIA GROUP CODE](#)

|      |                |                   |          |
|------|----------------|-------------------|----------|
| 0146 | A+K            | EPM 5000          | 33 - 57" |
| 9004 | A+K            | EPM 6000          | 33 - 57" |
| 0245 | ACER           | AT 3202           | 33 - 57" |
| 9002 | ACER           | AT 3201 W         | 15 - 32" |
| 0484 | ALLSEE         | OW 43 D           | 33 - 57" |
| 0371 | AQUALITE       | AQLS 52           | 33 - 57" |
| 0382 | AQUALITE       | AQLS 32           | 33 - 57" |
| 0349 | AQUIVO         | AQWP 42 R         | 33 - 57" |
| 0354 | AQUIVO         | AQWP 32 R         | 33 - 57" |
| 0156 | ARCHER         | T 42 V 2 T        | 33 - 57" |
| 0084 | ARTICO         | HP 4200           | 33 - 57" |
| 0241 | ATEC           | AV 420 W          | 33 - 57" |
| 0313 | AXIUM          | HDL 32            | 15 - 32" |
| 0255 | BANG & OLUFSEN | BEOVISION 732 880 | 33 - 57" |
| 0293 | BANG & OLUFSEN | BV 740            | 33 - 57" |
| 0119 | BARCO          | SOLARIS LC 40     | 33 - 57" |
| 0119 | BARCO          | LCD 40            | 33 - 57" |
| 0217 | BARCO          | LC 42             | 33 - 57" |
| 0338 | BARCO          | LC 5621           | 33 - 57" |
| 9004 | BARCO          | LC 47             | 33 - 57" |
| 0200 | BEKO           | TV 42 FHGER       | 33 - 57" |
| 0065 | BENQ           | 46 W 1            | 33 - 57" |
| 0466 | BENQ           | ST 550 K          | 33 - 57" |
| 0467 | BENQ           | TL 550            | 33 - 57" |
| 0668 | BENQ           | ST 650            | 33 - 57" |
| 0366 | BUSH           | FHD 52785         | 33 - 57" |
| 0469 | BUSH           | DLED 50265        | 33 - 57" |
| 0000 | CELLO          | C 28227           | 15 - 32" |
| 0379 | CELLO          | L 40227 DVB       | 33 - 57" |
| 0430 | CELLO          | C 50238 - V2      | 33 - 57" |
| 0435 | CELLO          | C 50238 V3        | 33 - 57" |
| 0476 | CELLO          | 65 ANSMT 4K       | 33 - 57" |
| 0111 | CHRISTIE       | FP 40             | 33 - 57" |
| 0111 | CHRISTIE       | 38 FP 0001 01     | 33 - 57" |
| 0111 | CHRISTIE       | 38 FP 0001 02     | 33 - 57" |
| 0065 | CHUNGWA        | CLD PD 4610       | 33 - 57" |
| 0065 | CHUNGWA        | PD 4610           | 33 - 57" |

|      |               |                  |          |
|------|---------------|------------------|----------|
| 0065 | CHUNGWA       | PD 46 WV 1       | 33 - 57" |
| 0065 | CHUNGWA       | CPT PD 46 WV 1   | 33 - 57" |
| 0196 | CISCO         | CCD 100 PRO 40 N | 33 - 57" |
| 0237 | CISCO         | 32"              | 33 - 57" |
| 0292 | CISCO         | PRO 52           | 33 - 57" |
| 0337 | CISCO         | LCD-110L-PRO-42  | 33 - 57" |
| 0398 | CISCO         | 55"              | 33 - 57" |
| 0472 | CISCO         | SPARKBOARD 55"   | 33 - 57" |
| 0474 | CISCO         | SPARKBOARD 70"   | 33 - 57" |
| 0362 | CLARION       | CD 460 - WX01    | 33 - 57" |
| 0025 | CLARITY       | SN 4210 P        | 33 - 57" |
| 0137 | CLARITY       | SN 4035 WX       | 33 - 57" |
| 0203 | CLARITY       | BOBCAT XSN 4045  | 33 - 57" |
| 0342 | CLEVER TOUCH  | 52 MDT 1000      | 33 - 57" |
| 0343 | CLEVER TOUCH  | 42 MDT 1000      | 33 - 57" |
| 0378 | CLEVER TOUCH  | GT 52 MCP        | 33 - 57" |
| 0412 | CLEVER TOUCH  | GT 42 MSQ        | 33 - 57" |
| 0421 | CLEVER TOUCH  | 84" 1547008      | 71 - 90" |
| 0440 | CLEVER TOUCH  | PLUS 84"         | 71 - 90" |
| 0480 | CLEVER TOUCH  | 15486 PRO E CAP  | 71 - 90" |
| 0455 | CLEVER VISION | CV 50 AS         | 33 - 57" |
| 0343 | COLLEVO       | 42 MDT 1         | 33 - 57" |
| 0022 | CONRAC        | 4142 WP          | 33 - 57" |
| 0024 | CONRAC        | 4042 42 WP       | 33 - 57" |
| 0070 | CONRAC        | 4042 42          | 33 - 57" |
| 0083 | CONRAC        | 4042 42 PD 003   | 33 - 57" |
| 0162 | CONRAC        | 6040 PD GEB 7    | 33 - 57" |
| 0162 | CONRAC        | 6040 PD 002 010  | 33 - 57" |
| 0188 | CONRAC        | 6030 PD GEB 7    | 33 - 57" |
| 0234 | CONRAC        | 6032 PD          | 33 - 57" |
| 0234 | CONRAC        | 6032 PD 005 025  | 33 - 57" |
| 0239 | CONRAC        | 6946 PD 002 001  | 33 - 57" |
| 9004 | CONRAC        | 6030 CD          | 33 - 57" |
| 0395 | CTOUCH        | 46               | 33 - 57" |
| 0416 | CTOUCH        | LEDDURA XT 84    | 71 - 90" |
| 0034 | DAEWOO        | DSP 4210 GM      | 33 - 57" |
| 0034 | DAEWOO        | DT 4280 NH       | 33 - 57" |
| 0244 | DAEWOO        | DLP 37 D 1       | 33 - 57" |
| 0280 | DAEWOO        | DLP 42 C 1       | 33 - 57" |
| 0216 | DELL          | W 3202 MC        | 33 - 57" |
| 0216 | DELL          | W 3706 MC        | 33 - 57" |
| 0470 | DELL          | P 4317 Q         | 33 - 57" |

|      |              |                 |          |
|------|--------------|-----------------|----------|
| 0003 | DELPHI       | PRO 42          | 33 - 57" |
| 0003 | DELPHI       | PRO MARK 2      | 33 - 57" |
| 0035 | DELPHI       | DIRECT 42       | 33 - 57" |
| 0296 | DEMCO        | SMP 420 APZ     | 33 - 57" |
| 0350 | DGM          | LTV 3203 HT     | 33 - 57" |
| 0102 | DIBOSS       | LT 32 HLP       | 15 - 32" |
| 0206 | DIBOSS       | LT 26 HLF       | 33 - 57" |
| 0014 | DIGITAL      | DEVISE DPD 4210 | 33 - 57" |
| 0199 | DMTECH       | DML 4132 WD     | 33 - 57" |
| 0199 | DMTECH       | LM 32 DT        | 33 - 57" |
| 0277 | DMTECH       | LQ 37 XTY       | 33 - 57" |
| 0277 | DMTECH       | DML 4137 XTY    | 33 - 57" |
| 0277 | DMTECH       | LM 37 DT        | 33 - 57" |
| 0386 | DMTECH       | LT 42 DT        | 33 - 57" |
| 0317 | DYNASCAN     | DS 55 LT 4      | 33 - 57" |
| 0431 | DYNASCAN     | DS 421 LT 4     | 33 - 57" |
| 0441 | DYNASCAN     | DS 841 LR 4     | 71 - 90" |
| 0462 | DYNASCAN     | DS 72 LT 4      | 71 - 90" |
| 0001 | EIKI         | PLD 42 UE       | 33 - 57" |
| 0023 | EIKI         | PV 4210 AT      | 33 - 57" |
| 0063 | EIKI         | PLD 32 UE       | 33 - 57" |
| 0031 | EIZO         | P 5071          | 33 - 57" |
| 0459 | ELO          | 5501            | 33 - 57" |
| 0311 | ELONEX       | LNX GAZ 50 A    | 33 - 57" |
| 0208 | FIMI         | 42 LCDTS        | 33 - 57" |
| 0037 | FLATDISPLAYS | MPD 5020 A      | 33 - 57" |
| 0065 | FLATDISPLAYS | FD 46 PW 1      | 33 - 57" |
| 0086 | FRONTNICHE   | 40              | 33 - 57" |
| 0084 | FUJIMARO     | 42 X 5          | 33 - 57" |
| 0085 | FUJIMARO     | 50 X 5          | 33 - 57" |
| 0001 | FUJITSU      | PDS 4203        | 33 - 57" |
| 0001 | FUJITSU      | PDS 4207        | 33 - 57" |
| 0001 | FUJITSU      | HTM 42          | 33 - 57" |
| 0001 | FUJITSU      | PDS 4201        | 33 - 57" |
| 0001 | FUJITSU      | PDS 4204        | 33 - 57" |
| 0001 | FUJITSU      | PDS 4202        | 33 - 57" |
| 0002 | FUJITSU      | PDS 4212        | 33 - 57" |
| 0002 | FUJITSU      | PDS 4221        | 33 - 57" |

|      |                 |                   |          |
|------|-----------------|-------------------|----------|
| 0002 | FUJITSU         | PDS 4211          | 33 - 57" |
| 0002 | FUJITSU         | PDS 4222          | 33 - 57" |
| 0002 | FUJITSU         | PDS 4208          | 33 - 57" |
| 0002 | FUJITSU         | PDS 4213          | 33 - 57" |
| 0002 | FUJITSU         | PDS 4229          | 33 - 57" |
| 0002 | FUJITSU         | PDS 4242          | 33 - 57" |
| 0002 | FUJITSU         | PDS 4234          | 33 - 57" |
| 0002 | FUJITSU         | PDS 4233          | 33 - 57" |
| 0002 | FUJITSU         | PDS 42 TRS        | 33 - 57" |
| 0002 | FUJITSU         | PDS 4241          | 33 - 57" |
| 0002 | FUJITSU         | PDS 4214 ES       | 33 - 57" |
| 0004 | FUJITSU         | PDF 2174          | 33 - 57" |
| 0004 | FUJITSU         | PDF 2130          | 33 - 57" |
| 0012 | FUJITSU         | PDS 5001 E        | 33 - 57" |
| 0012 | FUJITSU         | P 50 XCA 11 EH    | 33 - 57" |
| 0012 | FUJITSU         | P 50 X 11 A 10 ES | 33 - 57" |
| 0075 | FUJITSU         | P 42 HCA 11 EH    | 33 - 57" |
| 0075 | FUJITSU         | P 42 HHA 10 EF    | 33 - 57" |
| 0075 | FUJITSU         | P 42 VCA 11 EH    | 33 - 57" |
| 0075 | FUJITSU         | P 42 VCA 21 EH    | 33 - 57" |
| 0075 | FUJITSU         | P 42 VHA 20 ES    | 33 - 57" |
| 0075 | FUJITSU         | P 42 VCA 30 EH    | 33 - 57" |
| 0075 | FUJITSU         | P 42 HHA 3 ES     | 33 - 57" |
| 0075 | FUJITSU         | P 42 HHA 30 ES    | 33 - 57" |
| 0075 | FUJITSU         | P 42 VHA 51 ES    | 33 - 57" |
| 0075 | FUJITSU         | P 42 HCA 40       | 33 - 57" |
| 0075 | FUJITSU         | P 42 HHA 40       | 33 - 57" |
| 0075 | FUJITSU         | P 42 XHA 58       | 33 - 57" |
| 0075 | FUJITSU         | P 42 HCA 51       | 33 - 57" |
| 0075 | FUJITSU         | P 42 HCA 30 EH    | 33 - 57" |
| 0075 | FUJITSU         | P 42 VHA 40 ES    | 33 - 57" |
| 0100 | FUJITSU         | P 50 XTA 40 ES    | 33 - 57" |
| 0100 | FUJITSU         | P 50 XTS 51       | 33 - 57" |
| 0100 | FUJITSU         | P 50 XTA 51       | 33 - 57" |
| 0100 | FUJITSU         | P 50 XCA 30 EH    | 33 - 57" |
| 0100 | FUJITSU         | 50 XHA 30         | 33 - 57" |
| 0100 | FUJITSU         | P 50 XHA 40       | 33 - 57" |
| 0100 | FUJITSU         | P 50 XHA 10       | 33 - 57" |
| 0100 | FUJITSU         | P 50 XCA 40       | 33 - 57" |
| 0100 | FUJITSU         | P 50 XCA 51       | 33 - 57" |
| 0175 | FUJITSU         | P 55 XHA 30 ES    | 33 - 57" |
| 0175 | FUJITSU         | P 55 XTS 51 RS    | 33 - 57" |
| 0175 | FUJITSU         | P 55 XHA 55       | 33 - 57" |
| 0067 | FUJITSU SIEMENS | MYRICA P 422 H    | 33 - 57" |
| 0067 | FUJITSU SIEMENS | MYRICA P 422      | 33 - 57" |
| 0067 | FUJITSU SIEMENS | MYRICA V 401      | 33 - 57" |
| 0067 | FUJITSU SIEMENS | P 502             | 33 - 57" |
| 0252 | FUJITSU SIEMENS | V 301             | 33 - 57" |
| 0253 | FUJITSU SIEMENS | PDP TV PQ 421     | 33 - 57" |
| 0187 | GDS             | G 320             | 33 - 57" |
| 0187 | GDS             | G 370             | 33 - 57" |

|      |             |                   |          |
|------|-------------|-------------------|----------|
| 0451 | GDS         | LITE 80           | 71 - 90" |
| 0377 | GENEE WORLD | GT 55             | 33 - 57" |
| 0155 | GOODMANS    | GTV 50 P          | 33 - 57" |
| 0177 | GOODMANS    | LD 3201           | 33 - 57" |
| 0386 | GOODMANS    | LD 3261 HDFVT     | 33 - 57" |
| 0386 | GOODMANS    | LD 3265 D         | 33 - 57" |
| 0309 | GRUNDIG     | GV 32 DVD         | 33 - 57" |
| 0415 | HANNSPREE   | SE 40             | 33 - 57" |
| 0003 | HANTAREX    | PDP 42 QV         | 33 - 57" |
| 0003 | HANTAREX    | PDP 42 UX GA      | 33 - 57" |
| 0003 | HANTAREX    | P 42 UX GA MARK 3 | 33 - 57" |
| 0068 | HANTAREX    | PD 42 SRL         | 33 - 57" |
| 0068 | HANTAREX    | PD 40 SRL         | 33 - 57" |
| 0109 | HANTAREX    | FPD TFT 40        | 33 - 57" |
| 0118 | HANTAREX    | PD 42 XPTVZ       | 33 - 57" |
| 0000 | HISENSE     | LTDN 50 D 36 TUK  | 33 - 57" |
| 0139 | HISENSE     | PDP 4212 EU       | 33 - 57" |
| 0018 | HITACHI     | CMP 307 XE        | 33 - 57" |
| 0019 | HITACHI     | CMP 402 HDE       | 33 - 57" |
| 0019 | HITACHI     | CMP 4120 HDE      | 33 - 57" |
| 0050 | HITACHI     | CL 32 PD 2100     | 33 - 57" |
| 0050 | HITACHI     | CL 32 PD 3000     | 33 - 57" |
| 0051 | HITACHI     | C 37 PD 2100      | 33 - 57" |
| 0052 | HITACHI     | CMP 4121 HDE      | 33 - 57" |
| 0052 | HITACHI     | CL 42 PD 2100     | 33 - 57" |
| 0052 | HITACHI     | 42 PMA 400        | 33 - 57" |
| 0052 | HITACHI     | CMP 4202 W        | 33 - 57" |
| 0069 | HITACHI     | CMP 5000 WXE      | 33 - 57" |
| 0108 | HITACHI     | 42 PD 5300        | 33 - 57" |
| 0108 | HITACHI     | CMP 4214 E        | 33 - 57" |
| 0108 | HITACHI     | 42 PMA 500        | 33 - 57" |
| 0108 | HITACHI     | 42 PD 5200        | 33 - 57" |
| 0108 | HITACHI     | 42 PD 5000        | 33 - 57" |
| 0108 | HITACHI     | 42 PD 5100        | 33 - 57" |
| 0108 | HITACHI     | 42 PD 4200        | 33 - 57" |
| 0108 | HITACHI     | 42 PD 7200        | 33 - 57" |
| 0114 | HITACHI     | 32 PD 5200        | 15 - 32" |
| 0114 | HITACHI     | 32 PD 5100 E      | 15 - 32" |
| 0114 | HITACHI     | 32 PD 5300 E      | 15 - 32" |
| 0114 | HITACHI     | 32 PD 5000        | 15 - 32" |
| 0133 | HITACHI     | 55 PMA 550        | 33 - 57" |
| 0149 | HITACHI     | 28 LD 5200 E      | 15 - 32" |
| 0180 | HITACHI     | 42 PMA 225 EZ     | 33 - 57" |
| 0180 | HITACHI     | 42 PD 3200        | 33 - 57" |
| 0180 | HITACHI     | 42 PD 6600        | 33 - 57" |
| 0180 | HITACHI     | 42 PD 6 A 10      | 33 - 57" |



|      |          |                 |          |
|------|----------|-----------------|----------|
| 0198 | HITACHI  | 32 LD 7200      | 33 - 57" |
| 0213 | HITACHI  | 32 LD 6200      | 33 - 57" |
| 0251 | HITACHI  | 55 PD 9700 U    | 33 - 57" |
| 0271 | HITACHI  | 32 LD 8700      | 33 - 57" |
| 0271 | HITACHI  | 37 LD 8700      | 33 - 57" |
| 0272 | HITACHI  | 42 PD 9700      | 33 - 57" |
| 0291 | HITACHI  | P 50 T 01 U     | 33 - 57" |
| 0309 | HITACHI  | L 37 V 01 U     | 33 - 57" |
| 0345 | HITACHI  | L 42 VC 04 U    | 33 - 57" |
| 9003 | HITACHI  | L 32 HP 01 U    | 15 - 32" |
| 0236 | HUMAX    | 32 PF 9731      | 33 - 57" |
| 0236 | HUMAX    | LGB 40 TPVR     | 33 - 57" |
| 9002 | HUMAX    | LGB 32 TPVR     | 15 - 32" |
| 0067 | HYUNDAI  | HQP 421 SR      | 33 - 57" |
| 0067 | HYUNDAI  | PD 421          | 33 - 57" |
| 0104 | HYUNDAI  | DPD 4240        | 33 - 57" |
| 0104 | HYUNDAI  | HPT 4250        | 33 - 57" |
| 0104 | HYUNDAI  | HPT 4240        | 33 - 57" |
| 0132 | HYUNDAI  | HPT 5040        | 33 - 57" |
| 0179 | HYUNDAI  | HPTN 4200 S     | 33 - 57" |
| 0179 | HYUNDAI  | HPTD 4202 S     | 33 - 57" |
| 0193 | HYUNDAI  | HPTD 4201 S     | 33 - 57" |
| 0000 | IYAMA    | LH 4780         | 33 - 57" |
| 0082 | IYAMA    | PROLITE L 320 W | 33 - 57" |
| 0176 | IYAMA    | PROLITE L 400 W | 33 - 57" |
| 0431 | IYAMA    | TH 4664 MIS     | 33 - 57" |
| 0431 | IYAMA    | TH 4264 MIS     | 33 - 57" |
| 0487 | IYAMA    | PROLITE TE 8668 | 71 - 90" |
| 0295 | INFINITE | M PDP 4220      | 33 - 57" |
| 0194 | INFOCUS  | TD 40           | 33 - 57" |
| 0001 | JVC      | V 4225 PZW      | 33 - 57" |
| 0001 | JVC      | V 425 PZW       | 33 - 57" |
| 0001 | JVC      | GDV 425 PZW     | 33 - 57" |
| 0012 | JVC      | GVD 500 PZU     | 33 - 57" |
| 0012 | JVC      | GVD 500 PCE     | 33 - 57" |
| 0012 | JVC      | GDV 502 PCE     | 33 - 57" |
| 0017 | JVC      | GDV 4200 PZW    | 33 - 57" |
| 0017 | JVC      | GDV 4210 PCE    | 33 - 57" |
| 0026 | JVC      | GMX 50 E        | 33 - 57" |
| 0078 | JVC      | GMP 420 PCE     | 33 - 57" |
| 0078 | JVC      | GMP 421 PCE     | 33 - 57" |
| 0078 | JVC      | GMV 42 PCEB     | 33 - 57" |
| 0095 | JVC      | VM 35 D 30 ES   | 33 - 57" |
| 0101 | JVC      | LT 32 C 31 BJE  | 15 - 32" |
| 0101 | JVC      | 26 C 31 BJE     | 15 - 32" |
| 0101 | JVC      | LT 32 C 50 BJ   | 15 - 32" |
| 0101 | JVC      | LT 32 D 50      | 15 - 32" |

|      |       |                  |          |
|------|-------|------------------|----------|
| 0134 | JVC   | VM 42 WX 84      | 33 - 57" |
| 0134 | JVC   | PD 35 B 50 BU    | 33 - 57" |
| 0134 | JVC   | PD 42 DX 6 BJ    | 33 - 57" |
| 0134 | JVC   | PD 42 B 50 BU    | 33 - 57" |
| 0134 | JVC   | VM 42 V 31 BUE   | 33 - 57" |
| 0135 | JVC   | VM 42 D 30 ES    | 33 - 57" |
| 0157 | JVC   | LT 32 DX 7       | 33 - 57" |
| 0172 | JVC   | LT 30 E 45 SJ    | 33 - 57" |
| 0229 | JVC   | GMH 40 L 1 G     | 33 - 57" |
| 0229 | JVC   | GMH 40 L 2 G     | 33 - 57" |
| 0279 | JVC   | LT 46 DZ 7 BJ    | 33 - 57" |
| 0279 | JVC   | LT 46 DS 9       | 33 - 57" |
| 0288 | JVC   | GDF 46 L 1       | 33 - 57" |
| 0288 | JVC   | GD 463 D 10 E    | 33 - 57" |
| 0310 | JVC   | GDF 52 L 1       | 33 - 57" |
| 0317 | JVC   | GMF 520 S        | 33 - 57" |
| 0369 | JVC   | LT 42 DV 1 BJ    | 33 - 57" |
| 0369 | JVC   | LT 42 WX 70      | 33 - 57" |
| 0374 | JVC   | GMF 470          | 33 - 57" |
| 0374 | JVC   | GMF 420 S        | 33 - 57" |
| 0450 | JVC   | LT 50 C 550      | 33 - 57" |
| 0406 | KOGAN | KULED 551 HD     | 33 - 57" |
| 0016 | LG    | PD 40 X 2        | 33 - 57" |
| 0045 | LG    | MZ 42 PZ 10      | 33 - 57" |
| 0045 | LG    | MZ 42 PZ 44      | 33 - 57" |
| 0045 | LG    | MZ 42 PM 13      | 33 - 57" |
| 0045 | LG    | 42 PM 3 MVA      | 33 - 57" |
| 0045 | LG    | 42 PC 1 D        | 33 - 57" |
| 0045 | LG    | 42 PZ 17         | 33 - 57" |
| 0045 | LG    | RZ 42 PX 11      | 33 - 57" |
| 0045 | LG    | RZ 42 PY 10 X    | 33 - 57" |
| 0045 | LG    | 42 PX 5 D        | 33 - 57" |
| 0045 | LG    | 42 PX 3 RV       | 33 - 57" |
| 0046 | LG    | MZ 40 PA 10      | 33 - 57" |
| 0072 | LG    | MZ 50 PZ 43      | 33 - 57" |
| 0072 | LG    | 50 PXD 4         | 33 - 57" |
| 0072 | LG    | 50 PM 1 MA       | 33 - 57" |
| 0072 | LG    | RZ 50 PY 10      | 33 - 57" |
| 0072 | LG    | 50 PC 1 D        | 33 - 57" |
| 0080 | LG    | RZ 30 LZ 13      | 33 - 57" |
| 0141 | LG    | L 3000 H         | 15 - 32" |
| 0152 | LG    | RZ 37 LZ 30      | 33 - 57" |
| 0174 | LG    | L 4200 A         | 33 - 57" |
| 0174 | LG    | FLATRON M 4201 C | 33 - 57" |
| 0174 | LG    | L 4200 C         | 33 - 57" |
| 0209 | LG    | M 5500 C         | 33 - 57" |
| 0218 | LG    | 42 LS 3400       | 33 - 57" |
| 0218 | LG    | 42 LS 341        | 33 - 57" |
| 0218 | LG    | RZ 32 LZ 55 H    | 33 - 57" |
| 0218 | LG    | 37 LK 455        | 33 - 57" |
| 0218 | LG    | 42 LM 3400       | 33 - 57" |

|      |    |               |          |
|------|----|---------------|----------|
| 0237 | LG | M 3200 C      | 33 - 57" |
| 0237 | LG | M 3202 C      | 33 - 57" |
| 0237 | LG | L 3200 C      | 33 - 57" |
| 0237 | LG | M 3201 C      | 33 - 57" |
| 0268 | LG | 50 PY 2 R     | 33 - 57" |
| 0278 | LG | 32 LX 2 R     | 33 - 57" |
| 0278 | LG | 32 LC 56      | 33 - 57" |
| 0281 | LG | 42 LT 75      | 33 - 57" |
| 0282 | LG | 42 LG 3000    | 33 - 57" |
| 0282 | LG | 47 LG 5000    | 33 - 57" |
| 0282 | LG | 42 LG 5000    | 33 - 57" |
| 0297 | LG | 50 PC 55      | 33 - 57" |
| 0298 | LG | 42 LM 620 T   | 33 - 57" |
| 0322 | LG | 42 LA 660 V   | 33 - 57" |
| 0322 | LG | 42 LA 860 W   | 33 - 57" |
| 0322 | LG | 42 LA 740 V   | 33 - 57" |
| 0322 | LG | 42 LA 690 V   | 33 - 57" |
| 0322 | LG | 42 LA 641 V   | 33 - 57" |
| 0322 | LG | 42 LA 640 V   | 33 - 57" |
| 0322 | LG | 42 LB 730 V   | 33 - 57" |
| 0322 | LG | 42 LB 630 V   | 33 - 57" |
| 0322 | LG | 42 LB 580 V   | 33 - 57" |
| 0322 | LG | 42 LB 561 V   | 33 - 57" |
| 0322 | LG | 42 LB 5500    | 33 - 57" |
| 0322 | LG | 42 LB 731 V   | 33 - 57" |
| 0322 | LG | 42 LB 700 V   | 33 - 57" |
| 0322 | LG | 42 LB 585 V   | 33 - 57" |
| 0322 | LG | 42 LB 570 V   | 33 - 57" |
| 0322 | LG | PD 42 PG 3000 | 33 - 57" |
| 0322 | LG | 47 LA 620 V   | 33 - 57" |
| 0322 | LG | 50 PH 660 V   | 33 - 57" |
| 0322 | LG | 50 PN 650 T   | 33 - 57" |
| 0322 | LG | 42 PN 450 B   | 33 - 57" |
| 0322 | LG | 47 LA 740 V   | 33 - 57" |
| 0322 | LG | 47 LA 660 V   | 33 - 57" |
| 0322 | LG | 47 LA 860 W   | 33 - 57" |
| 0322 | LG | 50 PH 670 V   | 33 - 57" |
| 0322 | LG | 50 PN 450 B   | 33 - 57" |
| 0322 | LG | 47 LN 575 V   | 33 - 57" |
| 0322 | LG | 50 LA 660 V   | 33 - 57" |
| 0322 | LG | 47 LN 578 V   | 33 - 57" |
| 0322 | LG | 47 LN 570 V   | 33 - 57" |
| 0322 | LG | 50 LA 620 V   | 33 - 57" |
| 0322 | LG | 47 LA 790 W   | 33 - 57" |
| 0322 | LG | 50 LN 540 V   | 33 - 57" |
| 0322 | LG | 47 LA 641 V   | 33 - 57" |
| 0322 | LG | 47 LA 640 V   | 33 - 57" |
| 0322 | LG | 50 LN 578 V   | 33 - 57" |
| 0322 | LG | 47 LN 5400    | 33 - 57" |
| 0322 | LG | 47 LA 613 V   | 33 - 57" |
| 0322 | LG | 47 LN 613 V   | 33 - 57" |
| 0322 | LG | 50 PZ 950 T   | 33 - 57" |
| 0322 | LG | 50 PA 650 T   | 33 - 57" |

|      |    |             |          |
|------|----|-------------|----------|
| 0322 | LG | 47 LM 670 T | 33 - 57" |
| 0322 | LG | 47 LM 620 T | 33 - 57" |
| 0322 | LG | 50 PA 4500  | 33 - 57" |
| 0322 | LG | 47 LM 660 T | 33 - 57" |
| 0322 | LG | 47 LS 5700  | 33 - 57" |
| 0322 | LG | 47 LW 650 T | 33 - 57" |
| 0322 | LG | 47 LV 550 T | 33 - 57" |
| 0322 | LG | 42 LS 5600  | 33 - 57" |
| 0322 | LG | 47 LS 5600  | 33 - 57" |
| 0322 | LG | 47 LW 550 T | 33 - 57" |
| 0322 | LG | 47 WL 10 MS | 33 - 57" |
| 0322 | LG | 50 PB 5600  | 33 - 57" |
| 0322 | LG | 47 LB 731 V | 33 - 57" |
| 0322 | LG | 47 LA 690 V | 33 - 57" |
| 0322 | LG | 55 LA 620 V | 33 - 57" |
| 0322 | LG | 55 LA 690 V | 33 - 57" |
| 0322 | LG | 55 LA 660 V | 33 - 57" |
| 0322 | LG | 55 LA 860 W | 33 - 57" |
| 0322 | LG | 55 LA 740 V | 33 - 57" |
| 0322 | LG | 55 LA 790 W | 33 - 57" |
| 0322 | LG | 55 LN 575 V | 33 - 57" |
| 0322 | LG | 55 LA 640 V | 33 - 57" |
| 0322 | LG | 55 LA 641 V | 33 - 57" |
| 0322 | LG | 50 PG 6000  | 33 - 57" |
| 0324 | LG | 50 PG 3000  | 33 - 57" |
| 0325 | LG | M 5520 C    | 33 - 57" |
| 0325 | LG | M 4716 CC   | 33 - 57" |
| 0325 | LG | 47 VS 10    | 33 - 57" |
| 0325 | LG | 55 VS 20    | 33 - 57" |
| 0325 | LG | 47 VX 30 AF | 33 - 57" |
| 0325 | LG | 47 WV 30    | 33 - 57" |
| 0325 | LG | 47 VL 10    | 33 - 57" |
| 0325 | LG | 47 VS 20    | 33 - 57" |
| 0326 | LG | M 5201      | 33 - 57" |
| 0326 | LG | 52 LG 5000  | 33 - 57" |
| 0332 | LG | 32 LT 360 C | 33 - 57" |
| 0332 | LG | 32 LN 549 C | 33 - 57" |
| 0337 | LG | M 4225      | 33 - 57" |
| 0337 | LG | M 4214      | 33 - 57" |
| 0337 | LG | 42 VS 10    | 33 - 57" |
| 0341 | LG | 32 LS 570 T | 33 - 57" |
| 0341 | LG | 32 LB 580 V | 33 - 57" |
| 0341 | LG | 32 LB 561 V | 33 - 57" |
| 0341 | LG | 32 LB 5500  | 33 - 57" |
| 0341 | LG | 32 LB 550 U | 33 - 57" |
| 0341 | LG | 32 LB 550 B | 33 - 57" |
| 0341 | LG | 32 LB 585 V | 33 - 57" |
| 0341 | LG | 32 LW 340 C | 33 - 57" |
| 0341 | LG | 37 LH 2000  | 33 - 57" |
| 0341 | LG | 37 LH 4000  | 33 - 57" |
| 0341 | LG | 37 LH 3000  | 33 - 57" |
| 0341 | LG | 37 LD 450   | 33 - 57" |
| 0341 | LG | 37 LH 301   | 33 - 57" |

|      |    |             |          |
|------|----|-------------|----------|
| 0341 | LG | 37 SL 8000  | 33 - 57" |
| 0341 | LG | 42 LN 578 V | 33 - 57" |
| 0341 | LG | 42 LN 540 V | 33 - 57" |
| 0341 | LG | 42 LN 575 V | 33 - 57" |
| 0341 | LG | 42 LN 570 V | 33 - 57" |
| 0341 | LG | 37 LM 620 T | 33 - 57" |
| 0341 | LG | M 3204 C    | 33 - 57" |
| 0341 | LG | 37 LS 570 T | 33 - 57" |
| 0341 | LG | 37 LT 360 C | 33 - 57" |
| 0341 | LG | 32 LB 650 V | 33 - 57" |
| 0341 | LG | 42 LN 543 V | 33 - 57" |
| 0341 | LG | 43 SE 3 KE  | 33 - 57" |
| 0341 | LG | 42 LH 2000  | 33 - 57" |
| 0341 | LG | 42 LH 3000  | 33 - 57" |
| 0341 | LG | 42 SL 9000  | 33 - 57" |
| 0341 | LG | 47 LH 4000  | 33 - 57" |
| 0341 | LG | 42 LH 5000  | 33 - 57" |
| 0341 | LG | 47 LH 3000  | 33 - 57" |
| 0341 | LG | 42 SL 9500  | 33 - 57" |
| 0341 | LG | 42 LH 201   | 33 - 57" |
| 0341 | LG | 47 LD 920   | 33 - 57" |
| 0341 | LG | 47 LD 450   | 33 - 57" |
| 0341 | LG | 42 LD 450   | 33 - 57" |
| 0341 | LG | 42 LD 420   | 33 - 57" |
| 0341 | LG | 47 LD 420 C | 33 - 57" |
| 0341 | LG | 42 LK 450   | 33 - 57" |
| 0341 | LG | 42 LK 455   | 33 - 57" |
| 0341 | LG | 42 LH 301   | 33 - 57" |
| 0341 | LG | 42 LK 530   | 33 - 57" |
| 0341 | LG | 42 CS 460   | 33 - 57" |
| 0341 | LG | 42 LN 5400  | 33 - 57" |
| 0341 | LG | 42 LA 613 V | 33 - 57" |
| 0341 | LG | 42 LN 613 V | 33 - 57" |
| 0341 | LG | 42 LE 5310  | 33 - 57" |
| 0341 | LG | 37 LG 3000  | 33 - 57" |
| 0341 | LG | 37 LF 2510  | 33 - 57" |
| 0341 | LG | 42 LF 2500  | 33 - 57" |
| 0341 | LG | 37 LF 7700  | 33 - 57" |
| 0341 | LG | 42 LF 7700  | 33 - 57" |
| 0341 | LG | 42 D 490    | 33 - 57" |
| 0341 | LG | 37 LS 5600  | 33 - 57" |
| 0341 | LG | 42 LA 620 V | 33 - 57" |
| 0341 | LG | 42 LN 540   | 33 - 57" |
| 0341 | LG | 43 LX 341 C | 33 - 57" |
| 0341 | LG | 32 LX 330 C | 33 - 57" |
| 0341 | LG | 43 LH 604 V | 33 - 57" |
| 0341 | LG | 40 UF 770 V | 33 - 57" |
| 0341 | LG | 32 LV 340 C | 33 - 57" |
| 0341 | LG | 37 LH 201 C | 33 - 57" |
| 0352 | LG | 42 WS 50    | 33 - 57" |
| 0352 | LG | 42 WS 10    | 33 - 57" |
| 0352 | LG | 42 PM 470 T | 33 - 57" |
| 0352 | LG | 42 PQ 6000  | 33 - 57" |

|      |    |              |          |
|------|----|--------------|----------|
| 0352 | LG | 50 PK 530    | 33 - 57" |
| 0352 | LG | 50 PJ 650    | 33 - 57" |
| 0352 | LG | PD 50 PJ 650 | 33 - 57" |
| 0352 | LG | 50 PT 353 K  | 33 - 57" |
| 0352 | LG | 42 PT 353 K  | 33 - 57" |
| 0352 | LG | 50 PQ 6000   | 33 - 57" |
| 0352 | LG | 55 LM 620    | 33 - 57" |
| 0352 | LG | 55 LM 610    | 33 - 57" |
| 0352 | LG | 42 PQ 3000   | 33 - 57" |
| 0352 | LG | 50 PQ 3000   | 33 - 57" |
| 0352 | LG | 50 PS 3000   | 33 - 57" |
| 0352 | LG | 50 PQ 2000   | 33 - 57" |
| 0352 | LG | 42 PJ 350    | 33 - 57" |
| 0352 | LG | 50 PJ 350    | 33 - 57" |
| 0352 | LG | 47 LV 355 U  | 33 - 57" |
| 0352 | LG | 42 LV 450    | 33 - 57" |
| 0352 | LG | 55 LA 970 W  | 33 - 57" |
| 0355 | LG | 42 LE 5900   | 33 - 57" |
| 0355 | LG | 47 LK 530    | 33 - 57" |
| 0370 | LG | 47 LK 355    | 33 - 57" |
| 0370 | LG | 47 LN 549 C  | 33 - 57" |
| 0370 | LG | 50 LN 575    | 33 - 57" |
| 0370 | LG | 42 PA 4500   | 33 - 57" |
| 0370 | LG | 47 LN 540 V  | 33 - 57" |
| 0370 | LG | 42 LS 570 T  | 33 - 57" |
| 0370 | LG | 49 UB 850 V  | 33 - 57" |
| 0370 | LG | 47 LB 730 V  | 33 - 57" |
| 0370 | LG | 50 LB 650 V  | 33 - 57" |
| 0370 | LG | 47 LB 650 V  | 33 - 57" |
| 0370 | LG | 42 LB 650 V  | 33 - 57" |
| 0370 | LG | 47 LB 630 V  | 33 - 57" |
| 0370 | LG | 50 LB 580 V  | 33 - 57" |
| 0370 | LG | 47 LB 580 V  | 33 - 57" |
| 0370 | LG | 50 LB 561 V  | 33 - 57" |
| 0370 | LG | 47 LB 561 V  | 33 - 57" |
| 0370 | LG | 50 PB 690 V  | 33 - 57" |
| 0370 | LG | 47 LB 700 V  | 33 - 57" |
| 0370 | LG | 47 LB 585 V  | 33 - 57" |
| 0370 | LG | 55 LE 5300   | 33 - 57" |
| 0370 | LG | 55 LW 450 U  | 33 - 57" |
| 0370 | LG | 55 LW 451    | 33 - 57" |
| 0370 | LG | 55 LM 660 T  | 33 - 57" |
| 0370 | LG | 55 LW 650 T  | 33 - 57" |
| 0370 | LG | 55 LW 550 T  | 33 - 57" |
| 0370 | LG | 55 UB 950 V  | 33 - 57" |
| 0370 | LG | 55 UB 850 V  | 33 - 57" |
| 0370 | LG | 55 LB 730 V  | 33 - 57" |
| 0370 | LG | 55 LB 650 V  | 33 - 57" |
| 0370 | LG | 55 LB 630 V  | 33 - 57" |
| 0370 | LG | 55 LB 580 V  | 33 - 57" |
| 0370 | LG | 55 LB 561 V  | 33 - 57" |
| 0370 | LG | 55 LB 700 V  | 33 - 57" |
| 0370 | LG | 55 LA 965 W  | 33 - 57" |

|      |    |                             |           |
|------|----|-----------------------------|-----------|
| 0370 | LG | 55 LB 731 V                 | 33 - 57"  |
| 0370 | LG | 60 UF 695 V                 | 33 - 57"  |
| 0374 | LG | 55 WS 10                    | 33 - 57"  |
| 0383 | LG | 47 LT 360                   | 33 - 57"  |
| 0404 | LG | 37 LN 549 C                 | 33 - 57"  |
| 0404 | LG | 43 UW 761 H                 | 33 - 57"  |
| 0404 | LG | 42 LT 360                   | 33 - 57"  |
| 0404 | LG | 42 WL 10 MS                 | 33 - 57"  |
| 0404 | LG | 42 WL 30                    | 33 - 57"  |
| 0404 | LG | 43 LW 340 C                 | 33 - 57"  |
| 0404 | LG | 43 LV 340 C                 | 33 - 57"  |
| 0405 | LG | 72 LM 905 V                 | 71 - 90"  |
| 0405 | LG | 84 LM 960 V                 | 71 - 90"  |
| 0405 | LG | 84 WS 70                    | 71 - 90"  |
| 0405 | LG | 84 UB 980 V                 | 71 - 90"  |
| 0405 | LG | 79 UB 980 V                 | 71 - 90"  |
| 0405 | LG | 84 WT 70                    | 71 - 90"  |
| 0411 | LG | 32 WL 30                    | 33 - 57"  |
| 0415 | LG | 47 WS 10                    | 33 - 57"  |
| 0415 | LG | 55 WL 30                    | 33 - 57"  |
| 0415 | LG | 55 LS 33 A                  | 33 - 57"  |
| 0415 | LG | 55 WX 30                    | 33 - 57"  |
| 0423 | LG | 42 LB 550                   | 33 - 57"  |
| 0423 | LG | 42 LY 330 C                 | 33 - 57"  |
| 0423 | LG | 42 LF 580 V                 | 33 - 57"  |
| 0424 | LG | 47 LY 330 C                 | 33 - 57"  |
| 0424 | LG | 47 WS 50                    | 33 - 57"  |
| 0424 | LG | 50 LF 5610                  | 33 - 57"  |
| 0433 | LG | 55 LY 330 C                 | 33 - 57"  |
| 0433 | LG | 55 LF 580 V                 | 33 - 57"  |
| 0439 | LG | 47 LV 35 A                  | 33 - 57"  |
| 0439 | LG | 55 LV 35 A                  | 33 - 57"  |
| 0443 | LG | 55 EC 930 V                 | 33 - 57"  |
| 0446 | LG | 49 LW 340 C                 | 33 - 57"  |
| 0446 | LG | 49 LV 340 C                 | 33 - 57"  |
| 0446 | LG | 49 LJ 515 V                 | 33 - 57"  |
| 0446 | LG | 55 UH 661 V                 | 33 - 57"  |
| 0446 | LG | 55 UJ 630 V                 | 33 - 57"  |
| 0446 | LG | 55 UH 5 C                   | 33 - 57"  |
| 0446 | LG | 55 LX 341 C                 | 33 - 57"  |
| 0446 | LG | 55 LW 340 C                 | 33 - 57"  |
| 0449 | LG | 98 LS 95 A                  | 91 - 108" |
| 0465 | LG | 55 EF 950 V                 | 33 - 57"  |
| 0471 | LG | 86 BH 5 C - 150X150 CENTRES | 71 - 90"  |
| 0619 | LG | 32 LY 330 C                 | 33 - 57"  |
| 9000 | LG | 32 LD 350                   | 15 - 32"  |
| 9001 | LG | 26 LT 360 C                 | 15 - 32"  |
| 9002 | LG | 32 LC 2                     | 15 - 32"  |
| 9002 | LG | 32 LB 1 R                   | 15 - 32"  |
| 9002 | LG | 32 LB 1 D                   | 15 - 32"  |
| 9002 | LG | 32 LG 5000                  | 15 - 32"  |
| 9002 | LG | 32 LG 3000                  | 15 - 32"  |
| 9002 | LG | 32 LG 4000                  | 15 - 32"  |

|      |    |                  |          |
|------|----|------------------|----------|
| 9002 | LG | 32 LH 3000       | 15 - 32" |
| 9002 | LG | 32 LH 2000       | 15 - 32" |
| 9002 | LG | 26 LG 4000       | 15 - 32" |
| 9002 | LG | 32 LH 201 C      | 15 - 32" |
| 9002 | LG | 32 LD 450        | 15 - 32" |
| 9002 | LG | 32 LH 301        | 15 - 32" |
| 9002 | LG | 26 LD 350        | 15 - 32" |
| 9002 | LG | 32 LD 320        | 15 - 32" |
| 9002 | LG | 32 LH 202        | 15 - 32" |
| 9002 | LG | 32 LK 455        | 15 - 32" |
| 9002 | LG | 26 LK 355        | 15 - 32" |
| 9002 | LG | 32 LK 450        | 15 - 32" |
| 9002 | LG | 26 LK 335 C      | 15 - 32" |
| 9002 | LG | 32 LN 5400       | 15 - 32" |
| 9002 | LG | 32 LA 620 V      | 15 - 32" |
| 9002 | LG | 32 LN 575 V      | 15 - 32" |
| 9002 | LG | 32 LN 540 V      | 15 - 32" |
| 9002 | LG | 32 LN 578 V      | 15 - 32" |
| 9002 | LG | 32 LN 540 U      | 15 - 32" |
| 9002 | LG | 32 LN 570 U      | 15 - 32" |
| 9002 | LG | 32 LN 540 B      | 15 - 32" |
| 9003 | LG | 32 VS 10         | 15 - 32" |
| 9003 | LG | 32 SE 3 KB       | 15 - 32" |
| 9003 | LG | M 3203           | 33 - 57" |
| 9003 | LG | 42 LN 549 C      | 33 - 57" |
| 9003 | LG | 42 PJ 650        | 33 - 57" |
| 9003 | LG | 47 LD 950        | 33 - 57" |
| 9003 | LG | 50 PJ 550        | 33 - 57" |
| 9003 | LG | 55 LE 8900       | 33 - 57" |
| 9003 | LG | 50 PK 590        | 33 - 57" |
| 9004 | LG | FLATRON M 3700 C | 33 - 57" |
| 9004 | LG | M 3701 C         | 33 - 57" |
| 9004 | LG | 37 LC 2 D        | 33 - 57" |
| 9004 | LG | 37 LC 55         | 33 - 57" |
| 9004 | LG | 37 LT 75         | 33 - 57" |
| 9004 | LG | M 3702 C         | 33 - 57" |
| 9004 | LG | M 3703           | 33 - 57" |
| 9004 | LG | 42 VS 20         | 33 - 57" |
| 9004 | LG | 42 LC 2 D        | 33 - 57" |
| 9004 | LG | 42 LF 66         | 33 - 57" |
| 9004 | LG | 42 LF 65         | 33 - 57" |
| 9004 | LG | 42 PC 55         | 33 - 57" |
| 9004 | LG | 42 LC 55         | 33 - 57" |
| 9004 | LG | 42 PT 85         | 33 - 57" |
| 9004 | LG | 42 LF 75         | 33 - 57" |
| 9004 | LG | 42 PC 5 D        | 33 - 57" |
| 9004 | LG | 42 LB 1 DB       | 33 - 57" |
| 9004 | LG | M 4212 CBA       | 33 - 57" |
| 9004 | LG | M 4210 G         | 33 - 57" |
| 9004 | LG | M 4213 C         | 33 - 57" |
| 9004 | LG | M 4224 CBA       | 33 - 57" |
| 9004 | LG | 50 PC 5 D        | 33 - 57" |
| 9005 | LG | M 4715 C         | 33 - 57" |



|      |            |                     |          |
|------|------------|---------------------|----------|
| 9005 | LG         | M 4712              | 33 - 57" |
| 9005 | LG         | M 4714              | 33 - 57" |
| 9005 | LG         | M 4710 C            | 33 - 57" |
| 9005 | LG         | 4716 CCBA           | 33 - 57" |
| 0093 | LOEWE      | SPHEROS 20          | 15 - 32" |
| 0231 | LOEWE      | INDIVIDUAL 32 S     | 33 - 57" |
| 0446 | M & B      | DB 502101 FSM       | 33 - 57" |
| 0102 | MANHATTAN  | LT 30 FLP           | 15 - 32" |
| 0011 | MARANTZ    | PD 4200 N 1 M       | 33 - 57" |
| 0249 | MARANTZ    | LC 3201 ENIB        | 33 - 57" |
| 0089 | MAXENT     | MX 42 LE 7          | 33 - 57" |
| 0207 | MEDION     | MD 41527            | 33 - 57" |
| 0460 | MICROSOFT  | SURFACE HUB 55      | 33 - 57" |
| 0461 | MICROSOFT  | SURFACE HUB 84 INCH | 71 - 90" |
| 0486 | MICROSOFT  | HUB 2               | 33 - 57" |
| 0200 | MIRAI      | T 3715 C            | 33 - 57" |
| 0218 | MIRAI      | DTL 632 E 500       | 33 - 57" |
| 0304 | MIRAI      | DTL 632 E 600       | 33 - 57" |
| 0388 | MIRAI      | DTL 642 E 500       | 33 - 57" |
| 0388 | MIRAI      | DTL 742 E 600       | 33 - 57" |
| 0067 | MITAC      | PDP 42 H            | 33 - 57" |
| 0073 | MITAC      | HP 5000             | 33 - 57" |
| 0015 | mitsubishi | XP 4015 E           | 33 - 57" |
| 0082 | mitsubishi | LDT 321 U           | 33 - 57" |
| 0082 | mitsubishi | MDT 321 S           | 33 - 57" |
| 0082 | mitsubishi | LDT 321 V           | 33 - 57" |
| 0082 | mitsubishi | LDT 323             | 33 - 57" |
| 0082 | mitsubishi | LDT 371 V           | 33 - 57" |
| 0082 | mitsubishi | LDT 322             | 33 - 57" |
| 0082 | mitsubishi | L 464 G 7           | 33 - 57" |
| 0082 | mitsubishi | MDT 402 S           | 33 - 57" |
| 0082 | mitsubishi | LDT 421 V           | 33 - 57" |
| 0288 | mitsubishi | MDT 421 S           | 33 - 57" |
| 0288 | mitsubishi | LDT 461 V           | 33 - 57" |
| 0288 | mitsubishi | MDT 461 S           | 33 - 57" |
| 0288 | mitsubishi | LDT 422 V 2         | 33 - 57" |
| 0353 | mitsubishi | LDT 521 V           | 33 - 57" |
| 0398 | mitsubishi | MDT 521 S           | 33 - 57" |
| 0398 | mitsubishi | MDT 552 S           | 33 - 57" |
| 0398 | mitsubishi | MDT 551 S           | 33 - 57" |
| 0398 | mitsubishi | LDT 551 V           | 33 - 57" |
| 0066 | NAKAMICHI  | PDP 42              | 33 - 57" |

|      |     |               |          |
|------|-----|---------------|----------|
| 0000 | NEC | X 754 HB      | 71 - 90" |
| 0007 | NEC | LCD 8205      | 71 - 90" |
| 0013 | NEC | PX 33 M 2 G   | 33 - 57" |
| 0013 | NEC | PX 3300       | 33 - 57" |
| 0013 | NEC | PX 33 M 3 G   | 33 - 57" |
| 0026 | NEC | 4200 W        | 33 - 57" |
| 0026 | NEC | 4210 W        | 33 - 57" |
| 0026 | NEC | PX 42 VP 1 G  | 33 - 57" |
| 0026 | NEC | PX 42 M 2 G   | 33 - 57" |
| 0026 | NEC | PX 42 VM 1    | 33 - 57" |
| 0026 | NEC | 4205          | 33 - 57" |
| 0026 | NEC | 42 PD 2       | 33 - 57" |
| 0026 | NEC | PX 42 VM 2 G  | 33 - 57" |
| 0026 | NEC | 42 MP 1       | 33 - 57" |
| 0026 | NEC | PX 42 VP 4 G  | 33 - 57" |
| 0026 | NEC | PX 42 VP 5 HG | 33 - 57" |
| 0026 | NEC | PX 42 XM 4 G  | 33 - 57" |
| 0026 | NEC | PX 42 XM 2 G  | 33 - 57" |
| 0026 | NEC | 42 XR 3       | 33 - 57" |
| 0026 | NEC | PX 42 VM 5    | 33 - 57" |
| 0026 | NEC | 42 MP 3       | 33 - 57" |
| 0026 | NEC | 42 MP 2       | 33 - 57" |
| 0026 | NEC | PX 42 XM 3 G  | 33 - 57" |
| 0026 | NEC | 5000 W        | 33 - 57" |
| 0026 | NEC | 50 PD 1       | 33 - 57" |
| 0026 | NEC | 50 PD 2       | 33 - 57" |
| 0026 | NEC | PX 50 VP 1 G  | 33 - 57" |
| 0026 | NEC | PX 50 XM 3 G  | 33 - 57" |
| 0026 | NEC | 50 MP 2       | 33 - 57" |
| 0082 | NEC | LCD 4215      | 33 - 57" |
| 0125 | NEC | LCD 3000      | 15 - 32" |
| 0226 | NEC | T 1000        | 33 - 57" |
| 0232 | NEC | PX 50 XM 5 G  | 33 - 57" |
| 0232 | NEC | PX 50 XR 5 G  | 33 - 57" |
| 0232 | NEC | 50 XM 6       | 33 - 57" |
| 0262 | NEC | E 321         | 33 - 57" |
| 0263 | NEC | LCD 5710      | 33 - 57" |
| 0288 | NEC | LCD 3210      | 33 - 57" |
| 0288 | NEC | LCD 3215      | 33 - 57" |
| 0288 | NEC | V 321         | 33 - 57" |
| 0288 | NEC | LCD 3220      | 33 - 57" |
| 0288 | NEC | LCD 4010      | 33 - 57" |
| 0288 | NEC | M 40 AV       | 33 - 57" |
| 0288 | NEC | LCD 4610      | 33 - 57" |
| 0288 | NEC | LCD 4620      | 33 - 57" |
| 0288 | NEC | M 46 AV       | 33 - 57" |
| 0288 | NEC | V 461         | 33 - 57" |
| 0288 | NEC | V 421         | 33 - 57" |
| 0288 | NEC | E 505         | 33 - 57" |
| 0288 | NEC | LCD 4000      | 33 - 57" |
| 0302 | NEC | 42 XP 10      | 33 - 57" |
| 0302 | NEC | 50 XP 10      | 33 - 57" |
| 0302 | NEC | 50 XC 10      | 33 - 57" |

|      |     |            |           |
|------|-----|------------|-----------|
| 0317 | NEC | P 551      | 33 - 57"  |
| 0317 | NEC | V 551      | 33 - 57"  |
| 0317 | NEC | X 551 UN   | 33 - 57"  |
| 0317 | NEC | P 552      | 33 - 57"  |
| 0317 | NEC | X 554 UN   | 33 - 57"  |
| 0317 | NEC | X 554 UNS  | 33 - 57"  |
| 0317 | NEC | LCD 5220   | 33 - 57"  |
| 0317 | NEC | P 521      | 33 - 57"  |
| 0365 | NEC | P 401      | 33 - 57"  |
| 0365 | NEC | M 401      | 33 - 57"  |
| 0365 | NEC | P 402      | 33 - 57"  |
| 0365 | NEC | X 401 S    | 33 - 57"  |
| 0365 | NEC | V 423      | 33 - 57"  |
| 0365 | NEC | P 403      | 33 - 57"  |
| 0365 | NEC | P 403 DST  | 33 - 57"  |
| 0365 | NEC | P 461      | 33 - 57"  |
| 0365 | NEC | M 461 AV   | 33 - 57"  |
| 0365 | NEC | X 461 UN   | 33 - 57"  |
| 0365 | NEC | P 462      | 33 - 57"  |
| 0365 | NEC | X 461 H    | 33 - 57"  |
| 0365 | NEC | X 551 S    | 33 - 57"  |
| 0365 | NEC | X 462 S    | 33 - 57"  |
| 0365 | NEC | X 462 HB   | 33 - 57"  |
| 0365 | NEC | X 462 UN   | 33 - 57"  |
| 0365 | NEC | X 463 UN   | 33 - 57"  |
| 0365 | NEC | P 463      | 33 - 57"  |
| 0365 | NEC | P 463 DST  | 33 - 57"  |
| 0365 | NEC | X 464 UN   | 33 - 57"  |
| 0365 | NEC | X 464 UNV  | 33 - 57"  |
| 0365 | NEC | X 474 HB   | 33 - 57"  |
| 0365 | NEC | P 404      | 33 - 57"  |
| 0365 | NEC | V 484      | 33 - 57"  |
| 0365 | NEC | V 552      | 33 - 57"  |
| 0365 | NEC | X 552 S    | 33 - 57"  |
| 0365 | NEC | P 553      | 33 - 57"  |
| 0365 | NEC | P 554      | 33 - 57"  |
| 0368 | NEC | X 431 BT   | 33 - 57"  |
| 0380 | NEC | V 462      | 33 - 57"  |
| 0380 | NEC | V 422      | 33 - 57"  |
| 0380 | NEC | V 463      | 33 - 57"  |
| 0380 | NEC | V 554      | 33 - 57"  |
| 0408 | NEC | V 801      | 71 - 90"  |
| 0408 | NEC | P 801      | 71 - 90"  |
| 0408 | NEC | X 841 UHD  | 71 - 90"  |
| 0408 | NEC | E 805      | 71 - 90"  |
| 0408 | NEC | E 905      | 71 - 90"  |
| 0408 | NEC | V 754 Q    | 71 - 90"  |
| 0408 | NEC | X 981 UHD  | 91 - 108" |
| 0434 | NEC | E 464      | 33 - 57"  |
| 0434 | NEC | E 554      | 33 - 57"  |
| 0434 | NEC | E 585      | 33 - 57"  |
| 9001 | NEC | EA 244 WMI | 15 - 32"  |
| 9001 | NEC | E 324      | 15 - 32"  |

|      |              |                |          |
|------|--------------|----------------|----------|
| 9001 | NEC          | E 324 R        | 15 - 32" |
| 9002 | NEC          | E 323          | 15 - 32" |
| 9003 | NEC          | V 322          | 15 - 32" |
| 9003 | NEC          | V 323          | 15 - 32" |
| 9003 | NEC          | E 423          | 33 - 57" |
| 9003 | NEC          | E 424          | 33 - 57" |
| 9003 | NEC          | E 553          | 33 - 57" |
| 0156 | NEOVIA       | SL 42 VK 10    | 33 - 57" |
| 0431 | NEOVO        | RX 32          | 33 - 57" |
| 0014 | ORION        | PM 4202        | 33 - 57" |
| 0295 | ORION        | 4220           | 33 - 57" |
| 0045 | OTRON        | EPM 420 A      | 33 - 57" |
| 0312 | PACER        | SMP 320 LPZ    | 33 - 57" |
| 0372 | PACER        | W 42 L 100     | 33 - 57" |
| 0102 | PACKARD BELL | 300 SW         | 15 - 32" |
| 0006 | PANASONIC    | TH 85 PF 12 E  | 71 - 90" |
| 0006 | PANASONIC    | TH 85 VX 200 W | 71 - 90" |
| 0012 | PANASONIC    | TC 37 P 1 F    | 33 - 57" |
| 0012 | PANASONIC    | TH 37 PWD 4    | 33 - 57" |
| 0012 | PANASONIC    | TH 37 PWD 5    | 33 - 57" |
| 0012 | PANASONIC    | TH 37 PWD 8    | 33 - 57" |
| 0012 | PANASONIC    | TH 37 PX 80    | 33 - 57" |
| 0012 | PANASONIC    | TH 37 PX 70    | 33 - 57" |
| 0012 | PANASONIC    | TC 42 P 1 F    | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PWD 3 B  | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PWD 4 B  | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PWD 6    | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PW 7 BX  | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PHD 8 BK | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PHD 9 BK | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PR 10    | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PS 9     | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PS 10    | 33 - 57" |
| 0012 | PANASONIC    | TH 42 PD 12    | 33 - 57" |
| 0012 | PANASONIC    | TH 50 PHW 3    | 33 - 57" |
| 0012 | PANASONIC    | TH 50 PWD 5 B  | 33 - 57" |
| 0012 | PANASONIC    | TH 50 PHD 6 BX | 33 - 57" |
| 0012 | PANASONIC    | TH 50 PHD 8 BK | 33 - 57" |
| 0012 | PANASONIC    | TH 50 PH 9 BK  | 33 - 57" |
| 0012 | PANASONIC    | TH 50 PF 10 EK | 33 - 57" |
| 0012 | PANASONIC    | TH 50 PH 10    | 33 - 57" |
| 0012 | PANASONIC    | TH 50 PF 9     | 33 - 57" |
| 0012 | PANASONIC    | TH 50 PH 12 EK | 33 - 57" |
| 0087 | PANASONIC    | TX 22 LT 2     | 15 - 32" |
| 0100 | PANASONIC    | TH 37 PX 8 B   | 33 - 57" |
| 0100 | PANASONIC    | TH 37 PA 20    | 33 - 57" |

|      |           |                |           |
|------|-----------|----------------|-----------|
| 0100 | PANASONIC | TH 37 PX 60    | 33 - 57"  |
| 0100 | PANASONIC | TH 42 PA 20    | 33 - 57"  |
| 0100 | PANASONIC | TH 42 PX 60 B  | 33 - 57"  |
| 0100 | PANASONIC | TH 42 PV 60    | 33 - 57"  |
| 0100 | PANASONIC | TH 42 PV 70    | 33 - 57"  |
| 0100 | PANASONIC | TH 42 PV 80    | 33 - 57"  |
| 0100 | PANASONIC | TH 50 PX 60 B  | 33 - 57"  |
| 0100 | PANASONIC | TH 50 PZ 70    | 33 - 57"  |
| 0100 | PANASONIC | TH 50 PX 70    | 33 - 57"  |
| 0129 | PANASONIC | TH 50 PZ 81    | 33 - 57"  |
| 0129 | PANASONIC | TH 37 PE 30    | 33 - 57"  |
| 0129 | PANASONIC | TH 42 PE 30    | 33 - 57"  |
| 0129 | PANASONIC | TH 50 PV 30    | 33 - 57"  |
| 0129 | PANASONIC | TH 42 PV 500 B | 33 - 57"  |
| 0129 | PANASONIC | TH 50 PX 600   | 33 - 57"  |
| 0129 | PANASONIC | TH 42 PX 600 B | 33 - 57"  |
| 0129 | PANASONIC | TH 50 PZ 700   | 33 - 57"  |
| 0129 | PANASONIC | 50 PX 7        | 33 - 57"  |
| 0129 | PANASONIC | TH 42 PZ 85    | 33 - 57"  |
| 0129 | PANASONIC | TH 37 PV 500   | 33 - 57"  |
| 0129 | PANASONIC | TH 37 PV 600   | 33 - 57"  |
| 0129 | PANASONIC | TH 37 PX 600   | 33 - 57"  |
| 0129 | PANASONIC | TH 37 PA 50    | 33 - 57"  |
| 0129 | PANASONIC | TH 50 PV 600   | 33 - 57"  |
| 0131 | PANASONIC | TX 26 LXD 1    | 15 - 32"  |
| 0131 | PANASONIC | TX 32 LXD 1    | 15 - 32"  |
| 0131 | PANASONIC | TX 32 LXD 50   | 15 - 32"  |
| 0131 | PANASONIC | TX 26 LXD 50   | 15 - 32"  |
| 0157 | PANASONIC | TXL 37 G 20 B  | 33 - 57"  |
| 0185 | PANASONIC | TH 37 PE 50    | 33 - 57"  |
| 0185 | PANASONIC | TH 37 PG 9 B   | 33 - 57"  |
| 0185 | PANASONIC | TH 42 PA 50    | 33 - 57"  |
| 0185 | PANASONIC | TH 42 PG 9 B   | 33 - 57"  |
| 0185 | PANASONIC | TH 42 PX 80    | 33 - 57"  |
| 0185 | PANASONIC | TH 50 PX 706   | 33 - 57"  |
| 0185 | PANASONIC | TH 50 PX 70 BA | 33 - 57"  |
| 0190 | PANASONIC | TH 32 LHD 7 EK | 33 - 57"  |
| 0190 | PANASONIC | TH 32 LHD 7 ES | 33 - 57"  |
| 0233 | PANASONIC | TX 32 LXD 60   | 33 - 57"  |
| 0233 | PANASONIC | BTLH 2600 WE   | 33 - 57"  |
| 0274 | PANASONIC | TH 103 PF 9 EC | 91 - 108" |
| 0274 | PANASONIC | TH 103 PF 12   | 91 - 108" |
| 0322 | PANASONIC | TH 55 LFE 8    | 33 - 57"  |
| 0341 | PANASONIC | TXL 26 X 10 B  | 33 - 57"  |
| 0341 | PANASONIC | TXL 32 ET 5 B  | 33 - 57"  |
| 0341 | PANASONIC | TXL 32 X 5 B   | 33 - 57"  |
| 0341 | PANASONIC | TXL 32 DT 30 B | 33 - 57"  |
| 0341 | PANASONIC | TXL 32 E 3 B   | 33 - 57"  |
| 0341 | PANASONIC | TX 32 S 10     | 33 - 57"  |
| 0341 | PANASONIC | TXL 32 G 10    | 33 - 57"  |
| 0341 | PANASONIC | TXL 37 S 10    | 33 - 57"  |
| 0341 | PANASONIC | TXL 37 E 30    | 33 - 57"  |
| 0341 | PANASONIC | TXL 32 X 15 B  | 33 - 57"  |

|      |           |                |          |
|------|-----------|----------------|----------|
| 0341 | PANASONIC | TXL 37 E 5 B   | 33 - 57" |
| 0341 | PANASONIC | TXL 32 U 3 B   | 33 - 57" |
| 0341 | PANASONIC | TXL 37 ET 5 B  | 33 - 57" |
| 0341 | PANASONIC | TXL 37 DT 30 B | 33 - 57" |
| 0341 | PANASONIC | TXL 32 C 5 B   | 33 - 57" |
| 0341 | PANASONIC | TXL 32 C 3 B   | 33 - 57" |
| 0341 | PANASONIC | TXL 37 E 3 B   | 33 - 57" |
| 0341 | PANASONIC | TXL 32 E 30 B  | 33 - 57" |
| 0341 | PANASONIC | TH 32 LRH 30 U | 33 - 57" |
| 0341 | PANASONIC | TH 32 LRU 5    | 33 - 57" |
| 0341 | PANASONIC | TH 37 LRU 5    | 33 - 57" |
| 0341 | PANASONIC | TXL 42 S 10 B  | 33 - 57" |
| 0341 | PANASONIC | TXL 42 E 30 B  | 33 - 57" |
| 0341 | PANASONIC | TXL 42 D 25 B  | 33 - 57" |
| 0341 | PANASONIC | TH 42 LRU 5    | 33 - 57" |
| 0341 | PANASONIC | TH 42 LFE 7 U  | 33 - 57" |
| 0355 | PANASONIC | TX 37 LZ 80    | 33 - 57" |
| 0357 | PANASONIC | TXP 37 X 10 B  | 33 - 57" |
| 0357 | PANASONIC | TXP 42 G 10    | 33 - 57" |
| 0357 | PANASONIC | TXP 42 S 10    | 33 - 57" |
| 0357 | PANASONIC | TXP 42 X 10 B  | 33 - 57" |
| 0357 | PANASONIC | TH 42 PH 20 E  | 33 - 57" |
| 0357 | PANASONIC | TH 42 PF 30    | 33 - 57" |
| 0357 | PANASONIC | TXP 46 G 10 B  | 33 - 57" |
| 0357 | PANASONIC | TH 42 PF 20 E  | 33 - 57" |
| 0357 | PANASONIC | TXP 50 GT 60 B | 33 - 57" |
| 0357 | PANASONIC | TXP 42 GT 60 B | 33 - 57" |
| 0357 | PANASONIC | TXP 50 ST 50 B | 33 - 57" |
| 0357 | PANASONIC | TXP 42 ST 60 B | 33 - 57" |
| 0357 | PANASONIC | TXP 50 X 60 B  | 33 - 57" |
| 0357 | PANASONIC | TXP 42 X 60 B  | 33 - 57" |
| 0357 | PANASONIC | TXP 50 GT 50 B | 33 - 57" |
| 0357 | PANASONIC | TXP 46 ST 30 B | 33 - 57" |
| 0357 | PANASONIC | TH 42 PF 50 E  | 33 - 57" |
| 0357 | PANASONIC | TXP 42 GT 30 B | 33 - 57" |
| 0357 | PANASONIC | TXP 42 S 30    | 33 - 57" |
| 0357 | PANASONIC | TXP 42 U 30    | 33 - 57" |
| 0357 | PANASONIC | TXP 42 GT 50 B | 33 - 57" |
| 0357 | PANASONIC | TXP 42 ST 30 B | 33 - 57" |
| 0357 | PANASONIC | TXP 42 C 3     | 33 - 57" |
| 0357 | PANASONIC | TXP 50 X 50 B  | 33 - 57" |
| 0357 | PANASONIC | TXP 42 X 50 B  | 33 - 57" |
| 0357 | PANASONIC | TXP 46 GT 30 B | 33 - 57" |
| 0357 | PANASONIC | TXP 46 G 20 B  | 33 - 57" |
| 0357 | PANASONIC | TXP 42 UT 30 B | 33 - 57" |
| 0357 | PANASONIC | TXP 42 VT 30 E | 33 - 57" |
| 0357 | PANASONIC | TXP 42 UT 50 B | 33 - 57" |
| 0357 | PANASONIC | TXP 50 UT 50 B | 33 - 57" |
| 0357 | PANASONIC | TXP 50 VT 50 B | 33 - 57" |
| 0357 | PANASONIC | TH 42 BT 300 U | 33 - 57" |
| 0357 | PANASONIC | TH 42 PF 30 U  | 33 - 57" |
| 0357 | PANASONIC | TH 42 PH 30 U  | 33 - 57" |
| 0357 | PANASONIC | TXP 50 G 10 B  | 33 - 57" |

|      |           |                |           |
|------|-----------|----------------|-----------|
| 0357 | PANASONIC | TXP 50 X 10    | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 X 20 B  | 33 - 57"  |
| 0357 | PANASONIC | TH 50 PF 20 E  | 33 - 57"  |
| 0357 | PANASONIC | TX 50 PG 10    | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 V 10    | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 S 10    | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 G 20 B  | 33 - 57"  |
| 0357 | PANASONIC | TH 50 PH 30 E  | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 VT 65 B | 33 - 57"  |
| 0357 | PANASONIC | TH 50 BT 300   | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 C 3     | 33 - 57"  |
| 0357 | PANASONIC | TH 50 PF 50 E  | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 G 30 B  | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 U 30    | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 VT 30 E | 33 - 57"  |
| 0357 | PANASONIC | TXP 50 UT 30 B | 33 - 57"  |
| 0357 | PANASONIC | TH 50 BT 300 U | 33 - 57"  |
| 0357 | PANASONIC | TH 50 PF 30 U  | 33 - 57"  |
| 0357 | PANASONIC | TH 50 PF 50 U  | 33 - 57"  |
| 0357 | PANASONIC | TH 50 PH 30 U  | 33 - 57"  |
| 0363 | PANASONIC | TXP 55 VT 65 B | 33 - 57"  |
| 0363 | PANASONIC | TXP 55 ST 60 B | 33 - 57"  |
| 0363 | PANASONIC | TXP 55 VT 50 B | 33 - 57"  |
| 0363 | PANASONIC | TH 58 PF 20 ER | 33 - 57"  |
| 0363 | PANASONIC | TXP 55 VT 30 B | 33 - 57"  |
| 0388 | PANASONIC | TXL 32 V 10 B  | 33 - 57"  |
| 0388 | PANASONIC | TXL 37 V 10 B  | 33 - 57"  |
| 0404 | PANASONIC | TH 48 LFE 8    | 33 - 57"  |
| 0404 | PANASONIC | TH 43 LFE 8    | 33 - 57"  |
| 0410 | PANASONIC | TH 80 LF 50    | 71 - 90"  |
| 0419 | PANASONIC | TH 50 LFE 6    | 33 - 57"  |
| 0422 | PANASONIC | TX 50 AS 500 B | 33 - 57"  |
| 0422 | PANASONIC | TX 50 A 400 B  | 33 - 57"  |
| 0424 | PANASONIC | TH 49 LF 80 W  | 33 - 57"  |
| 0437 | PANASONIC | TH 84 LQ 70    | 71 - 90"  |
| 0458 | PANASONIC | TH 98 LQ 70 W  | 91 - 108" |
| 0472 | PANASONIC | TH 42 AF 1 W   | 33 - 57"  |
| 0479 | PANASONIC | TH 75 EQ 1 W   | 71 - 90"  |
| 9001 | PANASONIC | TXL 24 C 3 B   | 15 - 32"  |
| 9002 | PANASONIC | TX 32 LMD 70   | 15 - 32"  |
| 9002 | PANASONIC | TX 32 LXD 7    | 15 - 32"  |
| 9002 | PANASONIC | TX 32 LXD 70   | 15 - 32"  |
| 9002 | PANASONIC | TX 32 LXD 700  | 15 - 32"  |
| 9002 | PANASONIC | TXL 32 XM 6 B  | 15 - 32"  |
| 9002 | PANASONIC | TXL 32 B 6 B   | 15 - 32"  |
| 9002 | PANASONIC | TH 32 LRU 6 U  | 15 - 32"  |
| 9003 | PANASONIC | TXL 32 E 6 B   | 15 - 32"  |
| 9003 | PANASONIC | TXL 42 DT 65 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 42 FT 60 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 42 ET 60 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 42 E 6 B   | 33 - 57"  |
| 9003 | PANASONIC | TXL 39 E 6 B   | 33 - 57"  |
| 9003 | PANASONIC | TXL 39 EM 6 B  | 33 - 57"  |

|      |           |                |           |
|------|-----------|----------------|-----------|
| 9003 | PANASONIC | TXL 42 B 6 B   | 33 - 57"  |
| 9003 | PANASONIC | TXL 39 B 6 B   | 33 - 57"  |
| 9003 | PANASONIC | TXL 42 ET 5 B  | 33 - 57"  |
| 9003 | PANASONIC | TH 42 LF 5 E   | 33 - 57"  |
| 9003 | PANASONIC | TXL 42 ET 50 B | 33 - 57"  |
| 9003 | PANASONIC | TH 42 LF 20 E  | 33 - 57"  |
| 9003 | PANASONIC | TH 42 LF 25 U  | 33 - 57"  |
| 9003 | PANASONIC | TH 42 LF 30 U  | 33 - 57"  |
| 9003 | PANASONIC | TH 42 LRU 60 U | 33 - 57"  |
| 9003 | PANASONIC | TH LRG 20 B    | 33 - 57"  |
| 9003 | PANASONIC | TXP 42 S 20 B  | 33 - 57"  |
| 9003 | PANASONIC | TXL 47 WT 65 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 50 DT 65 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 47 DT 65 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 47 FT 60 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 50 ET 60 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 47 ET 60 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 50 E 6 B   | 33 - 57"  |
| 9003 | PANASONIC | TXL 50 EM 6 B  | 33 - 57"  |
| 9003 | PANASONIC | TXL 50 B 6 B   | 33 - 57"  |
| 9003 | PANASONIC | TXL 47 E 5 B   | 33 - 57"  |
| 9003 | PANASONIC | TH 47 LFP 30 W | 33 - 57"  |
| 9003 | PANASONIC | TXL 42 U 5 B   | 33 - 57"  |
| 9003 | PANASONIC | TXL 47 ET 5 B  | 33 - 57"  |
| 9003 | PANASONIC | TXL 50 EM 5 B  | 33 - 57"  |
| 9003 | PANASONIC | TH 47 LF 20 E  | 33 - 57"  |
| 9003 | PANASONIC | TH 47 LF 30    | 33 - 57"  |
| 9003 | PANASONIC | TXL 42 E 5 B   | 33 - 57"  |
| 9003 | PANASONIC | TXL 42 E 3 B   | 33 - 57"  |
| 9003 | PANASONIC | TXL 47 ET 50 B | 33 - 57"  |
| 9003 | PANASONIC | TH 47 LF 25 ER | 33 - 57"  |
| 9003 | PANASONIC | TH 47 LF 25 U  | 33 - 57"  |
| 9003 | PANASONIC | TH 47 LF 30 U  | 33 - 57"  |
| 9003 | PANASONIC | TH 47 LFT 30 W | 33 - 57"  |
| 9003 | PANASONIC | TX 50 AX 802 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 55 WT 65 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 55 DT 65 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 55 ET 60 B | 33 - 57"  |
| 9003 | PANASONIC | TXL 55 ET 5 B  | 33 - 57"  |
| 9003 | PANASONIC | TH 55 LRV 5 U  | 33 - 57"  |
| 0273 | PENTA     | D 1001401      | 33 - 57"  |
| 0273 | PENTA     | 47 HD 2        | 33 - 57"  |
| 0284 | PENTA     | PD 37 W        | 33 - 57"  |
| 0425 | PENTA     | PD 32 W        | 33 - 57"  |
| 0008 | PHILIPS   | BDL 9870 EU    | 91 - 108" |
| 0011 | PHILIPS   | 42 FD 9932     | 33 - 57"  |
| 0011 | PHILIPS   | 422 F 9922     | 33 - 57"  |
| 0011 | PHILIPS   | 420 P 10       | 33 - 57"  |
| 0011 | PHILIPS   | 42 FD 9952     | 33 - 57"  |
| 0047 | PHILIPS   | 32 FD 9944     | 33 - 57"  |
| 0047 | PHILIPS   | 32 FD 9964     | 33 - 57"  |



|      |         |                   |          |
|------|---------|-------------------|----------|
| 0047 | PHILIPS | 32 PF 9965        | 33 - 57" |
| 0065 | PHILIPS | BDS 4611          | 33 - 57" |
| 0065 | PHILIPS | BDS 4621          | 33 - 57" |
| 0071 | PHILIPS | 42 FD 9944        | 33 - 57" |
| 0071 | PHILIPS | 42 PF 9964        | 33 - 57" |
| 0071 | PHILIPS | 420 P 30          | 33 - 57" |
| 0071 | PHILIPS | 420 P 20          | 33 - 57" |
| 0071 | PHILIPS | 42 FD 9945        | 33 - 57" |
| 0071 | PHILIPS | BDH 4211          | 33 - 57" |
| 0082 | PHILIPS | 42 BDL 4231       | 33 - 57" |
| 0090 | PHILIPS | BDH 5021          | 33 - 57" |
| 0097 | PHILIPS | 30 PF 9975/12     | 15 - 32" |
| 0097 | PHILIPS | 37 PF 9965        | 33 - 57" |
| 0113 | PHILIPS | 42 PF 9945 / 12   | 33 - 57" |
| 0117 | PHILIPS | BDH 5011          | 33 - 57" |
| 0150 | PHILIPS | 50 FD 9935        | 33 - 57" |
| 0159 | PHILIPS | 42 HF 9442        | 33 - 57" |
| 0159 | PHILIPS | 42 PF 3320        | 33 - 57" |
| 0159 | PHILIPS | BDS 4231 R        | 33 - 57" |
| 0159 | PHILIPS | 42 PF 9946        | 33 - 57" |
| 0159 | PHILIPS | 107 FP 4          | 33 - 57" |
| 0160 | PHILIPS | 37 PF 9946        | 33 - 57" |
| 0161 | PHILIPS | 32 PF 9956        | 33 - 57" |
| 0161 | PHILIPS | 32 PF 9976        | 33 - 57" |
| 0164 | PHILIPS | 30 PF 9946 12     | 33 - 57" |
| 0164 | PHILIPS | 30 HF 9442        | 33 - 57" |
| 0169 | PHILIPS | 32 PF 9986        | 33 - 57" |
| 0179 | PHILIPS | BDS 4241 V / 00   | 33 - 57" |
| 0179 | PHILIPS | BDH 4241          | 33 - 57" |
| 0183 | PHILIPS | 42 PF 9966        | 33 - 57" |
| 0183 | PHILIPS | 42 PF 9956        | 33 - 57" |
| 0202 | PHILIPS | 42 PF 9986 12     | 33 - 57" |
| 0202 | PHILIPS | 50 PF 9966 12     | 33 - 57" |
| 0208 | PHILIPS | BDL 4211          | 33 - 57" |
| 0210 | PHILIPS | 37 PF 5520 D      | 33 - 57" |
| 0210 | PHILIPS | 42 PF 5520 D      | 33 - 57" |
| 0210 | PHILIPS | 50 PF 7320        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 5521 D      | 33 - 57" |
| 0210 | PHILIPS | 37 PF 5521 D / 10 | 33 - 57" |
| 0210 | PHILIPS | 42 PF 7320        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 5320        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 9731        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 9831        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 5421        | 33 - 57" |
| 0210 | PHILIPS | 42 PF 7520 D      | 33 - 57" |
| 0243 | PHILIPS | BDL 4221          | 33 - 57" |
| 0288 | PHILIPS | BDL 4251 V        | 33 - 57" |
| 0288 | PHILIPS | BDL 3245 E        | 33 - 57" |
| 0288 | PHILIPS | BDL 4225          | 33 - 57" |
| 0288 | PHILIPS | BDL 4230 E        | 33 - 57" |
| 0288 | PHILIPS | BDL 4651 VH       | 33 - 57" |
| 0288 | PHILIPS | BDL 4645 E        | 33 - 57" |
| 0288 | PHILIPS | BDL 4245 E        | 33 - 57" |

|      |         |                  |          |
|------|---------|------------------|----------|
| 0314 | PHILIPS | BDL 3731 V       | 33 - 57" |
| 0318 | PHILIPS | 32 PFL 5403      | 33 - 57" |
| 0330 | PHILIPS | 42 PFL 5603 D    | 33 - 57" |
| 0330 | PHILIPS | 42 PFL 8404      | 33 - 57" |
| 0330 | PHILIPS | 47 PFL 7404      | 33 - 57" |
| 0330 | PHILIPS | 47 PFL 4007      | 33 - 57" |
| 0337 | PHILIPS | 42 PFL 7662 D    | 33 - 57" |
| 0341 | PHILIPS | 37 PFL 9604      | 33 - 57" |
| 0344 | PHILIPS | 47 PFL 9664 H/12 | 33 - 57" |
| 0356 | PHILIPS | 52 PFL 7404 H    | 33 - 57" |
| 0356 | PHILIPS | BDT 5530 EM      | 33 - 57" |
| 0356 | PHILIPS | 46 HFL 5573      | 33 - 57" |
| 0356 | PHILIPS | 50 PFL 3807      | 33 - 57" |
| 0375 | PHILIPS | 46 PFL 7605      | 33 - 57" |
| 0391 | PHILIPS | 52 PFL 5605 H    | 33 - 57" |
| 0398 | PHILIPS | BDL 5231         | 33 - 57" |
| 0398 | PHILIPS | BDL 5545 E       | 33 - 57" |
| 0415 | PHILIPS | BDL 4330 QL      | 33 - 57" |
| 0415 | PHILIPS | 49 BDL 4050 D    | 33 - 57" |
| 0415 | PHILIPS | BDL 4671 VL/00   | 33 - 57" |
| 0415 | PHILIPS | BDL 4765 EL      | 33 - 57" |
| 0424 | PHILIPS | BDL 4830 QL      | 33 - 57" |
| 0431 | PHILIPS | 55 BDL 3050 Q    | 33 - 57" |
| 0434 | PHILIPS | BDL 5520 QL      | 33 - 57" |
| 0463 | PHILIPS | BDL 8470 EU      | 71 - 90" |
| 9001 | PHILIPS | 32 PFL 3208 T    | 15 - 32" |
| 9001 | PHILIPS | 32 PFL 3258 T    | 15 - 32" |
| 9001 | PHILIPS | 32 PFL 9705 H    | 15 - 32" |
| 9002 | PHILIPS | 32 PF 5520 D     | 15 - 32" |
| 9002 | PHILIPS | 32 PF 7520 D     | 15 - 32" |
| 9002 | PHILIPS | 32 HF 7473       | 15 - 32" |
| 9002 | PHILIPS | 32 PF 4320       | 15 - 32" |
| 9002 | PHILIPS | 32 PF 5320       | 15 - 32" |
| 9002 | PHILIPS | 32 HF 7875       | 15 - 32" |
| 9002 | PHILIPS | 32 PFL 4208 T    | 15 - 32" |
| 9002 | PHILIPS | 32 PFL 4258 T    | 15 - 32" |
| 9002 | PHILIPS | 32 HFL 3007 D    | 15 - 32" |
| 9002 | PHILIPS | 32 PF 9631 D     | 15 - 32" |
| 9002 | PHILIPS | 32 PF 9531       | 15 - 32" |
| 9003 | PHILIPS | 32 PFL 5008 T    | 15 - 32" |
| 9003 | PHILIPS | 37 PFL 5604      | 33 - 57" |
| 9003 | PHILIPS | 32 PFL 5605      | 33 - 57" |
| 9003 | PHILIPS | 40 PFL 3208 T    | 33 - 57" |
| 9003 | PHILIPS | 39 PFL 3208 T    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 3208 T    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 5008 T    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 6188 S    | 33 - 57" |
| 9003 | PHILIPS | 39 PFL 4208 T    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 4208 T    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 7008 S    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 6008 S    | 33 - 57" |
| 9003 | PHILIPS | 40 PFL 9705 H    | 33 - 57" |
| 9003 | PHILIPS | 32 PFL 9604 H    | 33 - 57" |

|      |         |                  |          |
|------|---------|------------------|----------|
| 9003 | PHILIPS | 37 PFL 9604 H    | 33 - 57" |
| 9003 | PHILIPS | 32 PFL 9613 D    | 33 - 57" |
| 9003 | PHILIPS | 37 PFL 9603 D    | 33 - 57" |
| 9003 | PHILIPS | 32 PFL 9603 D    | 33 - 57" |
| 9003 | PHILIPS | 32 PFL 9632 D    | 33 - 57" |
| 9003 | PHILIPS | 46 PFL 3208 T    | 33 - 57" |
| 9003 | PHILIPS | 50 PFL 4208 T    | 33 - 57" |
| 9003 | PHILIPS | 47 PFL 5008 T    | 33 - 57" |
| 9003 | PHILIPS | 50 PFL 5008 T    | 33 - 57" |
| 9003 | PHILIPS | 46 PFL 4208 T    | 33 - 57" |
| 9003 | PHILIPS | 47 PFL 6188 S    | 33 - 57" |
| 9003 | PHILIPS | 47 PFL 7008 S    | 33 - 57" |
| 9003 | PHILIPS | 47 PFL 7108 S    | 33 - 57" |
| 9003 | PHILIPS | 46 PFL 8008 S    | 33 - 57" |
| 9003 | PHILIPS | 47 PFL 6008 S    | 33 - 57" |
| 9003 | PHILIPS | BDL 4610 Q       | 33 - 57" |
| 9003 | PHILIPS | 46 PFL 9707 S    | 33 - 57" |
| 9003 | PHILIPS | 46 PFL 9707 T    | 33 - 57" |
| 9003 | PHILIPS | 46 PFL 9706 T    | 33 - 57" |
| 9003 | PHILIPS | 46 PFL 9705 H    | 33 - 57" |
| 9003 | PHILIPS | 47 PFL 9664 H    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 9664 H    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 9803 H    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 9603 D    | 33 - 57" |
| 9003 | PHILIPS | 47 PFL 9603 D    | 33 - 57" |
| 9003 | PHILIPS | 42 PFL 9703 D    | 33 - 57" |
| 9003 | PHILIPS | 37 PFL 9632 D    | 33 - 57" |
| 9003 | PHILIPS | 55 PDL 8908 S    | 33 - 57" |
| 9003 | PHILIPS | 55 PFL 7008 S    | 33 - 57" |
| 9003 | PHILIPS | 55 PFL 7108 S    | 33 - 57" |
| 9003 | PHILIPS | 55 PFL 8008 S    | 33 - 57" |
| 9003 | PHILIPS | 55 PFL 6008 S    | 33 - 57" |
| 9003 | PHILIPS | 55 PFL 6188 S    | 33 - 57" |
| 9003 | PHILIPS | 52 PFL 9606 T    | 33 - 57" |
| 9004 | PHILIPS | 37 PFL 5522 D/05 | 33 - 57" |
| 9004 | PHILIPS | 40 PFL 9704 H    | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 5522      | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 5532 D    | 33 - 57" |
| 9004 | PHILIPS | 46 PFL 9704 H    | 33 - 57" |
| 9004 | PHILIPS | 47 PFL 9632 D    | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 9900 D    | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 9732 D    | 33 - 57" |
| 9004 | PHILIPS | 47 PFL 9732 D    | 33 - 57" |
| 9004 | PHILIPS | 42 PFL 9632 D    | 33 - 57" |
| 9004 | PHILIPS | 50 FD 9631 D     | 33 - 57" |
| 9004 | PHILIPS | 52 PFL 9703 D    | 33 - 57" |
| 9004 | PHILIPS | 52 PFL 9632 D    | 33 - 57" |
| 9005 | PHILIPS | 42 PF 9731 D     | 33 - 57" |
| 9005 | PHILIPS | 42 PF 9831 D     | 33 - 57" |
| 0027 | PIONEER | PDP 434 PE       | 33 - 57" |
| 0027 | PIONEER | PDP 433 PE       | 33 - 57" |
| 0027 | PIONEER | PDP 433 MXE      | 33 - 57" |

|      |            |                 |             |
|------|------------|-----------------|-------------|
| 0027 | PIONEER    | PDP 43 MXE 1    | 33 - 57"    |
| 0027 | PIONEER    | PDP 436 PE      | 33 - 57"    |
| 0027 | PIONEER    | PDP 42 MXE 10   | 33 - 57"    |
| 0027 | PIONEER    | PDP 427 XD      | 33 - 57"    |
| 0027 | PIONEER    | 4280 XD         | 33 - 57"    |
| 0027 | PIONEER    | PDP 42 MXE 20   | 33 - 57"    |
| 0027 | PIONEER    | PDP 4270 XD     | 33 - 57"    |
| 0027 | PIONEER    | PDP 428 XD      | 33 - 57"    |
| 0027 | PIONEER    | PDP 435         | 33 - 57"    |
| 0027 | PIONEER    | PDP 501 MX      | 33 - 57"    |
| 0027 | PIONEER    | PDP 502 MX      | 33 - 57"    |
| 0027 | PIONEER    | 50 MXE 1        | 33 - 57"    |
| 0027 | PIONEER    | PDP 506 PE      | 33 - 57"    |
| 0027 | PIONEER    | PDP 50 MXE 11   | 33 - 57"    |
| 0027 | PIONEER    | PDP 50 MXE 20   | 33 - 57"    |
| 0027 | PIONEER    | PDP 508 D       | 33 - 57"    |
| 0027 | PIONEER    | PDP 503 XD      | 33 - 57"    |
| 0027 | PIONEER    | PDP 504 XD      | 33 - 57"    |
| 0027 | PIONEER    | PDP 506 XDE     | 33 - 57"    |
| 0027 | PIONEER    | PDP 50 MXE 10   | 33 - 57"    |
| 0027 | PIONEER    | PDP 507 XDE     | 33 - 57"    |
| 0027 | PIONEER    | PDP 508 XDE     | 33 - 57"    |
| 0028 | PIONEER    | 40 PDPV 401 E   | 33 - 57"    |
| 0028 | PIONEER    | PDP 401 E       | 33 - 57"    |
| 0028 | PIONEER    | 40 PDPV 402 E   | 33 - 57"    |
| 0307 | PIONEER    | KRL 32 V        | 33 - 57"    |
| 0307 | PIONEER    | KRL 37 V        | 33 - 57"    |
| 0336 | PRESTIGIO  | P 320 DVD XD    | 33 - 57"    |
| 0001 | PROMETHEAN | 78              | Interactive |
| 0457 | PRYSM      | CASCADE 85"     | 71 - 90"    |
| 0460 | PRYSM      | CASCADE 98"     | 91 - 108"   |
| 0014 | RELISYS    | PDP 4202        | 33 - 57"    |
| 0067 | RELISYS    | RP 4205         | 33 - 57"    |
| 0073 | RELISYS    | RP 5000 S       | 33 - 57"    |
| 0080 | RELISYS    | RLT 3000        | 15 - 32"    |
| 0139 | RELISYS    | RP 4210 S       | 33 - 57"    |
| 0139 | RELISYS    | RP 5010 S       | 33 - 57"    |
| 0142 | RELISYS    | RP 4206         | 33 - 57"    |
| 0156 | RELISYS    | RP 4207         | 33 - 57"    |
| 0157 | RELISYS    | RLT 32 AB 20 RU | 33 - 57"    |
| 0157 | RELISYS    | RLT 32 AB 50 RU | 33 - 57"    |
| 0179 | RELISYS    | RP 42 AB 50     | 33 - 57"    |
| 0179 | RELISYS    | RP 42 AB 20     | 33 - 57"    |
| 0179 | RELISYS    | RP 50 AB 50     | 33 - 57"    |
| 0180 | RELISYS    | RP 42 DV 30     | 33 - 57"    |
| 0180 | RELISYS    | RP 42 AV 20     | 33 - 57"    |
| 0184 | RELISYS    | RLT 3200        | 33 - 57"    |
| 0194 | RELISYS    | RLT 4000        | 33 - 57"    |
| 0194 | RELISYS    | RLT 40 AH 20    | 33 - 57"    |

|      |         |                |          |
|------|---------|----------------|----------|
| 0194 | RELISYS | RYT 42 AH 20   | 33 - 57" |
| 0195 | RELISYS | RLT 2720 RU    | 33 - 57" |
| 0246 | RELISYS | RLT 32 AG 20   | 33 - 57" |
| 0212 | REVOX   | E 542          | 33 - 57" |
| 0204 | SAGEM   | AXIUM HDL 27   | 33 - 57" |
| 0166 | SAHARA  | P 42 CDN       | 33 - 57" |
| 0170 | SAHARA  | LT 30 AAN      | 33 - 57" |
| 0341 | SAHARA  | SV 40          | 33 - 57" |
| 0409 | SAHARA  | SV 46          | 33 - 57" |
| 0409 | SAHARA  | SV 55          | 33 - 57" |
| 0409 | SAHARA  | SV 47          | 33 - 57" |
| 0409 | SAHARA  | SV 40 B        | 33 - 57" |
| 0367 | SAMPO   | PME 50 XP 12 P | 33 - 57" |
| 0000 | SAMSUNG | UE 75 JU 6400  | 71 - 90" |
| 0000 | SAMSUNG | ME 40          | C1       |
| 0007 | SAMSUNG | 820 DXN        | 71 - 90" |
| 0007 | SAMSUNG | 820 DXN 2      | 71 - 90" |
| 0007 | SAMSUNG | 820 DX 3       | 71 - 90" |
| 0007 | SAMSUNG | 820 TSN 2      | 71 - 90" |
| 0067 | SAMSUNG | PS 42 P 2 S    | 33 - 57" |
| 0067 | SAMSUNG | PPM 42 S 3     | 33 - 57" |
| 0067 | SAMSUNG | PPM 50 H 3     | 33 - 57" |
| 0073 | SAMSUNG | PS 50 P 2 HT   | 33 - 57" |
| 0077 | SAMSUNG | LW 29 A 13 W   | 33 - 57" |
| 0079 | SAMSUNG | LW 40 A 13 W   | 33 - 57" |
| 0090 | SAMSUNG | P 42 P 3 S     | 33 - 57" |
| 0098 | SAMSUNG | LW 32 A 23 W   | 15 - 32" |
| 0112 | SAMSUNG | 403 T          | 33 - 57" |
| 0123 | SAMSUNG | 241 MP         | 15 - 32" |
| 0128 | SAMSUNG | LW 40 A 23 W   | 33 - 57" |
| 0143 | SAMSUNG | PS 42 D 4 S    | 33 - 57" |
| 0143 | SAMSUNG | PS 42 V 4 S    | 33 - 57" |
| 0143 | SAMSUNG | PS 50 P 4 H 1  | 33 - 57" |
| 0155 | SAMSUNG | PS 50 P 3 H    | 33 - 57" |
| 0168 | SAMSUNG | LW 32 A 33 W   | 33 - 57" |
| 0177 | SAMSUNG | 320 P          | 33 - 57" |
| 0200 | SAMSUNG | SM 320 MXN     | 33 - 57" |
| 0200 | SAMSUNG | 320 TSN        | 33 - 57" |
| 0200 | SAMSUNG | 320 MX 3       | 33 - 57" |
| 0200 | SAMSUNG | 320 MXN 3      | 33 - 57" |
| 0200 | SAMSUNG | 320 BX         | 33 - 57" |
| 0200 | SAMSUNG | 320 TSN 3      | 33 - 57" |
| 0200 | SAMSUNG | UA 32 EH 4005  | 33 - 57" |
| 0200 | SAMSUNG | UA 32 EH 4003  | 33 - 57" |
| 0200 | SAMSUNG | UA 32 H 4500   | 33 - 57" |
| 0200 | SAMSUNG | LE 32 R 74 BD  | 33 - 57" |
| 0200 | SAMSUNG | LE 32 R 41 BX  | 33 - 57" |
| 0200 | SAMSUNG | LE 32 M 61     | 33 - 57" |

|      |         |                   |          |
|------|---------|-------------------|----------|
| 0200 | SAMSUNG | LE 32 S 81        | 33 - 57" |
| 0200 | SAMSUNG | LE 32 S 86        | 33 - 57" |
| 0200 | SAMSUNG | 320 MX 2          | 33 - 57" |
| 0200 | SAMSUNG | LE 32 T 51 B      | 33 - 57" |
| 0200 | SAMSUNG | LE 32 R 51        | 33 - 57" |
| 0200 | SAMSUNG | UA 40 EH 5005     | 33 - 57" |
| 0200 | SAMSUNG | UA 40 EH 5000     | 33 - 57" |
| 0200 | SAMSUNG | LE 40 R 51 B      | 33 - 57" |
| 0200 | SAMSUNG | LE 40 R 72        | 33 - 57" |
| 0200 | SAMSUNG | LE 40 M 61 B      | 33 - 57" |
| 0200 | SAMSUNG | 40 R 74 BDX       | 33 - 57" |
| 0200 | SAMSUNG | LE 40 N 73 BD     | 33 - 57" |
| 0200 | SAMSUNG | LE 40 R 73        | 33 - 57" |
| 0200 | SAMSUNG | LE 37 R 87 BD     | 33 - 57" |
| 0200 | SAMSUNG | LE 37 R 87        | 33 - 57" |
| 0200 | SAMSUNG | LE 37 S 71        | 33 - 57" |
| 0200 | SAMSUNG | LE 37 A 559       | 33 - 57" |
| 0205 | SAMSUNG | PS 42 D 5 S       | 33 - 57" |
| 0205 | SAMSUNG | LE 46 M 87 BD     | 33 - 57" |
| 0205 | SAMSUNG | 400 DXN           | 33 - 57" |
| 0205 | SAMSUNG | 460 DX 3          | 33 - 57" |
| 0205 | SAMSUNG | 550 DX            | 33 - 57" |
| 0205 | SAMSUNG | 400 UX 3          | 33 - 57" |
| 0205 | SAMSUNG | 400 UXN 3         | 33 - 57" |
| 0205 | SAMSUNG | 460 UX 3          | 33 - 57" |
| 0205 | SAMSUNG | 460 UXN 3         | 33 - 57" |
| 0205 | SAMSUNG | 460 UT 2          | 33 - 57" |
| 0205 | SAMSUNG | 460 UTN 2         | 33 - 57" |
| 0205 | SAMSUNG | 460 UTB           | 33 - 57" |
| 0205 | SAMSUNG | 460 UTNB          | 33 - 57" |
| 0205 | SAMSUNG | 400 MX 3          | 33 - 57" |
| 0205 | SAMSUNG | 460 MX 3          | 33 - 57" |
| 0205 | SAMSUNG | 460 BX            | 33 - 57" |
| 0205 | SAMSUNG | 400 TS 3          | 33 - 57" |
| 0205 | SAMSUNG | 460 TS 3          | 33 - 57" |
| 0205 | SAMSUNG | UD 46 A           | 33 - 57" |
| 0205 | SAMSUNG | UD 46 C           | 33 - 57" |
| 0205 | SAMSUNG | UD 55 C           | 33 - 57" |
| 0205 | SAMSUNG | UD 46 C-B         | 33 - 57" |
| 0205 | SAMSUNG | SL 46 B           | 33 - 57" |
| 0215 | SAMSUNG | PS 50 A 457       | 33 - 57" |
| 0238 | SAMSUNG | SMT 4022 P        | 33 - 57" |
| 0282 | SAMSUNG | LE 32 R 87 BD     | 33 - 57" |
| 0282 | SAMSUNG | LE 32 A 436 T 1 D | 33 - 57" |
| 0282 | SAMSUNG | LE 32 A 457       | 33 - 57" |
| 0282 | SAMSUNG | LE 32 R 86        | 33 - 57" |
| 0282 | SAMSUNG | LE 32 R 88        | 33 - 57" |
| 0282 | SAMSUNG | LE 32 A 45        | 33 - 57" |
| 0282 | SAMSUNG | LE 32 B 550       | 33 - 57" |
| 0282 | SAMSUNG | LE 37 A 436       | 33 - 57" |
| 0282 | SAMSUNG | LE 32 B 450       | 33 - 57" |
| 0282 | SAMSUNG | LE 40 R 87 BD     | 33 - 57" |
| 0282 | SAMSUNG | LE 40 N 87        | 33 - 57" |

|      |         |                   |          |
|------|---------|-------------------|----------|
| 0282 | SAMSUNG | LE 40 S 86 BDX    | 33 - 57" |
| 0282 | SAMSUNG | 40 A 656          | 33 - 57" |
| 0282 | SAMSUNG | LE 40 A 786       | 33 - 57" |
| 0282 | SAMSUNG | LE 40 A 558       | 33 - 57" |
| 0282 | SAMSUNG | LE 40 A 336 J 1   | 33 - 57" |
| 0282 | SAMSUNG | LE 37 S 86 BDX    | 33 - 57" |
| 0290 | SAMSUNG | LE 52 M 87 BD     | 33 - 57" |
| 0290 | SAMSUNG | LE 52 F 96        | 33 - 57" |
| 0292 | SAMSUNG | 570 DX            | 33 - 57" |
| 0292 | SAMSUNG | SM 570            | 33 - 57" |
| 0292 | SAMSUNG | 520 DX            | 33 - 57" |
| 0321 | SAMSUNG | PS 42 A 457       | 33 - 57" |
| 0321 | SAMSUNG | PS 42 B 451       | 33 - 57" |
| 0323 | SAMSUNG | LE 52 A 559       | 33 - 57" |
| 0323 | SAMSUNG | LE 52 A 656       | 33 - 57" |
| 0323 | SAMSUNG | OM 55 D           | 33 - 57" |
| 0341 | SAMSUNG | MD 32 B           | 33 - 57" |
| 0341 | SAMSUNG | ED 32 D           | 33 - 57" |
| 0341 | SAMSUNG | LE 32 A 558 P3F   | 33 - 57" |
| 0341 | SAMSUNG | CE 32 C 530       | 33 - 57" |
| 0341 | SAMSUNG | LE 32 A 656       | 33 - 57" |
| 0341 | SAMSUNG | LE 32 A 556       | 33 - 57" |
| 0341 | SAMSUNG | LE 37 B 550       | 33 - 57" |
| 0341 | SAMSUNG | LE 37 B 530       | 33 - 57" |
| 0341 | SAMSUNG | LE 40 B 550 A 5 W | 33 - 57" |
| 0341 | SAMSUNG | LE 40 B 553       | 33 - 57" |
| 0341 | SAMSUNG | UE 37 D 50000     | 33 - 57" |
| 0341 | SAMSUNG | MD 40 B           | 33 - 57" |
| 0341 | SAMSUNG | ED 40             | 33 - 57" |
| 0341 | SAMSUNG | MD 40 C           | 33 - 57" |
| 0341 | SAMSUNG | 40 ES 6300        | 33 - 57" |
| 0341 | SAMSUNG | 32 D 550          | 33 - 57" |
| 0341 | SAMSUNG | LE 40 D 503       | 33 - 57" |
| 0341 | SAMSUNG | 40 EH 5000        | 33 - 57" |
| 0341 | SAMSUNG | ED 40 D           | 33 - 57" |
| 0341 | SAMSUNG | LE 40 A 457       | 33 - 57" |
| 0341 | SAMSUNG | LE 40 B 650       | 33 - 57" |
| 0341 | SAMSUNG | ED 40 C           | 33 - 57" |
| 0344 | SAMSUNG | KDL 40 EX 703     | 33 - 57" |
| 0351 | SAMSUNG | LE 46 A 856       | 33 - 57" |
| 0356 | SAMSUNG | LE 52 A 856       | 33 - 57" |
| 0358 | SAMSUNG | LE 55 B 650       | 33 - 57" |
| 0358 | SAMSUNG | LE 55 B 655       | 33 - 57" |
| 0358 | SAMSUNG | LE 55 C 650       | 33 - 57" |
| 0359 | SAMSUNG | LE 46 B 530 P 7   | 33 - 57" |
| 0359 | SAMSUNG | LE 46 B 550       | 33 - 57" |
| 0359 | SAMSUNG | 46 B 650          | 33 - 57" |
| 0359 | SAMSUNG | 42 C 450          | 33 - 57" |
| 0359 | SAMSUNG | LE 46 C 530       | 33 - 57" |
| 0359 | SAMSUNG | PS 43 E 430       | 33 - 57" |
| 0359 | SAMSUNG | PS 43 E 450       | 33 - 57" |
| 0359 | SAMSUNG | 50 EH 5300        | 33 - 57" |
| 0359 | SAMSUNG | PS 51 D 550       | 33 - 57" |

|      |         |               |          |
|------|---------|---------------|----------|
| 0359 | SAMSUNG | PS 43 D 450   | 33 - 57" |
| 0359 | SAMSUNG | PS 51 D 450   | 33 - 57" |
| 0359 | SAMSUNG | UE 46 ES 5500 | 33 - 57" |
| 0359 | SAMSUNG | 46 EH 5000    | 33 - 57" |
| 0359 | SAMSUNG | 46 D 6530     | 33 - 57" |
| 0359 | SAMSUNG | 46 D 580      | 33 - 57" |
| 0359 | SAMSUNG | PS 43 E 490   | 33 - 57" |
| 0359 | SAMSUNG | 46 ES 8000    | 33 - 57" |
| 0359 | SAMSUNG | UE 46 D 8090  | 33 - 57" |
| 0359 | SAMSUNG | UE 50 ES 6300 | 33 - 57" |
| 0359 | SAMSUNG | PS 42 B 430   | 33 - 57" |
| 0359 | SAMSUNG | PS 50 B 430   | 33 - 57" |
| 0359 | SAMSUNG | PS 50 B 551   | 33 - 57" |
| 0359 | SAMSUNG | PS 50 B 451   | 33 - 57" |
| 0359 | SAMSUNG | PS 50 C 450   | 33 - 57" |
| 0359 | SAMSUNG | PS 50 C 550   | 33 - 57" |
| 0359 | SAMSUNG | LE 50 B 550   | 33 - 57" |
| 0359 | SAMSUNG | 55 ES 6300    | 33 - 57" |
| 0361 | SAMSUNG | UE 55 B 7020  | 33 - 57" |
| 0361 | SAMSUNG | UE 55 C 7000  | 33 - 57" |
| 0361 | SAMSUNG | UE 55 C 8000  | 33 - 57" |
| 0361 | SAMSUNG | LE 46 C 653   | 33 - 57" |
| 0361 | SAMSUNG | UE 55 D 6100  | 33 - 57" |
| 0361 | SAMSUNG | 55 ES 6800    | 33 - 57" |
| 0361 | SAMSUNG | UE 46 F 7000  | 33 - 57" |
| 0361 | SAMSUNG | UE 55 F 7000  | 33 - 57" |
| 0364 | SAMSUNG | UE 40 C 5100  | 33 - 57" |
| 0364 | SAMSUNG | UE 46 B 7020  | 33 - 57" |
| 0364 | SAMSUNG | UE 40 B 7020  | 33 - 57" |
| 0364 | SAMSUNG | 46 B 6000     | 33 - 57" |
| 0364 | SAMSUNG | UE 40 B 8000  | 33 - 57" |
| 0364 | SAMSUNG | UE 40 B 7000  | 33 - 57" |
| 0364 | SAMSUNG | UE 40 B 6000  | 33 - 57" |
| 0364 | SAMSUNG | LE 46 C 6530  | 33 - 57" |
| 0364 | SAMSUNG | DE 46 A       | 33 - 57" |
| 0364 | SAMSUNG | MD 46 B       | 33 - 57" |
| 0364 | SAMSUNG | UE 46 D 5000  | 33 - 57" |
| 0364 | SAMSUNG | ME 46 B       | 33 - 57" |
| 0364 | SAMSUNG | UE 46 F 5000  | 33 - 57" |
| 0364 | SAMSUNG | ED 46 C       | 33 - 57" |
| 0364 | SAMSUNG | DE 46 C       | 33 - 57" |
| 0364 | SAMSUNG | PE 46 C       | 33 - 57" |
| 0364 | SAMSUNG | LE 46 C       | 33 - 57" |
| 0364 | SAMSUNG | ME 46 A       | 33 - 57" |
| 0364 | SAMSUNG | ME 46 C       | 33 - 57" |
| 0364 | SAMSUNG | MD 46 C       | 33 - 57" |
| 0364 | SAMSUNG | UE 46 A       | 33 - 57" |
| 0364 | SAMSUNG | UE 46 C       | 33 - 57" |
| 0364 | SAMSUNG | PS 51 F 4900  | 33 - 57" |
| 0364 | SAMSUNG | 46 ES 6710    | 33 - 57" |
| 0364 | SAMSUNG | 40 D 6100     | 33 - 57" |
| 0364 | SAMSUNG | UE 46 F 5500  | 33 - 57" |
| 0364 | SAMSUNG | UE 46 D 8000  | 33 - 57" |



|      |         |                 |          |
|------|---------|-----------------|----------|
| 0364 | SAMSUNG | DB 48 D         | 33 - 57" |
| 0364 | SAMSUNG | DH 48 D         | 33 - 57" |
| 0364 | SAMSUNG | DM 48 D         | 33 - 57" |
| 0364 | SAMSUNG | ED 46 D         | 33 - 57" |
| 0364 | SAMSUNG | UA 50 HU 7000   | 33 - 57" |
| 0364 | SAMSUNG | UA 48 H 5100 A  | 33 - 57" |
| 0364 | SAMSUNG | UA 48 H 5500 A  | 33 - 57" |
| 0364 | SAMSUNG | UA 48 H 6400 A  | 33 - 57" |
| 0364 | SAMSUNG | UA 46 H 7000 A  | 33 - 57" |
| 0364 | SAMSUNG | PA 51 H 5000 A  | 33 - 57" |
| 0364 | SAMSUNG | UA 48 H 6300 A  | 33 - 57" |
| 0364 | SAMSUNG | PA 51 H 4500 A  | 33 - 57" |
| 0364 | SAMSUNG | PA 43 H 4500 A  | 33 - 57" |
| 0364 | SAMSUNG | PA 43 H 4000 A  | 33 - 57" |
| 0364 | SAMSUNG | PS 51 F 5500 A  | 33 - 57" |
| 0364 | SAMSUNG | UE 48 H 6400    | 33 - 57" |
| 0364 | SAMSUNG | UE 50 H 6400    | 33 - 57" |
| 0364 | SAMSUNG | DM 48 E         | 33 - 57" |
| 0364 | SAMSUNG | HG 48 ED 670 CK | 33 - 57" |
| 0364 | SAMSUNG | DE 55 A         | 33 - 57" |
| 0364 | SAMSUNG | ME 55 A         | 33 - 57" |
| 0364 | SAMSUNG | MD 55 B         | 33 - 57" |
| 0364 | SAMSUNG | ME 55 B         | 33 - 57" |
| 0364 | SAMSUNG | DE 55 C         | 33 - 57" |
| 0364 | SAMSUNG | LE 55 C         | 33 - 57" |
| 0364 | SAMSUNG | PE 55 C         | 33 - 57" |
| 0364 | SAMSUNG | ME 55 C         | 33 - 57" |
| 0364 | SAMSUNG | MD 55 C         | 33 - 57" |
| 0364 | SAMSUNG | UE 55 A         | 33 - 57" |
| 0364 | SAMSUNG | UE 55 C         | 33 - 57" |
| 0364 | SAMSUNG | ED 55 C         | 33 - 57" |
| 0364 | SAMSUNG | DH 55 D         | 33 - 57" |
| 0364 | SAMSUNG | DB 55 B         | 33 - 57" |
| 0364 | SAMSUNG | ED 55 D         | 33 - 57" |
| 0364 | SAMSUNG | UE 55 D 8000    | 33 - 57" |
| 0364 | SAMSUNG | UE 55 H 6400    | 33 - 57" |
| 0364 | SAMSUNG | DB 55 E         | 33 - 57" |
| 0364 | SAMSUNG | 550 EX          | 33 - 57" |
| 0389 | SAMSUNG | SM 400 EX       | 33 - 57" |
| 0389 | SAMSUNG | 400 EXN         | 33 - 57" |
| 0400 | SAMSUNG | VESA 200X200 M8 | 33 - 57" |
| 0400 | SAMSUNG | ME 32 B         | 33 - 57" |
| 0400 | SAMSUNG | DE 40 A         | 33 - 57" |
| 0400 | SAMSUNG | DE 40 C         | 33 - 57" |
| 0400 | SAMSUNG | PE 40 C         | 33 - 57" |
| 0400 | SAMSUNG | LE 32 C         | 33 - 57" |
| 0400 | SAMSUNG | ME 40 A         | 33 - 57" |
| 0400 | SAMSUNG | ME 40 B         | 33 - 57" |
| 0400 | SAMSUNG | ME 32 C         | 33 - 57" |
| 0400 | SAMSUNG | ME 40 C         | 33 - 57" |
| 0400 | SAMSUNG | 32 ES 6710      | 33 - 57" |
| 0400 | SAMSUNG | UE 40 D 8000    | 33 - 57" |
| 0400 | SAMSUNG | 32 D 4000       | 33 - 57" |

|      |         |                 |           |
|------|---------|-----------------|-----------|
| 0400 | SAMSUNG | 37 D 6530       | 33 - 57"  |
| 0400 | SAMSUNG | UE 32 F 5070    | 33 - 57"  |
| 0400 | SAMSUNG | UE 32 ES 6300   | 33 - 57"  |
| 0400 | SAMSUNG | 32 EH 5000      | 33 - 57"  |
| 0400 | SAMSUNG | 37 ES 6710      | 33 - 57"  |
| 0400 | SAMSUNG | UE 42 F 5000    | 33 - 57"  |
| 0400 | SAMSUNG | DB 32 D         | 33 - 57"  |
| 0400 | SAMSUNG | DH 40 D         | 33 - 57"  |
| 0400 | SAMSUNG | DM 32 D         | 33 - 57"  |
| 0400 | SAMSUNG | DM 40 D         | 33 - 57"  |
| 0400 | SAMSUNG | UA 40 H 4200    | 33 - 57"  |
| 0400 | SAMSUNG | UA 40 HU 7000   | 33 - 57"  |
| 0400 | SAMSUNG | UA 32 H 5400 A  | 33 - 57"  |
| 0400 | SAMSUNG | UA 40 H 6400 A  | 33 - 57"  |
| 0400 | SAMSUNG | UA 40 H 6300 A  | 33 - 57"  |
| 0400 | SAMSUNG | UA 40 H 5500 A  | 33 - 57"  |
| 0400 | SAMSUNG | UA 32 H 5100 A  | 33 - 57"  |
| 0400 | SAMSUNG | UA 32 H 4100 A  | 33 - 57"  |
| 0400 | SAMSUNG | UA 40 H 5100 A  | 33 - 57"  |
| 0400 | SAMSUNG | UE 40 F 7000    | 33 - 57"  |
| 0400 | SAMSUNG | UE 32 H 6400    | 33 - 57"  |
| 0400 | SAMSUNG | UE 40 H 6400    | 33 - 57"  |
| 0400 | SAMSUNG | DM 32 E         | 33 - 57"  |
| 0404 | SAMSUNG | ED 32 C         | 33 - 57"  |
| 0404 | SAMSUNG | SMT 4031        | 33 - 57"  |
| 0408 | SAMSUNG | ME 75           | 71 - 90"  |
| 0408 | SAMSUNG | ME 75 C         | 71 - 90"  |
| 0408 | SAMSUNG | ED 75 C         | 71 - 90"  |
| 0408 | SAMSUNG | 75 ES 9000      | 71 - 90"  |
| 0408 | SAMSUNG | ED 75 D         | 71 - 90"  |
| 0408 | SAMSUNG | DM 75 D         | 71 - 90"  |
| 0408 | SAMSUNG | UE 75 F 6470    | 71 - 90"  |
| 0408 | SAMSUNG | UE 75 H 6400    | 71 - 90"  |
| 0414 | SAMSUNG | ME 95           | 91 - 108" |
| 0414 | SAMSUNG | ME 95 C         | 91 - 108" |
| 0416 | SAMSUNG | QM 85 D         | 71 - 90"  |
| 0416 | SAMSUNG | LH 85 QMD       | 71 - 90"  |
| 0416 | SAMSUNG | DM 82 E - BR    | 71 - 90"  |
| 0418 | SAMSUNG | QM 85 F         | 71 - 90"  |
| 0420 | SAMSUNG | UE 50 F 5070    | 33 - 57"  |
| 0420 | SAMSUNG | UE 50 F 5700 AW | 33 - 57"  |
| 0426 | SAMSUNG | UE 40 H 6700    | 33 - 57"  |
| 0426 | SAMSUNG | UE 40 H 5500    | 33 - 57"  |
| 0428 | SAMSUNG | UE 32 F 4500    | 33 - 57"  |
| 0429 | SAMSUNG | DB 40 D         | 33 - 57"  |
| 0429 | SAMSUNG | DB 40 E         | 33 - 57"  |
| 0436 | SAMSUNG | DM 55 D         | 33 - 57"  |
| 0436 | SAMSUNG | QM 49 R         | 33 - 57"  |
| 0438 | SAMSUNG | OM 75 D         | 71 - 90"  |
| 0444 | SAMSUNG | RM 48 D         | 33 - 57"  |
| 0444 | SAMSUNG | LH 48D          | 33 - 57"  |
| 0446 | SAMSUNG | QM 105          | 91 - 108" |
| 0447 | SAMSUNG | DC 49 J         | 33 - 57"  |

|      |         |                 |          |
|------|---------|-----------------|----------|
| 0447 | SAMSUNG | PM 49 H         | 33 - 57" |
| 0447 | SAMSUNG | UE 55 J 5100    | 33 - 57" |
| 0447 | SAMSUNG | DC 55           | 33 - 57" |
| 0452 | SAMSUNG | UE 40 J 5100    | 33 - 57" |
| 0452 | SAMSUNG | HG 48 EE 470 SK | 33 - 57" |
| 0452 | SAMSUNG | HG 49 EE 470 HK | 33 - 57" |
| 0464 | SAMSUNG | OH 55 D         | 33 - 57" |
| 0469 | SAMSUNG | SH 37 F         | 33 - 57" |
| 0475 | SAMSUNG | OH 46 F         | 33 - 57" |
| 0478 | SAMSUNG | OH 55 F         | 33 - 57" |
| 0485 | SAMSUNG | UE 49 NU 7100   | 33 - 57" |
| 0485 | SAMSUNG | UE 43 RU 7400   | 33 - 57" |
| 0485 | SAMSUNG | QM 43 N         | 33 - 57" |
| 0488 | SAMSUNG | PM 43 H         | 33 - 57" |
| 0681 | SAMSUNG | UE 55 NU 7021   | 33 - 57" |
| 9002 | SAMSUNG | LE 32 A 41 BS   | 15 - 32" |
| 9003 | SAMSUNG | SM 320 MX 3     | 15 - 32" |
| 9003 | SAMSUNG | MD 32 C         | 15 - 32" |
| 9003 | SAMSUNG | LE 32 D 400 E   | 15 - 32" |
| 9003 | SAMSUNG | 37 D 550        | 33 - 57" |
| 9003 | SAMSUNG | 400 BX          | 33 - 57" |
| 9003 | SAMSUNG | UN 46 C 7000    | 33 - 57" |
| 9003 | SAMSUNG | LE 46 C 650     | 33 - 57" |
| 9003 | SAMSUNG | 46 C 580        | 33 - 57" |
| 9003 | SAMSUNG | LE 46 C 580     | 33 - 57" |
| 9003 | SAMSUNG | LE 40 C 652     | 33 - 57" |
| 9003 | SAMSUNG | 40 C 7000       | 33 - 57" |
| 9003 | SAMSUNG | UE 46 C 5100    | 33 - 57" |
| 9003 | SAMSUNG | LE 46 C 750     | 33 - 57" |
| 9003 | SAMSUNG | LE 40 D 550     | 33 - 57" |
| 9003 | SAMSUNG | PS 50 B 530     | 33 - 57" |
| 9003 | SAMSUNG | TXP 50 G 20     | 33 - 57" |
| 9004 | SAMSUNG | 400 PNS         | 33 - 57" |
| 9004 | SAMSUNG | 400 P           | 33 - 57" |
| 9004 | SAMSUNG | SM 400 PXN      | 33 - 57" |
| 9004 | SAMSUNG | 460 P           | 33 - 57" |
| 9004 | SAMSUNG | PPM 42 M 5 SS   | 33 - 57" |
| 9004 | SAMSUNG | LE 46 F 71 B    | 33 - 57" |
| 9004 | SAMSUNG | PPM 42 M 7 HS   | 33 - 57" |
| 9004 | SAMSUNG | SM 460 DXN      | 33 - 57" |
| 9004 | SAMSUNG | LE 46 A 656 A 1 | 33 - 57" |
| 9004 | SAMSUNG | LE 46 A 559 P 4 | 33 - 57" |
| 9004 | SAMSUNG | SM 400 MXN      | 33 - 57" |
| 9004 | SAMSUNG | 400 CXN         | 33 - 57" |
| 9004 | SAMSUNG | PS 42 M 5       | 33 - 57" |
| 9004 | SAMSUNG | PS 42 M 6       | 33 - 57" |
| 9004 | SAMSUNG | PS 42 M 7       | 33 - 57" |
| 9004 | SAMSUNG | PS 42 P 5       | 33 - 57" |
| 9004 | SAMSUNG | PS 42 S 5       | 33 - 57" |
| 9004 | SAMSUNG | PPM 42 M 6      | 33 - 57" |
| 9004 | SAMSUNG | PS 42 C 91 HX   | 33 - 57" |
| 9004 | SAMSUNG | PS 42 C 96 HDX  | 33 - 57" |
| 9004 | SAMSUNG | SPDN 42 KLP     | 33 - 57" |

|      |         |                     |          |
|------|---------|---------------------|----------|
| 9004 | SAMSUNG | PS 42 Q 97 HD       | 33 - 57" |
| 9004 | SAMSUNG | LH 40 MG FLBS / 2 A | 33 - 57" |
| 9004 | SAMSUNG | SM 400 MX 2         | 33 - 57" |
| 9004 | SAMSUNG | SM 400 CXN 2        | 33 - 57" |
| 9004 | SAMSUNG | PS 42 V 6 S         | 33 - 57" |
| 9004 | SAMSUNG | LE 46 S 86 BDX      | 33 - 57" |
| 9004 | SAMSUNG | LE 46 N 73 BD       | 33 - 57" |
| 9004 | SAMSUNG | LE 46 F 86          | 33 - 57" |
| 9004 | SAMSUNG | LE 46 A 559         | 33 - 57" |
| 9004 | SAMSUNG | PS 42 Q 7 HD        | 33 - 57" |
| 9004 | SAMSUNG | 400 UXN             | 33 - 57" |
| 9004 | SAMSUNG | PS 42 E 7           | 33 - 57" |
| 9004 | SAMSUNG | SM 460 UXN          | 33 - 57" |
| 9004 | SAMSUNG | SM 460 MX 2         | 33 - 57" |
| 9004 | SAMSUNG | P 42 H 2            | 33 - 57" |
| 9004 | SAMSUNG | LE 46 M 53 BD       | 33 - 57" |
| 9004 | SAMSUNG | LH 40 MG QLBC       | 33 - 57" |
| 9004 | SAMSUNG | SM 400 MX 3         | 33 - 57" |
| 9004 | SAMSUNG | 400 DX 3            | 33 - 57" |
| 9004 | SAMSUNG | P 50 H              | 33 - 57" |
| 9004 | SAMSUNG | PPM 50 H 5 HS       | 33 - 57" |
| 9004 | SAMSUNG | PPM 50 M 5 HS       | 33 - 57" |
| 9004 | SAMSUNG | PS 50 Q 7 HD        | 33 - 57" |
| 9004 | SAMSUNG | PS 50 Q 97 HDX      | 33 - 57" |
| 9004 | SAMSUNG | PS 50 P 5 H         | 33 - 57" |
| 9004 | SAMSUNG | PPM 50 M 7          | 33 - 57" |
| 9004 | SAMSUNG | P 50 FP             | 33 - 57" |
| 9004 | SAMSUNG | P 50 HP             | 33 - 57" |
| 9004 | SAMSUNG | PS 50 C 96          | 33 - 57" |
| 9004 | SAMSUNG | UD 55 A             | 33 - 57" |

|      |       |                 |          |
|------|-------|-----------------|----------|
| 0012 | SANYO | PDP 42 WV 1 SR  | 33 - 57" |
| 0026 | SANYO | PDP 42 WE 1     | 33 - 57" |
| 0026 | SANYO | PDP 42 WE 2     | 33 - 57" |
| 0059 | SANYO | PDP 32 HIE      | 33 - 57" |
| 0060 | SANYO | PDP 42 H 1 EV   | 33 - 57" |
| 0094 | SANYO | LMU TK 29 C 1   | 15 - 32" |
| 0096 | SANYO | LMU TK 40       | 33 - 57" |
| 0111 | SANYO | LMU TK 40 CK 2  | 33 - 57" |
| 0181 | SANYO | CE 30 LC 3 B    | 33 - 57" |
| 0181 | SANYO | CE 30 LD 3 B    | 33 - 57" |
| 0186 | SANYO | CE 27 LC 3 B    | 33 - 57" |
| 0262 | SANYO | CE 32 LM 5      | 33 - 57" |
| 0262 | SANYO | CE 42 WPX 1     | 33 - 57" |
| 0262 | SANYO | CE 42 LM 4 R E  | 33 - 57" |
| 0262 | SANYO | CE 42 LM 4 WPRE | 33 - 57" |
| 0262 | SANYO | 42 LM 5         | 33 - 57" |
| 0262 | SANYO | 42 SR 4         | 33 - 57" |
| 0303 | SANYO | CE 42 LD 81 B   | 33 - 57" |
| 0309 | SANYO | CE 26 LD 33 B   | 33 - 57" |
| 0309 | SANYO | 32 LD 81        | 33 - 57" |
| 0309 | SANYO | CE 32 LD 33 B   | 33 - 57" |
| 0309 | SANYO | CE 37 FD 90     | 33 - 57" |

|      |            |                |           |
|------|------------|----------------|-----------|
| 0309 | SANYO      | CE 37 FD 33    | 33 - 57"  |
| 0315 | SANYO      | CE 42 LE 1     | 33 - 57"  |
| 0315 | SANYO      | CE 42 SRE 1    | 33 - 57"  |
| 0329 | SANYO      | CE 42 FD 33 B  | 33 - 57"  |
| 0329 | SANYO      | CE 42 LD 33 B  | 33 - 57"  |
| 0329 | SANYO      | CE 42 FD 90    | 33 - 57"  |
| 0335 | SANYO      | 52 LH 1 R      | 33 - 57"  |
| 0336 | SANYO      | CE 32 LD 90 B  | 33 - 57"  |
| 0336 | SANYO      | CE 32 FD 90    | 33 - 57"  |
| 0360 | SANYO      | CE 26 LD 90    | 33 - 57"  |
| 9002 | SANYO      | CE 32 LM 3 WPB | 15 - 32"  |
| 0221 | SAVILLE AV | KDEW 50 A 12 U | 33 - 57"  |
| 0315 | SAVILLE AV | HD 4200        | 33 - 57"  |
| 0275 | SCEPTRE    | X 37 SV - NAGA | 33 - 57"  |
| 0009 | SHARP      | 108            | 91 - 108" |
| 0027 | SHARP      | PZ 43 HV 2 E   | 33 - 57"  |
| 0027 | SHARP      | PZ 50 HV 2 E   | 33 - 57"  |
| 0074 | SHARP      | LC 37 HV 4 E   | 33 - 57"  |
| 0074 | SHARP      | LCM 3700       | 33 - 57"  |
| 0157 | SHARP      | LC 32 GA 3 E   | 33 - 57"  |
| 0157 | SHARP      | LC 32 GA 5 E   | 33 - 57"  |
| 0157 | SHARP      | LC 32 P 55 E   | 33 - 57"  |
| 0157 | SHARP      | LC 37 GA 8 E   | 33 - 57"  |
| 0157 | SHARP      | LC 32 GA 8 E   | 33 - 57"  |
| 0157 | SHARP      | LC 32 AD 5 E   | 33 - 57"  |
| 0157 | SHARP      | LC 32 WD 1 E   | 33 - 57"  |
| 0157 | SHARP      | LC 32 GA 9 E   | 33 - 57"  |
| 0157 | SHARP      | LC 32 P 50 E   | 33 - 57"  |
| 0157 | SHARP      | LC 37 GA 6     | 33 - 57"  |
| 0157 | SHARP      | LC 37 GD 1 E   | 33 - 57"  |
| 0157 | SHARP      | LC 32 GD 9 E   | 33 - 57"  |
| 0157 | SHARP      | LC 32 SA 1     | 33 - 57"  |
| 0157 | SHARP      | LC 32 SD 1 E   | 33 - 57"  |
| 0157 | SHARP      | LC 37 GE 1     | 33 - 57"  |
| 0157 | SHARP      | LC 46 XL 1 E   | 33 - 57"  |
| 0157 | SHARP      | LC 46 XD 1 E   | 33 - 57"  |
| 0157 | SHARP      | LC 46 LD 266 K | 33 - 57"  |
| 0157 | SHARP      | LC 42 LE 761 K | 33 - 57"  |
| 0157 | SHARP      | LC 42 LD 266 K | 33 - 57"  |
| 0157 | SHARP      | LC 42 SD 1 E   | 33 - 57"  |
| 0157 | SHARP      | LC 42 XD 1 E   | 33 - 57"  |
| 0157 | SHARP      | LC 37 GD 8     | 33 - 57"  |
| 0157 | SHARP      | LC 37 GD 7     | 33 - 57"  |
| 0157 | SHARP      | LC 37 P 50 E   | 33 - 57"  |
| 0157 | SHARP      | LC 37 P 55 E   | 33 - 57"  |
| 0157 | SHARP      | LC 42 AD 5 E   | 33 - 57"  |
| 0201 | SHARP      | LC 45 GD 1 E   | 33 - 57"  |
| 0218 | SHARP      | 26 D 44        | 33 - 57"  |
| 0262 | SHARP      | 32 D 44        | 33 - 57"  |
| 0276 | SHARP      | LC 52 XD 1 E   | 33 - 57"  |

|      |       |                  |          |
|------|-------|------------------|----------|
| 0276 | SHARP | LC 52 XL 1 E     | 33 - 57" |
| 0282 | SHARP | LCD 32 DH 57 E   | 33 - 57" |
| 0288 | SHARP | PN 465 E         | 33 - 57" |
| 0288 | SHARP | PNE 471          | 33 - 57" |
| 0288 | SHARP | LC 50 LE 751 K   | 33 - 57" |
| 0288 | SHARP | LC 50 LE 651 K   | 33 - 57" |
| 0298 | SHARP | LC 52 X 20 E     | 33 - 57" |
| 0298 | SHARP | 52 D 65          | 33 - 57" |
| 0298 | SHARP | LC 52 XL 2 E     | 33 - 57" |
| 0305 | SHARP | LC 42 LE 40 E    | 33 - 57" |
| 0305 | SHARP | LC 46 X 20 E     | 33 - 57" |
| 0305 | SHARP | LC 42 XL 2 E     | 33 - 57" |
| 0305 | SHARP | LC 42 B 20 E     | 33 - 57" |
| 0305 | SHARP | LC 46 XL 2 E     | 33 - 57" |
| 0305 | SHARP | LC 46 D 65       | 33 - 57" |
| 0305 | SHARP | LC 46 LE 600 E   | 33 - 57" |
| 0305 | SHARP | LC 46 LE 700 E   | 33 - 57" |
| 0305 | SHARP | LC 42 DH 77 E    | 33 - 57" |
| 0305 | SHARP | LC 46 LE 821 E   | 33 - 57" |
| 0305 | SHARP | LC 46 LE 811     | 33 - 57" |
| 0305 | SHARP | LC 46 LE 631 E   | 33 - 57" |
| 0305 | SHARP | LC 42 X 20 E     | 33 - 57" |
| 0305 | SHARP | LC 40 SH 340 K   | 33 - 57" |
| 0305 | SHARP | LC 40 LE 631 E   | 33 - 57" |
| 0307 | SHARP | LC 37 X 20 E     | 33 - 57" |
| 0307 | SHARP | LC 40 LE 600     | 33 - 57" |
| 0307 | SHARP | LC 40 LE 831 E   | 33 - 57" |
| 0307 | SHARP | LC 40 LE 700 E   | 33 - 57" |
| 0307 | SHARP | LC 32 X 20       | 33 - 57" |
| 0309 | SHARP | LC 42 CT 2 E     | 33 - 57" |
| 0310 | SHARP | PN 525 E         | 33 - 57" |
| 0310 | SHARP | PNE 521          | 33 - 57" |
| 0341 | SHARP | LC 32 LE 60      | 33 - 57" |
| 0341 | SHARP | LC 37 D 65 E     | 33 - 57" |
| 0369 | SHARP | PNU 423          | 33 - 57" |
| 0369 | SHARP | PNU 473          | 33 - 57" |
| 0369 | SHARP | PNU 553          | 33 - 57" |
| 0370 | SHARP | 52 LE 700        | 33 - 57" |
| 0370 | SHARP | LC 52 LE 831 E   | 33 - 57" |
| 0370 | SHARP | LC 50 LD 266 K   | 33 - 57" |
| 0370 | SHARP | LC 50 LE 761 K   | 33 - 57" |
| 0370 | SHARP | LC 52 LE 700 E   | 33 - 57" |
| 0370 | SHARP | PNQ 701 K        | 33 - 57" |
| 0399 | SHARP | PNE 802          | 71 - 90" |
| 0399 | SHARP | PNL 802 B        | 71 - 90" |
| 0401 | SHARP | LC 80 LE 646     | 71 - 90" |
| 0401 | SHARP | LC 90 LE 757 K   | 71 - 90" |
| 0413 | SHARP | PNR 903          | 71 - 90" |
| 0418 | SHARP | LC 80 LE 657 KN  | 71 - 90" |
| 0418 | SHARP | LC 80 UQ 10 KN   | 71 - 90" |
| 9001 | SHARP | LC 32 LD 166 K   | 15 - 32" |
| 9002 | SHARP | LC 32 LE 351 KBK | 15 - 32" |
| 9002 | SHARP | LC 32 LE 351 KWH | 15 - 32" |

|      |            |                  |             |
|------|------------|------------------|-------------|
| 9002 | SHARP      | LC 32 LD 145 K   | 15 - 32"    |
| 9002 | SHARP      | LC 32 LD 135 K   | 15 - 32"    |
| 9003 | SHARP      | LC 37 GA 3       | 33 - 57"    |
| 9003 | SHARP      | LC 40 LE 811     | 33 - 57"    |
| 9003 | SHARP      | LC 39 LE 751 K   | 33 - 57"    |
| 9003 | SHARP      | LC 39 LE 651 K   | 33 - 57"    |
| 9003 | SHARP      | LC 39 LE 351 KBK | 33 - 57"    |
| 9003 | SHARP      | LC 39 LE 351 KWH | 33 - 57"    |
| 9003 | SHARP      | LC 39 LD 145 K   | 33 - 57"    |
| 9003 | SHARP      | LC 39 LE 351 K   | 33 - 57"    |
| 9003 | SHARP      | PNE 421          | 33 - 57"    |
| 9004 | SHARP      | 37 XD 1 E        | 33 - 57"    |
| 0032 | SMARTBOARD | SB 580           | Interactive |
| 0228 | SMARTBOARD | SB 660           | Interactive |
| 0228 | SMARTBOARD | SB 680           | Interactive |
| 0264 | SMARTBOARD | SB 540           | Interactive |
| 0356 | SMARTBOARD | 6055             | 33 - 57"    |
| 0395 | SMARTBOARD | IWB 8055 I       | 33 - 57"    |
| 0416 | SMARTBOARD | SB 8084 I G4     | 71 - 90"    |
| 0436 | SMARTBOARD | 8055I G5         | 33 - 57"    |
| 0029 | SONY       | 42 PFM 500       | 33 - 57"    |
| 0030 | SONY       | FWD 40 LX 1      | 33 - 57"    |
| 0030 | SONY       | FWD 40 LX 2      | 33 - 57"    |
| 0030 | SONY       | 40 LX 2 FBC 2    | 33 - 57"    |
| 0030 | SONY       | PFM 42 B 1 E     | 33 - 57"    |
| 0030 | SONY       | PFM 42 V 1 E     | 33 - 57"    |
| 0030 | SONY       | PFM 42 V 1 N     | 33 - 57"    |
| 0030 | SONY       | FWD 42 PV 1      | 33 - 57"    |
| 0030 | SONY       | FWD 42 LX 1      | 33 - 57"    |
| 0030 | SONY       | PFM 42 X 1 N     | 33 - 57"    |
| 0030 | SONY       | FWD 42 PX 2      | 33 - 57"    |
| 0053 | SONY       | FWD 32 LX 1      | 33 - 57"    |
| 0053 | SONY       | FWD 32 LX 2 F    | 33 - 57"    |
| 0053 | SONY       | PFM 32 C 1 E     | 33 - 57"    |
| 0061 | SONY       | KZ 42 TS 1 E     | 33 - 57"    |
| 0061 | SONY       | KE 42 TS 2 E     | 33 - 57"    |
| 0062 | SONY       | KZ 32 TS 1 E     | 33 - 57"    |
| 0062 | SONY       | KE 32 TS 2 E     | 33 - 57"    |
| 0064 | SONY       | PFM 50 C 1 E     | 33 - 57"    |
| 0064 | SONY       | FWD 50 PX 1 NS   | 33 - 57"    |
| 0064 | SONY       | FWD 50 PX 2      | 33 - 57"    |
| 0064 | SONY       | FWD 50 X 1       | 33 - 57"    |
| 0064 | SONY       | FWD 50 PX 3      | 33 - 57"    |
| 0088 | SONY       | LDM 3000         | 15 - 32"    |
| 0088 | SONY       | KLV 30 MR 1      | 15 - 32"    |
| 0091 | SONY       | PDM 4200         | 33 - 57"    |
| 0091 | SONY       | KE 42 MR 1       | 33 - 57"    |
| 0091 | SONY       | KLVL 42 MRX 1    | 33 - 57"    |
| 0091 | SONY       | LDM 4210         | 33 - 57"    |
| 0091 | SONY       | KDEP 42 MRX 1    | 33 - 57"    |
| 0091 | SONY       | PDM 4210         | 33 - 57"    |

|      |      |                 |          |
|------|------|-----------------|----------|
| 0110 | SONY | 50 MR 1         | 33 - 57" |
| 0145 | SONY | KDL L 32 MRX 1  | 15 - 32" |
| 0145 | SONY | KLV L 32 MRX 1  | 15 - 32" |
| 0145 | SONY | LDM 3210        | 15 - 32" |
| 0147 | SONY | LMD 320 W       | 15 - 32" |
| 0147 | SONY | LMD 322 W       | 15 - 32" |
| 0147 | SONY | LMD 3250 MV     | 15 - 32" |
| 0153 | SONY | KLV L 32 M 1    | 15 - 32" |
| 0154 | SONY | KDEP 42 XS 1    | 33 - 57" |
| 0154 | SONY | KDEP 37 XS 1    | 33 - 57" |
| 0154 | SONY | KEP 42 M 1      | 33 - 57" |
| 0157 | SONY | KDL 32 V 4000   | 33 - 57" |
| 0214 | SONY | KDL 32 P 3020 U | 33 - 57" |
| 0214 | SONY | KDLS 32 A 12 U  | 33 - 57" |
| 0214 | SONY | KDL 32 S 5500   | 33 - 57" |
| 0218 | SONY | KDL 26 U 3000   | 33 - 57" |
| 0218 | SONY | LMD 2450 MD     | 33 - 57" |
| 0218 | SONY | FWD 32 EX 650 P | 33 - 57" |
| 0218 | SONY | FWD 32 B 1      | 33 - 57" |
| 0223 | SONY | KDLW 40 A 12 U  | 33 - 57" |
| 0230 | SONY | KDL 40 V 2000   | 33 - 57" |
| 0230 | SONY | KDL 46 X 2000   | 33 - 57" |
| 0230 | SONY | KDLS 40 A 12 U  | 33 - 57" |
| 0230 | SONY | KDL 40 S 2010   | 33 - 57" |
| 0254 | SONY | KDL 32 S 2010   | 33 - 57" |
| 0254 | SONY | 32 V 2500       | 33 - 57" |
| 0264 | SONY | KDL 32 U 2000   | 33 - 57" |
| 0266 | SONY | KDL 52 X 2000   | 33 - 57" |
| 0267 | SONY | KDL 40 U 2000   | 33 - 57" |
| 0287 | SONY | KDL 46 S 2530 U | 33 - 57" |
| 0287 | SONY | KDL 46 S 2000   | 33 - 57" |
| 0287 | SONY | KDL 46 S 2510   | 33 - 57" |
| 0287 | SONY | KDL 46 V 2500   | 33 - 57" |
| 0298 | SONY | GXDL 52 H 1     | 33 - 57" |
| 0300 | SONY | 40 S 3000       | 33 - 57" |
| 0300 | SONY | KDL 40 D 3500 U | 33 - 57" |
| 0300 | SONY | KDL 40 D 3000   | 33 - 57" |
| 0300 | SONY | FWD 40 W 600 P  | 33 - 57" |
| 0300 | SONY | FWDS 42 H 5     | 33 - 57" |
| 0300 | SONY | KDL 40 X 3000 U | 33 - 57" |
| 0300 | SONY | FWD 48 W 600 P  | 33 - 57" |
| 0305 | SONY | FWDS 42 H 1     | 33 - 57" |
| 0305 | SONY | 42 H 5          | 33 - 57" |
| 0305 | SONY | FWD 42 B 2      | 33 - 57" |
| 0305 | SONY | FWDS 42 H 2     | 33 - 57" |
| 0305 | SONY | FWDS 47 H       | 33 - 57" |
| 0305 | SONY | FWD 46 B 2      | 33 - 57" |
| 0305 | SONY | FWD-S 46 H 2    | 33 - 57" |
| 0305 | SONY | LMD 4250 K      | 33 - 57" |
| 0305 | SONY | FWDS 55 H 2     | 33 - 57" |
| 0305 | SONY | FWD 55 B 2      | 33 - 57" |
| 0307 | SONY | KDL 40 LX 903 U | 33 - 57" |
| 0308 | SONY | KDL 55 EX 713 U | 33 - 57" |



|      |      |                    |          |
|------|------|--------------------|----------|
| 0308 | SONY | KDL 52 W 3000      | 33 - 57" |
| 0308 | SONY | KDL 52 X 3500      | 33 - 57" |
| 0327 | SONY | KDL 52 NX 803      | 33 - 57" |
| 0327 | SONY | 52 W 4000          | 33 - 57" |
| 0327 | SONY | KDL 52 V 4000 U    | 33 - 57" |
| 0327 | SONY | 52 V 5500          | 33 - 57" |
| 0327 | SONY | KDL 52 W 5500      | 33 - 57" |
| 0327 | SONY | KDL 52 V 5100      | 33 - 57" |
| 0327 | SONY | KDL 52 W 5810      | 33 - 57" |
| 0327 | SONY | KDL 52 V 5810      | 33 - 57" |
| 0327 | SONY | KDL 52 Z 4500      | 33 - 57" |
| 0327 | SONY | KDL 52 EX 703 U    | 33 - 57" |
| 0327 | SONY | FWD 55 HX 750 P    | 33 - 57" |
| 0327 | SONY | KDL 55 EX 720 P    | 33 - 57" |
| 0332 | SONY | KDL 40 R 473 A     | 33 - 57" |
| 0333 | SONY | KDL 46 V 3000      | 33 - 57" |
| 0341 | SONY | KDL 32 W 5500      | 33 - 57" |
| 0341 | SONY | KDL 32 EX 401      | 33 - 57" |
| 0341 | SONY | KDL 32 W 5710      | 33 - 57" |
| 0341 | SONY | KDL 32 EX 503      | 33 - 57" |
| 0341 | SONY | FW 49 BZ 35 F      | 33 - 57" |
| 0344 | SONY | 40 W 5710          | 33 - 57" |
| 0344 | SONY | KDL 40 V 5500      | 33 - 57" |
| 0344 | SONY | KDL 40 V 5810      | 33 - 57" |
| 0344 | SONY | KDL 40 W 5740      | 33 - 57" |
| 0344 | SONY | KDL 40 W 5810      | 33 - 57" |
| 0344 | SONY | KDL 37 W 5810      | 33 - 57" |
| 0344 | SONY | KDL 37 EX 524      | 33 - 57" |
| 0344 | SONY | KDL 37 S 5500      | 33 - 57" |
| 0344 | SONY | FWD 40 EX 650 P    | 33 - 57" |
| 0344 | SONY | FWD 42 W 800 P/T   | 33 - 57" |
| 0344 | SONY | FWD 42 W 800 P     | 33 - 57" |
| 0344 | SONY | KDL 40 HX 723      | 33 - 57" |
| 0344 | SONY | KDL 40 CX 520 P    | 33 - 57" |
| 0344 | SONY | KDL 46 EX 521 P    | 33 - 57" |
| 0344 | SONY | KDL 46 CX 520 P    | 33 - 57" |
| 0344 | SONY | KDL 46 V 4000 U    | 33 - 57" |
| 0344 | SONY | KDL 40 EX 503 U    | 33 - 57" |
| 0344 | SONY | KDL 40 L 4000      | 33 - 57" |
| 0344 | SONY | KDL 46 W 5810      | 33 - 57" |
| 0344 | SONY | KDL 40 S 5500      | 33 - 57" |
| 0344 | SONY | KDL 46 Z 4500      | 33 - 57" |
| 0344 | SONY | KDL 40 EX 401 U    | 33 - 57" |
| 0344 | SONY | KDL 46 EX 403      | 33 - 57" |
| 0344 | SONY | KDL 40 EX 523      | 33 - 57" |
| 0344 | SONY | KDL 46 W 55        | 33 - 57" |
| 0344 | SONY | FWD 46 EX 650 P    | 33 - 57" |
| 0344 | SONY | FWD 47 W 800 P / T | 33 - 57" |
| 0344 | SONY | FWD 47 W 800 P     | 33 - 57" |
| 0344 | SONY | KDL 40 EX 501 P    | 33 - 57" |
| 0344 | SONY | KDL 46 EX 723      | 33 - 57" |
| 0344 | SONY | KDL 40 EX 500 P    | 33 - 57" |
| 0344 | SONY | FWD 55 W 800 P / T | 33 - 57" |

|      |            |                  |          |
|------|------------|------------------|----------|
| 0344 | SONY       | FWD 55 W 800 P   | 33 - 57" |
| 0344 | SONY       | FWD 55 X 8600 P  | 33 - 57" |
| 0344 | SONY       | FW 55 X 8570 C   | 33 - 57" |
| 0344 | SONY       | FW 65 BZ 35 F    | 33 - 57" |
| 0348 | SONY       | KLH 40 X 1       | 33 - 57" |
| 0356 | SONY       | 55 PFL 6606 T    | 33 - 57" |
| 0373 | SONY       | KDL 55 EX 503    | 33 - 57" |
| 0402 | SONY       | KDL 40 EX 521    | 33 - 57" |
| 0417 | SONY       | KDL 32 W 653     | 33 - 57" |
| 0417 | SONY       | KDL 42 W 654 A   | 33 - 57" |
| 0417 | SONY       | KDL 50 W 685     | 33 - 57" |
| 0432 | SONY       | KDL 42 7 SERIES  | 33 - 57" |
| 0432 | SONY       | KDL 50 W 829 B   | 33 - 57" |
| 0442 | SONY       | KDL 32 W 706 B   | 33 - 57" |
| 0448 | SONY       | FWL 75 W 855 C   | 71 - 90" |
| 0448 | SONY       | FW 75 XD 8501    | 71 - 90" |
| 0448 | SONY       | FW 85 XD 8501    | 71 - 90" |
| 0448 | SONY       | FW 75 BZ 35 F    | 71 - 90" |
| 0468 | SONY       | FWL 55 W 805 C   | 33 - 57" |
| 0477 | SONY       | KD 55 XE 7002    | 33 - 57" |
| 0477 | SONY       | FW 55 BZ 35 F    | 33 - 57" |
| 0481 | SONY       | FW 43 XE 8001    | 33 - 57" |
| 0481 | SONY       | FW 43 BZ 35 F    | 33 - 57" |
| 0482 | SONY       | FW 85 BZ 35 F    | 71 - 90" |
| 9002 | SONY       | KLTV 30 HR 3     | 15 - 32" |
| 9003 | SONY       | KDL 55 EX 500    | 33 - 57" |
| 0189 | STARMEDIA  | LCDTV 32         | 33 - 57" |
| 0045 | TATUNG     | TPD 4201 S       | 33 - 57" |
| 0045 | TATUNG     | TPT 4202 S       | 33 - 57" |
| 0171 | TATUNG     | TLT 3001 S       | 33 - 57" |
| 0191 | TATUNG     | P 50 BSAT        | 33 - 57" |
| 0136 | TECHWOOD   | TWP 4210         | 33 - 57" |
| 0370 | TELEFUNKEN | D 50 F 275 N 3 C | 33 - 57" |
| 0250 | TEW        | T 42 - 122       | 33 - 57" |
| 0026 | THOMSON    | 42 WS 90 E       | 33 - 57" |
| 0026 | THOMSON    | 50 WS 94 E       | 33 - 57" |
| 0045 | THOMSON    | 42 WM 02 L       | 33 - 57" |
| 0045 | THOMSON    | 42 WM 03 L       | 33 - 57" |
| 0045 | THOMSON    | 42 PB 040 B 5    | 33 - 57" |
| 0059 | THOMSON    | 32 PW 95 E       | 33 - 57" |
| 0059 | THOMSON    | 32 WS 95 E       | 33 - 57" |
| 0089 | THOMSON    | 42 WB 02 S       | 33 - 57" |
| 0089 | THOMSON    | 42 MB 03 SW      | 33 - 57" |
| 0089 | THOMSON    | 42 WM 04 ST      | 33 - 57" |
| 0105 | THOMSON    | 27 LCD B 03 B    | 15 - 32" |
| 0105 | THOMSON    | 30 LCD B 03      | 15 - 32" |
| 0105 | THOMSON    | 32 LB 120 S 4 U  | 15 - 32" |

|      |         |                 |          |
|------|---------|-----------------|----------|
| 0140 | THOMSON | 50 WP 03 P      | 33 - 57" |
| 0197 | THOMSON | 42 PB 020       | 33 - 57" |
| 0222 | THOMSON | 32 LB 04 S 5 U  | 33 - 57" |
| 0285 | THOMSON | LB 138 B 5      | 33 - 57" |
| 0067 | TINY    | 42              | 33 - 57" |
| 0067 | TINY    | HC PLASMA TV TY | 33 - 57" |
| 0012 | TOSHIBA | PD 42 BW 1 E    | 33 - 57" |
| 0012 | TOSHIBA | 42 WP 37        | 33 - 57" |
| 0012 | TOSHIBA | 50 XP 27        | 33 - 57" |
| 0012 | TOSHIBA | 50 WP 16 B      | 33 - 57" |
| 0012 | TOSHIBA | PD 42 W 16 E    | 33 - 57" |
| 0082 | TOSHIBA | 47 Z 3030       | 33 - 57" |
| 0116 | TOSHIBA | 32 WL 36 P      | 15 - 32" |
| 0151 | TOSHIBA | 42 WP 36 P      | 33 - 57" |
| 0157 | TOSHIBA | 32 WLT 58       | 33 - 57" |
| 0157 | TOSHIBA | 32 WLT 68       | 33 - 57" |
| 0157 | TOSHIBA | 32 WLT 66       | 33 - 57" |
| 0157 | TOSHIBA | 32 C 3030       | 33 - 57" |
| 0157 | TOSHIBA | 32 C 3031       | 33 - 57" |
| 0157 | TOSHIBA | 37 WLT 66       | 33 - 57" |
| 0157 | TOSHIBA | 37 WL 66 P      | 33 - 57" |
| 0157 | TOSHIBA | 32 C 3035       | 33 - 57" |
| 0157 | TOSHIBA | 39 L 4353       | 33 - 57" |
| 0157 | TOSHIBA | 39 L 2333       | 33 - 57" |
| 0157 | TOSHIBA | 42 WLT 58       | 33 - 57" |
| 0157 | TOSHIBA | 42 A 3030       | 33 - 57" |
| 0157 | TOSHIBA | 42 C 3035       | 33 - 57" |
| 0157 | TOSHIBA | 42 WLT 66       | 33 - 57" |
| 0157 | TOSHIBA | 42 WLT 68       | 33 - 57" |
| 0157 | TOSHIBA | 37 WLT 68       | 33 - 57" |
| 0173 | TOSHIBA | 42 WP 46 P      | 33 - 57" |
| 0248 | TOSHIBA | 37 WLT 58       | 33 - 57" |
| 0256 | TOSHIBA | 47 WLT 66       | 33 - 57" |
| 0262 | TOSHIBA | 32 XV 55        | 33 - 57" |
| 0262 | TOSHIBA | 32 AV 615 DB    | 33 - 57" |
| 0262 | TOSHIBA | 32 AV 635       | 33 - 57" |
| 0262 | TOSHIBA | 32 A 3000 P     | 33 - 57" |
| 0262 | TOSHIBA | 32 AV 504       | 33 - 57" |
| 0262 | TOSHIBA | 32 DV 713 B     | 33 - 57" |
| 0288 | TOSHIBA | 42 XV 635       | 33 - 57" |
| 0319 | TOSHIBA | 52 Z 3030       | 33 - 57" |
| 0319 | TOSHIBA | 52 XV 555       | 33 - 57" |
| 0319 | TOSHIBA | 55 ZV 635       | 33 - 57" |
| 0319 | TOSHIBA | 57 Z 3030       | 33 - 57" |
| 0319 | TOSHIBA | 55 WL 53 B      | 33 - 57" |
| 0334 | TOSHIBA | 42 C 505        | 33 - 57" |
| 0334 | TOSHIBA | 42 RV 555       | 33 - 57" |
| 0334 | TOSHIBA | 42 AV 635       | 33 - 57" |
| 0334 | TOSHIBA | 46 XV 635 DB    | 33 - 57" |
| 0334 | TOSHIBA | 42 CV 505 DB    | 33 - 57" |
| 0334 | TOSHIBA | 42 XV 505 DB    | 33 - 57" |

|      |           |              |          |
|------|-----------|--------------|----------|
| 0334 | TOSHIBA   | 40 RV 733    | 33 - 57" |
| 0334 | TOSHIBA   | 50 L 7355    | 33 - 57" |
| 0334 | TOSHIBA   | 50 L 4353    | 33 - 57" |
| 0334 | TOSHIBA   | 50 L 2333    | 33 - 57" |
| 0334 | TOSHIBA   | 40 L 1333    | 33 - 57" |
| 0334 | TOSHIBA   | 40 L 1353    | 33 - 57" |
| 0334 | TOSHIBA   | 40 L 1354    | 33 - 57" |
| 0334 | TOSHIBA   | 40 BV 702    | 33 - 57" |
| 0334 | TOSHIBA   | 42 HL 833 B  | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 133 DB  | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 7355    | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 6353    | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 1353 DB | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 1354 DB | 33 - 57" |
| 0341 | TOSHIBA   | 40 L 1333 DB | 33 - 57" |
| 0341 | TOSHIBA   | 40 HL 933 B  | 33 - 57" |
| 0379 | TOSHIBA   | 32 BV 700    | 33 - 57" |
| 0401 | TOSHIBA   | 84 L 9363    | 71 - 90" |
| 0404 | TOSHIBA   | 48 U 7653 DB | 33 - 57" |
| 0424 | TOSHIBA   | TDZ 551      | 33 - 57" |
| 9000 | TOSHIBA   | 32 WL 46     | 15 - 32" |
| 9002 | TOSHIBA   | 32 D 1333    | 15 - 32" |
| 9002 | TOSHIBA   | 32 L 4353    | 15 - 32" |
| 9002 | TOSHIBA   | 32 L 6353    | 15 - 32" |
| 9002 | TOSHIBA   | 32 W 4333    | 15 - 32" |
| 9002 | TOSHIBA   | 32 W 1333 DB | 15 - 32" |
| 9002 | TOSHIBA   | 32 W 1333    | 15 - 32" |
| 9002 | TOSHIBA   | 32 L 1353 DB | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 512    | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 712    | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 504    | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 702    | 15 - 32" |
| 9002 | TOSHIBA   | 32 BV 502    | 15 - 32" |
| 9003 | TOSHIBA   | 32 BV 801    | 15 - 32" |
| 9003 | TOSHIBA   | 40 BV 705    | 33 - 57" |
| 9004 | TOSHIBA   | 42 WP 56 P   | 33 - 57" |
| 0347 | TVS       | KA 42        | 33 - 57" |
| 0005 | UNIVERSAL | MVP 2420     | 33 - 57" |
| 0005 | UNIVERSAL | MVP 420      | 33 - 57" |
| 0055 | UNIVERSAL | MVP 3202     | 33 - 57" |
| 0403 | U-TOUCH   | CSLCD 70     | 71 - 90" |
| 0082 | VIEWSONIC | CD 4220      | 33 - 57" |
| 0170 | VIEWSONIC | N 3000 W     | 33 - 57" |
| 0189 | VIEWSONIC | N 3200 W     | 33 - 57" |
| 0220 | VIEWSONIC | N 3260 W     | 33 - 57" |
| 0220 | VIEWSONIC | N 3766 W     | 33 - 57" |
| 0220 | VIEWSONIC | N 3760 W     | 33 - 57" |
| 0220 | VIEWSONIC | N 4060 W     | 33 - 57" |
| 9003 | VIEWSONIC | CD 3200      | 15 - 32" |

|      |            |              |          |
|------|------------|--------------|----------|
| 0014 | VISION     | PM 4204      | 33 - 57" |
| 0045 | VISION     | GPTM 4200 HA | 33 - 57" |
| 0045 | VISION     | DCM 42 WBP   | 33 - 57" |
| 0045 | VISION     | DCM 42 WT    | 33 - 57" |
| 0045 | VISION     | DCM 42 HBL   | 33 - 57" |
| 0092 | VISION     | PM 4230      | 33 - 57" |
| 0120 | VISION     | LT 30 FEP    | 15 - 32" |
| 0138 | VISION     | 30 V 2       | 15 - 32" |
| 0144 | VISION     | OP 50 TI     | 33 - 57" |
| 0182 | VISION     | PTS 4241     | 33 - 57" |
| 0182 | VISION     | PM 4241      | 33 - 57" |
| 0211 | VISION     | P 42 SX      | 33 - 57" |
| 0235 | VISION     | GLTM 550 B   | 33 - 57" |
| 0242 | VISION     | VMD 4200 P   | 33 - 57" |
| 0270 | VISION     | LT 5520 APN  | 33 - 57" |
| 0005 | VUTRIX     | 42 MM        | 33 - 57" |
| 0076 | VUTRIX     | 30           | 33 - 57" |
| 0067 | WHARFEDALE | W 42 S 40 PE | 33 - 57" |
| 0386 | WHARFEDALE | LCD 32 HDM 1 | 33 - 57" |